# INSTALLATION, OPERATION, PARTS LIST, AND MAINTENANCE MANUAL

GORMAN-RUPP
OM-00978-0E02

ACE

March 10, 1980

# Engine Driven Self-Priming Centrifugal Pump Model 88A2-5044



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.



This Installation, Operation, and Maintenance Manual is designed specifically to help you get the best performance and longest life from your Gorman-Rupp pump.

This pump is an 80 series, semi-enclosed impeller, self-priming centrifugal model. It is designed for straight-in suction where the medium being pumped enters directly to the impeller eye.

If there are any questions regarding the pump which are not covered in this manual or in other literature accompanying the unit, please contact your Gorman-Rupp distributor, or write:

> The Gorman-Rupp Company P.O. Box 1217

Mansfield, Ohio 44902

Gorman-Rupp of Canada Limited

70 Burwell Road

St. Thomas, Ontario N5P 3R7

For information or technical assistance on the power source, contact the power source manufacturer's local dealer or representative.

The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:

### NOTE

Instructions to aid in installation, operation, or maintenance or which clarify a procedure.

### CAUTION

Instructions which must be followed to avoid causing damage to the product or other equipment incidental to the installation. These describe the procedure required and the damage which could result from failure to follow the procedure.

### WARNING

Instructions which must be followed to avoid causing injury or death to personnel. These describe the procedure required and the injury which could result from failure to follow the procedure.

### TABLE OF CONTENTS

WARNINGS INSTALLATION **OPERATION** TROUBLESHOOTING MAINTENANCE AND REPAIR WARRANTY

Section A

Section B

Section C

Section D

Section E



# **WARNINGS**

THESE WARNINGS APPLY TO ALL ENGINE DRIVEN PUMPS. REFER TO THE MANUAL ACCOMPANYING THE ENGINE BEFORE ATTEMPTING TO START THE ENGINE.

Before attempting to open or service the pump: 1. Familiarize yourself with this manual. 2. Disconnect the power source to ensure that the pump will remain inoperative. 3. Allow the pump to cool if overheated. 4. Vent the pump slowly and cautiously. 5. Close the suction and discharge valves. 6. Check the temperature before opening any covers, plates, or plugs. 7. Drain the pump. Do not attempt to pump volatile or corrosive materials for which this pump has not been designed. After the pump has been located in its operating position, make certain that the pump has been secured before attempting to operate it. Do not operate the pump without shields and/or guards in place over drive shafts, belts and/or couplings, or other rotating parts. Exposed rotating parts can catch clothing, fingers, or tools, causing severe injury to personnel. Do not operate the pump against a closed discharge valve for long periods of time. This could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode.

Section A. Page 1



Overheated pumps can cause severe burns and injury. If overheating of the pump casing occurs:

- 1. Stop the pump immediately.
- 2. Allow the pump to cool.
- 3. Refer to instructions in this manual before restarting the pump.

Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to cool before servicing.

Do not operate an internal combustion engine in an explosive atmosphere. When operating internal combustion engines in an enclosed area, make certain that exhaust fumes are piped to the outside. These fumes contain carbon monoxide, a deadly gas that is colorless, tasteless, and odorless.

Fuel used by internal combustion engines presents an extreme explosion and fire hazard. Make certain that all fuel lines are securely connected and free of leaks. Never refuel a hot or running engine. Avoid overfilling the fuel tank. Always use the correct type of fuel.

Never tamper with the governor to gain more power. The governor establishes safe operating limits that should not be exceeded.

Page 2 Section A.



# INSTALLATION

Seldom are two pump installations identical. The information presented in this section is a summary of the recommended installation practices related to inspection, pump positioning, hardware, suction and discharge piping, and sumps. For further assistance, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

### PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before it was shipped from the factory. Before installation, inspect the pump for damage which may have occurred during shipment. Check as follows:

- a. Inspect the pump assembly for cracks, dents, damaged threads, and other obvious damage.
- b. Check for and tighten loose bolts, nuts, cap screws, and other attaching hardware. Since gaskets tend to shrink after drying, check for and tighten loose nuts and cap screws securing mating surfaces.
- c. Carefully read all tags, decals, and markings on the pump assembly, and perform all duties indicated. Note the direction of rotation indicated on the pump.
- d. Check all lubricant levels and lubricate as necessary. Refer to the MAINTENANCE AND REPAIR section of this manual.

### POSITIONING THE PUMP

### Mounting

Locate the pump in an accessible place as close as practical to the liquid to be pumped. Level mounting is essential for proper operation. The pump may have to be supported to provide for level operation or to eliminate vibration.

Section B. Page 1



### Lifting



Make sure that hoists and other lifting equipment are of sufficient capacity to safely handle the pump assembly. Attach the lifting mechanism to the bail, eye bolt, or other specific lifting device provided on the pump. If no specific lifting device is provided and chains or cables must be used, make certain that they are positioned so that they will not damage the pump, and so that the load will be balanced.

### CAUTION

The pump assembly can be seriously damaged if the cables or chains used to lift and move the unit are improperly wrapped around it.

### SUCTION AND DISCHARGE PIPING

### Materials

Either pipe or hose may be used for suction and discharge lines, but hose used in suction lines must be the rigid-wall, reinforced type to prevent collapse under suction. Using pipe couplings in suction lines is not recommended.

### Line Configuration

Keep suction and discharge lines as straight as possible to minimize friction losses. Make minimum use of elbows and fittings, which substantially increase friction loss. If elbows are necessary, use the long-radius type to minimize friction loss.

### Connections to Pump

Never pull a pipe line into place by tightening the flange bolts. The connecting flange must be aligned exactly with the pump port. Lines near the pump must be independently supported to avoid strain on the pump which could cause serious vibration, decreased bearing life, and increased shaft and seal wear. Hose-type lines should have supports strong enough to secure the line when it is filled with liquid and under pressure.

### Gauges

Most pumps are drilled and tapped for installing discharge pressure and vacuum suction gauges. If these gauges are desired for pumps that are not tapped, drill and tap the suction and discharge lines close to the pump before installing the lines.

Page 2 Section B.



### **SUCTION LINES**

To avoid air pockets which could affect pump priming, the suction line must be as short and direct as possible. When operation involves a suction lift, the line must always slope upward to the pump from the source of the liquid being pumped; if the line slopes down to the pump at any point along the suction run, air pockets will be created.

### **Fittings**

Suction lines should be the same size as the pump inlet. If reducers are used in suction lines, they should be the eccentric type, and should be installed with the flat part of the reducers uppermost to avoid creating air pockets. Valves are not normally used in suction lines, but if a valve is used, install it with the stem down or to either side to avoid air pockets.

### **Strainers**

Install a strainer at the end of the suction line to avoid possible clogging or damage to the pump. The total area of the openings in the strainer should be at least three or four times the cross section of the suction line, but no opening should be larger than the solids handling capability of the pump. Clean the strainer regularly during operation.

### Sealing

All connections in the suction line should be sealed with pipe dope to ensure an airtight seal. Even a slight leak will affect priming, head, and capacity, especially when operating with a high suction lift. After installation, inspect the suction line carefully for potential leaks.

### DISCHARGE LINES

### Throttling Valves

If a throttling valve is desired, install it in the discharge line. Use a valve as large as the largest pipe in the line to minimize friction losses. Never install a throttling valve in the suction line.

### Check Valves

A check valve in the discharge line is normally recommended, but is not necessary in low discharge head applications.

With high discharge heads, install a throttling valve and a check valve in the discharge line to protect the pump from excessive shock pressure and reverse rotation when it is stopped.

### **Bypass Lines**

If it is necessary to permit the escape of air to atmosphere during initial priming or in the repriming cycle, install a bypass line between the pump and the discharge check valve. The bypass line should be sized so that it does not affect pump discharge capacity.

Either a Gorman-Rupp automatic air release valve—which will automatically open to allow the pump to prime, and automatically close when priming is accomplished—or a hand-operated shutoff valve should be installed in the bypass line.

Section B. Page 3



### NOTE

The bypass line may clog frequently, particularly if the valve remains closed. If this condition occurs, either use a larger bypass line or leave the shutoff valve open during the pumping operation.

Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line. Otherwise, a siphoning action could result, causing damage to the pump.

### SUCTION LINE POSITIONING

The depth of submergence of the suction line is critical to efficient pump operation. Figure 1 shows recommended minimum submergence vs. velocity.




Figure 1. Recommended Minimum Suction Line Submergence Vs. Velocity

Page 4 Section B.



### **OPERATION**



### **PRIMING**

Install the pump and piping as described in INSTALLATION. Make sure that the piping connections are tight, and that the pump is securely mounted. Check that the pump is properly lubricated (see LUBRICATION in MAINTENANCE AND REPAIR).

This pump is self priming, but the pump volute casing must first be filled with liquid if:

- 1. The pump is being put into service for the first time.
- 2. The pump has not been used for a considerable length of time.
- 3. The liquid in the volute casing has evaporated.

Once the volute casing has been filled, the pump will prime and reprime as necessary.

### CAUTION

Never operate a self-priming pump unless the volute is filled with liquid. The pump will not prime when dry. Extended operation of a dry pump will destroy the seal assembly.

To fill the pump, remove the volute fill cover or fill plug at the top of the casing and add clean liquid until the pump is filled. Replace the fill cover or fill plug before operating the pump.

### **STARTING**

Consult the operating manual furnished with the power source.

### **OPERATION**

### Lines With a Bypass

Either a Gorman-Rupp automatic air release valve or a hand operated shutoff valve may be installed in a bypass line.

If a Gorman-Rupp automatic air release valve has been installed, close the throttling valve in the discharge line. The Gorman-Rupp valve will automatically open to allow the pump to prime, and automatically close when priming has been accomplished. After the pump has been primed, and liquid is flowing steadily from the bypass line, open the discharge throttling valve.



If a hand operated shutoff valve has been installed, close the throttling valve in the discharge line, and open the bypass shutoff valve so that the pump will not have to prime against the weight of the liquid in the discharge line. When the pump has been primed, and liquid is flowing steadily from the bypass line, close the bypass shutoff valve and open the discharge throttling valve.

### Lines Without a Bypass

Open all valves in the discharge line and start the power source. Priming is indicated by a positive reading on the discharge pressure gauge or by quieter operation. The pump may not prime immediately because the suction line must first fill with liquid. If the pump fails to prime within five minutes, stop it and check the suction line for leaks.


After the pump has been primed, partially close the discharge line throttling valve in order to fill the line slowly and guard against excessive shock pressure which could damage pipe ends, gaskets, sprinkler heads, and any other fixtures connected to the line. When the discharge line is completely filled, adjust the throttling valve to the required discharge flow rate.

### Leakage

No leakage should be visible at pump mating surfaces, or at pump connections or fittings. Keep all line connections and fittings tight to maintain maximum pump efficiency.

### Overheating

Overheating can occur if the valves in the suction or discharge lines are closed. Operating against closed valves could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode. If overheating occurs, stop the pump and allow it to cool before servicing it. Refill the volute casing with cool liquid.



### Strainer Check

Check the suction strainer regularly during pump operation, or if the pump flow rate begins to drop, and clean it as necessary. Be especially alert for unusual noises when pumping liquids containing solids.

### Pump Vacuum Check

Install a vacuum gauge in the system, using pipe dope on the threads.

The pump should pull a vacuum of 20 inches or more of mercury at operating speed with the suction line blocked. If it does not, check for air leaks in the seals or gaskets.

Page 2 Section C.



With the pump primed and at operating speed, and the suction line open, read the vacuum gauge. Shut off the pump, keep the vacuum line open, and read the gauge again to see if the vacuum remains at the maximum developed by the pump. If the vacuum falls off rapidly, an air leak exists. If the liquid level at the source of supply remains at a constant level, check to make certain that the air leak is not from the vacuum gauge connection.

### **STOPPING**

After stopping the pump, disconnect the power source to ensure that the pump will remain inoperative.

In below freezing conditions, drain the pump to prevent damage from freezing. Also, clean out any solids by flushing with a hose. Operate the pump for approximately one minute; this will remove any remaining liquid that could freeze the pump rotating parts.

If the pump will be idle for more than a few hours, or if it has been pumping liquids containing a large amount of solids, drain the pump, and flush it thoroughly with clean water. To prevent large solids from clogging the drain port and preventing the pump from completely draining, operate the pump during the draining process. Clean out any remaining solids by flushing with a hose.

### BEARING TEMPERATURE CHECK

Bearings normally run at higher than ambient temperatures because of heat generated by friction. Temperatures up to 160°F are considered normal for intermediate bearings, and they can operate safely to at least 180°F.

Checking bearing temperatures by hand is inaccurate. Bearing temperatures can be measured accurately by placing a contact-type thermometer against the housing. Record this temperature for future reference.

A sudden increase in bearing temperatures is a warning that the bearings are at the point of failing to operate properly. Make certain that the bearing lubricant is of the proper viscosity and at the correct level (see LUBRICATION in MAINTENANCE AND REPAIR). Bearing overheating can also be caused by shaft misalignment and/or excessive vibration.

When pumps are first started, the bearings may seem to run at temperatures above normal. Continued operation should bring the temperatures down to normal levels.

Section C. Page 3



# **TROUBLESHOOTING**

### WARNING

Before attempting to open or service the pump:

- 1. Consult pump service manual.
- 2. Disconnect the power source to ensure that the pump will remain inoperative.
- 3. Allow pump to cool if overheated.
- 4. Close suction and discharge valves.
- 5. Drain pump.

Trouble	Possible Cause	Probable Remedy		
PUMP FAILS TO	Air leak in suction line.	Correct leak.		
PRIME	Lining of suction hose collapsed.	Replace suction hose.		
	Suction check valve clogged or binding.	Clean valve.		
	Leaking or worn seal or pump gasket.	Check pump vacuum. Replace leaking or worn seal or gasket.		
	Suction lift or discharge head too high.	Check piping installation and install bypass line if needed. See INSTALLATION.		
	Suction strainer clogged.	Clean suction strainer.		
PUMP STOPS OR	Air leak in suction line.	Correct leak.		
FAILS TO DE- LIVER RATED FLOW OR PRESSURE	Suction intake not sub- merged at proper level or sump too small.	Check installation and correct as needed. Check submergence chart (Section B, page 4).		
	Lining of suction hose collapsed.	Replace suction hose.		
	Impeller or other wearing parts worn or damaged.	Check impeller clearance. Replace worn parts as needed.		
	Impeller clogged.	Free impeller of debris.		
	Pump speed too slow.	Check driver output.		
	Discharge head too high.	Install bypass line.		
·	Suction lift too high.	Reduce suction lift.		


Section D. Page 1



Trouble	Possible Cause	Probable Remedy	
PUMP STOPS OR FAILS TO DE- LIVER RATED	Leaking or worn seal or pump gaskets.	Check pump vacuum. Replace leaking o worn seal or pump gaskets.	
FLOW OR PRESSURE (cont)	Suction strainer clogged.	Clean suction strainer.	
PUMP REQUIRES	Pump speed too high.	Reduce speed of power source.	
POWER	Discharge head too low.	Adjust discharge valve.	
	Liquid solution too thick.	Dilute if possible.	
PUMP CLOGS FREQUENTLY	Discharge flow too slow.	Open discharge valve fully to increase flow rate, and run engine at maximum governed speed.	
	Suction check valve clogged or binding.	Free valve, and clean or replace it.	
EXCESSIVE NOISE	Cavitation in pump.	Reduce suction lift and/or friction losses in suction line.	
	Pumping entrained air.	Locate and eliminate source of air bubble.	
	Pump or drive not securely mounted.	Secure mounting hardware.	
	Impeller clogged or damaged.	Clean out debris; replace damaged parts.	
BEARINGS RUN TOO HOT	Bearing temperature is high, but within limits.	Check bearing temperature frequently to monitor any increase.	
	Low or incorrect lubricant.	Check for proper type and level of lubricant.	
	Suction and discharge lines not properly supported.	Check piping installation for proper support.	
	Drive misaligned.	Align drive properly.	

Page 2 Section D.





The only moving parts of this pump are the impeller, seal rotating elements, and the shaft. The wear plate, impeller, and seal, which receive the most wear, are easily accessible, and can be replaced without disturbing the volute piping. Maintenance and replacement of these three parts will maintain the peak operating efficiency of the pump.



# SECTIONAL DRAWING




Figure 1. Pump Model 88A2-5044



# PARTS LIST

ITEM NO.	MODEL 88A2-5044 PART NAME	PART NUMBER	MATL CODE	NO. REQ	ITEM NO.	MODEL 88A2-5044 PART NAME	PART NUMBER	MATL CODE	
1	VOLUTE CASING	6722	10010	1		WEAR PLATE	7209-A	10010	1
	IMPELLER	6721-A	10010	1	40	ROUND HEAD	X-0404	17090	2
	SEAL ASSEMBLY	GS-1250		1	1 .	MACHINE SCREW			
4	HEX HD CAP SCREW ?	B-1212	15991	8	41 🖈	SUCTION FLANGE	1759-G	18000	1
5	HEX NUT	D-12	15991	8	1	GASKET			
6	DISCHARGE FLANGE	1759	10010	1	42	VOLUTE DRAIN PLUG	P-20	11990	1
7☆	DISCHARGE FLANGE GASKET	1759-G	18000	1	1	SHAFT KEY HOWN:	N-0607	15990	1
8	STUD	C-1215	15991	8		STRAINER	S-2279		1
9	HEX NUT	D-12	15991	8		GM 5044 ENGINE	206-E2		1
10	SUCTION FLANGE	1759	10010	1	1	GROUND CABLE ASSY		24040	1
	FLAP VALVE SEAT	7211	10010	1		FUEL LINE ASSEMBLY		24040	1
	FLAP VALVE	7211-G	18000	1		FUEL OUTLET ASSY	10765	24030	1
12.7	SEAT GASKET	7211 3	10000	•		BASE	12312	24000	1
13	FLAP VALVE ASSY	7214		1		FUEL LINE RETURN	12641	24000	1
	FLAP VALVE	7217	19070	1			13351-X	24000	1
	FLAP VALVE WT	7215	24000	1		HOISTING BAIL	14294	24030	1
÷	FLAP VALVE WT	7216	15990	1		FUEL RETURN ASSY		24030	1
	HEX HD CAP SCREW	B-0604	17000	2		TUBE FITTING	S-0634		
		J-06				TERMINAL SLEEVE	S-1023		1
1.4	LOCKWASHER		17000	2		WEATHER CAP	S-1389		1
14	ACCESSORY PLUG	P-04	11990	1		CONNECTOR	S-1447		
15	FILL PLUG ASSEMBLY		10000	1		BATTERY BOX ASSY	GRP40-04		
	VOLUTE GASKET SET	34-G	18000	1		BATT BOX COVER	4896-X	24000	•
	SEAL PLATE	2546	10010	1		CABLE ASSEMBLY	5795-CR	24040	-
18	HEAVY PIPE NIPPLE	THA-0416	15070	1		BATTERY BOX	10478	24000	1
19	PIPE COUPLING	AE-04	11990	1		HEX HD CAP SCREW	B-0604	15991	•
	SEAL GREASE CUP	S-1509		1		HEX HD CAP SCREW	B-0605	15991	1
	SEAL WASHER	37-H	15990	1		HEX HD CAP SCREW	B-0624	15991	2
22☆	INTMD GREASE CUP	S-35		1		HEX NUT	D-06	15991	4
23	INTERMEDIATE	36	10010	1		LOCKWASHER	J-06	15991	4
24☆	BEARING CUP	S-1086		2		FLAT WASHER	K-06	15991	6
25☆	BEARING CONE	S-1087		2		BATTERY	S-0978		2
26☆	BEARING SHIM SET	48261-031		1		FUEL TANK AND	46711-033		
27☆	BEARING CAP	43-X	10010	1		GUARD ASSEMBLY			
28	LOCKWASHER	J-06	15991	2	1	HEX NUT	D-06	15991	4
29	HEX HD CAP SCREW	B-0604	15991	2	İ	LOCKWASHER	J-06	15991	4
30 ☆	IMPELLER SHAFT	45	15010	1		FLAT WASHER	K-06	15991	4
	BEARING CLOSURE	44	10010	1		FUEL TANK	42381-017		1
	SEAL LINER	2205	14080	1		GUARD ASSEMBLY			
1.1	IMPELLER SHIM SET	37-J	17090	; ]	1	FUEL TANK	46711-034		1
34	STUD	C-0809	15991	8		MOUNTING HARDWAR			
35	HEX NUT	D-08	15991	8		MACHINE BOLT	A-1205		4
36	STUD	C-0807	15991	2		MACHINE BOLT	A-1209		2
37	LOCKWASHER	7-0807	15991	2		HEX NUT	D-12		
38	HEX NUT	D-08	15991	2	1				(
J0	HEA NUT	D-06	10331	4		LOCKWASHER OPTIONAL WHEEL KIT	J-12 GRP30-30A GRP30-10A	•	6

Note: This parts list applies to pumps from serial no. 352111.

Above serial numbers do not apply to pumps made in Canada.

CANADIAN SERIAL NO. . . . . . . . . . . . . . . . . AND UP



# SECTIONAL DRAWING




Figure 2. Drive Assembly



# PARTS LIST

ITEM NO.	DRIVE ASSEMBLY PART NAME	PART NUMBER	MATERIAL CODE	NUMBER REQUIRED
1	HEX HEAD CAP SCREW	B-0605	15991	4
2	LOCKWASHER	J-06	15991	4
3	INTERMEDIATE GUARD	42381-031		1
4	INTERMEDIATE	36	10010	• 1
5	HEX HEAD CAP SCREW	B-0605	15991	8
6	LOCKWASHER	J-06	15991	8
7	HEX HEAD CAP SCREW	B-0604	15991	8
8	LOCKWASHER	J-06	15991	8
9	DRIVE PLATE ASSEMBLY	12320	15990	1
10	DRIVE ARM ASSEMBLY	13817-C		1
11	<b>☆</b> IMPELLER SHAFT	45	15010	1
12	<b>☆</b> SHAFT KEY	N-0607	15990	1

<sup>☆</sup>Indicates parts recommended for stock

### **ENGINE SEPARATION**

If it is necessary to separate the pump from the engine, disengage the hex head cap screws (5) securing the intermediate (4) to the engine housing, and separate the assemblies. The pins of the drive plate assembly (9) will disengage from the drive arm assembly (10), and the drive arm assembly will remain on the shaft (11).

It is not necessary to remove the drive plate assembly unless the drive pins are bent or worn and must be replaced. To remove the drive plate assembly, disengage the attaching hex head cap screws (7).

The drive arm and shaft key is a tight press fit on the shaft and the drive bushings are a press fit in the drive arm.

When reassembling the engine and pump end, make certain that the drive arm and drive plate assemblies are mounted in accordance with the dimensions shown in figure 2.

### CAUTION

If the drive assembly is not properly positioned on the shaft, a preload condition can occur and cause premature thrust bearing failure.

Section E. Page 5



### PUMP AND SEAL DISASSEMBLY AND REASSEMBLY

This pump requires little service due to its rugged, minimum-maintenance design. If it becomes necessary to inspect and/or replace the wearing parts, however, follow these instructions, which are keyed to the sectional view (see figure 1) and the accompanying parts list.

### **Pump Disassembly**

Disconnect the power source, making certain that it will remain inoperative while the pump is being serviced, and close all connecting valves. Remove the volute drain plug (42) to drain the pump.

Remove the hex nuts (35) securing the volute casing (1) to the seal plate (17) and the intermediate (23). Separate the assemblies. Inspect the wear plate (39), and replace it if scored or worn.

To loosen the impeller (2), tap the vanes in the direction of pump rotation with a block of wood or a soft-faced mallet or hammer. Unscrew the impeller, and replace it if cracked or badly worn.


Remove the impeller adjusting shims (33). For ease of reassembly, tag and tie the shims, or measure and record their thickness.

### Seal Disassembly

Before removing the seal assembly, turn the cross arm on the seal grease cup (20) clockwise until it rests against the cover (see figure 4). This will prevent the grease in the cup from escaping after the seal is removed.

Carefully remove the seal spring, the shaft sleeve, and the stationary and rotating seal elements, using a stiff wire with a hooked end if necessary. Remove the seal liner (32), which is a press fit.

Clean the seal cavity and shaft with a soft cloth soaked in cleaning solvent.



### Seal Reassembly

The seal is not normally reused because of the high polish on its lapped faces, but if it is necessary to reuse the old seal, wash all metallic parts in cleaning solvent and dry thoroughly.

Inspect the seal components for wear, scoring, grooves, and other damage that might cause leakage. If any components are worn, replace the complete seal; never mix old and new seal parts. Clean and polish the shaft sleeve, or replace it if there are nicks or cuts on the end.

Replace the seal liner if worn or grooved. If the seal liner is replaced, a hole must be drilled in it after installation to permit the flow of lubricant to the seal assembly. Deburr the hole after drilling, and clean the seal liner.

Page 6 Section F






Figure 3. GS-1250 Seal Assembly

### **CAUTION**

This seal is not designed for operation at temperatures above 110°F. Do not use at higher operating temperatures.

Reinstall the shaft sleeve, and install the replacement seal as a complete unit.

Lubricate the packing rings with soft grease or oil when installing the seal, and place a drop of light lubricating oil on the lapped faces. Assemble the seal as shown in figure 3.

### **Pump Reassembly**

Reinstall the impeller adjusting shims and the impeller. A clearance of .020 to .040 inch between the impeller and the seal plate is necessary for maximum pump efficiency. Measure this clearance, and add or subtract impeller shims until it is reached.

Reassemble the volute casing to the intermediate and the seal plate, replacing the volute gasket set (16). A clearance of .010 to .020 inch between the impeller and the wear plate is also recommended for maximum pump efficiency. This clearance can be reached by adding or subtracting gaskets in the volute gasket set until the impeller binds against the wear plate when the shaft is turned by hand. After the impeller binds, add .015 inch of gaskets.

Before starting the pump, clean and reinstall the volute drain plug, and fill the volute with liquid.



### LUBRICATION

### Seal Assembly

Before starting the pump, fill the grease cup through the grease fitting with a good grade of No. 2 pressure gun grease until grease escapes from the relief hole. Turn the grease cup arm counterclockwise until it is at the top of the stem; this will release the spring to apply grease to the seal (see figure 4).

### **Bearings**

When shipped from the factory, the pump contains sufficient grease to lubricate the bearings for approximately 5,000 operating hours. Do not lubricate sooner than required. When required, fill the intermediate housing through the intermediate grease cup (22) with No. 0 pressure gun grease until the cavity is approximately one third full, or just below the shaft.




Figure 4. Automatic Lubricating Grease Cup

# For U.S. and International Warranty Information, Please Visit www.grpumps.com/warranty or call:

U.S.: 419-755-1280 International: +1-419-755-1352

For Canadian Warranty Information, Please Visit www.grcanada.com/warranty or call: 519-631-2870