


**INSTALLATION, OPERATION, PARTS LIST,
AND MAINTENANCE MANUAL**



A C E

March 18, 1980



THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

GORMAN-RUPP OF CANADA LIMITED • ST. THOMAS, ONTARIO, CANADA Printed in U.S.A.

Copyright by the Gorman-Rupp Company



This Installation, Operation, and Maintenance Manual is designed to help you get the best performance and longest life from your Gorman-Rupp pump.

This pump is a 60 Series, semi-enclosed impeller, centrifugal model with straight-in suction without a suction check valve. This pump is suitable for pumping liquids which do not contain large entrained solids. For specific service, consult your Gorman-Rupp distributor or the Gorman-Rupp Company.

If there are any questions regarding the pump which are not covered in this manual or in other literature accompanying the unit, please contact your Gorman-Rupp distributor, or write:

The Gorman-Rupp Company
P.O. Box 1217
Mansfield, Ohio 44901

or

Gorman-Rupp of Canada Limited
70 Burwell Road
St. Thomas, Ontario N5P 3R7

The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:

NOTE

Instructions to aid in installation, operation, or maintenance or which clarify a procedure.

CAUTION

Instructions which must be followed to avoid causing damage to the product or other equipment incidental to the installation. These describe the procedure required and the damage which could result from failure to follow the procedure.

WARNING

Instructions which must be followed to avoid causing injury or death to personnel. These describe the procedure required and the injury which could result from failure to follow the procedure.

TABLE OF CONTENTS

WARNINGS	Section A
INSTALLATION	Section B
OPERATION	Section C
TROUBLESHOOTING	Section D
MAINTENANCE AND REPAIR	Section E
WARRANTY	

WARNINGS

THESE WARNINGS APPLY TO 60 SERIES BASIC PUMPS. GORMAN-RUPP HAS NO CONTROL OVER OR PARTICULAR KNOWLEDGE OF THE POWER SOURCE WHICH WILL BE USED. REFER TO THE MANUAL ACCOMPANYING THE POWER SOURCE BEFORE ATTEMPTING TO START THE POWER SOURCE.

Before attempting to open or service the pump:

1. Familiarize yourself with this manual.
2. Disconnect the power source to ensure that the pump will remain inoperative.
3. Allow the pump to cool if overheated.
4. Vent the pump slowly and cautiously.
5. Close the suction and discharge valves.
6. Check the temperature before opening any covers, plates, or plugs.
7. Drain the pump.

Do not attempt to pump any liquids for which this pump has not been designed.

After the pump has been installed, make certain that the pump and all piping connections are secure before attempting to operate it.

Do not operate the pump without shields and/or guards in place over drive shafts, belts and/or couplings, or other rotating parts. Exposed rotating parts can catch clothing, fingers, or tools, causing severe injury to personnel.

Do not operate the pump against a closed discharge valve for long periods of time. This could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode.



Overheated pumps can cause severe burns and injury. If overheating of the pump casing occurs:

1. Stop the pump immediately.
2. Allow the pump to cool.
3. Refer to instructions in this manual before restarting the pump.

Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to cool before servicing.

INSTALLATION

Since pump installations vary, this section is intended only to summarize recommended installation practice. If there are any questions concerning a specific installation, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before it was shipped from the factory. Before installation, inspect the pump for damage which may have occurred during shipment.

- a. Check the pump assembly for cracks, dents, damaged threads, and other obvious damage.
- b. Check for and tighten loose bolts, nuts, capscrews, and other attaching hardware. Since gaskets tend to shrink after drying, check for and tighten loose nuts and capscrews securing mating surfaces.
- c. Carefully read all tags, decals, and markings on the pump assembly, and perform all duties indicated. Note the direction of rotation indicated on the pump. Check that the pump shaft rotates in the required direction.

CAUTION

Only operate this pump in the direction indicated by the arrow on the pump body and on the accompanying decal. Otherwise, the impeller could become loosened from the shaft and seriously damage the pump.


- d. Check all lubricant levels and lubricate as necessary. Refer to the MAINTENANCE AND REPAIR section of this manual.

POSITIONING THE PUMP


Mounting

Locate the pump in an accessible place as close as practical to the liquid being pumped. Level mounting is essential for proper operation. It may be necessary to support or shim the pump for level operation.

Lifting



Make sure that hoists and other lifting equipment are of sufficient capacity to safely handle the pump assembly. If chains and cables are used, make certain that they are positioned so that they will not damage the pump, and so that the load will be balanced.



SUCTION AND DISCHARGE PIPING

Materials

Either pipe or hose may be used for suction and discharge lines. Piping materials must be compatible with the liquid being pumped. If hose is used in suction lines, it must be the rigid-wall, reinforced type to prevent collapse under suction. Using piping couplings in suction lines is not recommended.

Line Configuration

Keep suction and discharge lines as straight as possible to minimize friction losses. Make minimum use of elbows and fittings, which substantially increase friction loss. If elbows are necessary, use the long-radius type to minimize friction loss.

Connections to Pump

Before tightening a connecting flange, align it exactly with the pump port. Never pull a pipe line into place by tightening the flange bolts.

Lines near the pump must be independently supported to avoid strain on the pump which could cause excessive vibration, decreased bearing life, and increased shaft and seal wear. If hose-type lines are used, they should have adequate support to secure them when filled with liquid and under pressure.

Gauges

Most pumps are drilled and tapped for installing discharge pressure and vacuum suction gauges. If these gauges are desired for pumps that are not tapped, drill and tap the suction and discharge lines close to the pump before installing the lines.

SUCTION LINES

To avoid air pockets which could affect pump priming, the suction line must be as short and direct as possible. When operation involves a suction lift, the line must always slope upward to the pump from the source of the liquid being pumped; if the line slopes down to the pump at any point along the suction run, air pockets will be created.

Fittings

Suction lines should be the same size as the pump inlet. If reducers are used in suction lines, they should be the eccentric type, and should be installed with the flat part of the reducers uppermost to avoid creating air pockets. Valves are not normally used in suction lines, but if a valve is used, install it with the stem horizontal to avoid air pockets.

Strainers

If a strainer is furnished with the pump, be certain to use it; any entrained solids which pass through a strainer furnished with the pump will also pass through the pump itself.

If a strainer is not furnished with the pump, but is installed by the pump user, make certain that the total area of the openings in the strainer is at least three or four times the cross section of the suction line, and that the openings will not permit passage of solids larger than the solids handling capability of the pump.

Sealing

Since even a slight leak will affect priming, head, and capacity, especially when operating with a high suction lift, all connections in the suction line should be sealed with pipe dope to ensure an airtight seal. In volatile and/or corrosive service, the pipe dope should be compatible with the liquid being pumped.

Suction Lines In Sumps

If a single suction line is installed in a sump, it should be positioned away from the wall of the sump at a distance equal to one and one-half times the diameter of the suction pipe.


If there is a liquid flow from an open pipe into the sump, the flow should be kept away from the suction inlet because the inflow will carry air down into the sump, and air entering the suction line will reduce pump efficiency.

If it is necessary to position inflow close to the suction inlet, install a baffle between the inflow and the suction inlet at a distance one and one-half times the diameter of the suction pipe. The baffle will allow entrained air to escape from the liquid before it is drawn into the suction inlet.

If two suction lines are installed in a single sump, the flow paths may interact, reducing the efficiency of one or both pumps. To avoid this, position the suction inlets so that they are separated by a distance equal to at least three times the diameter of the suction pipe.

Suction Line Positioning

The depth of submergence of the suction line is critical to efficient pump operation. Figure 1 shows recommended minimum submergence vs. velocity.



$$\text{VELOCITY IN FEET PER SEC.} = \frac{\text{QUAN. [G.P.M.] x .321}}{\text{AREA}} \text{ OR } \frac{\text{G.P.M. x .4085}}{D^2}$$

Figure 1. Recommended Minimum Suction Line Submergence Vs. Velocity

DISCHARGE LINES

Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line. Otherwise, a siphoning action causing damage to the pump could result.

Valves

If a throttling valve is desired in the discharge line, use a valve as large as the largest pipe in the line to minimize friction losses. Never install a throttling valve in a suction line.

A check valve in the discharge line is normally recommended, but is not necessary in low discharge head applications.

With high discharge heads, it is recommended that a throttling valve and a check valve be installed in the discharge line to protect the pump from excessive shock pressure and reverse rotation when it is stopped.

ALIGNMENT

Aligning the pump and its power source is critical for trouble-free mechanical operation.

WARNING

When checking alignment, disconnect the power source to ensure that the pump will remain inoperative.

Before checking alignment, tighten the foundation bolts, pump casing and/or pedestal feet, and power source mounting bolts. Make sure that the pump is level.

CAUTION

Adjusting the alignment in one direction may alter the alignment in another direction. Check each procedure after altering alignment.

Coupling-Driven Pumps

When using couplings, the axis of the power source must be aligned to the axis of the pump shaft in both the horizontal and vertical planes. Most couplings require a specific gap or clearance between the driving and the driven shafts. Refer to the coupling manufacturer's service literature.

Align spider insert type couplings by using calipers to measure the dimensions on the circumference of the outer ends of the coupling hub every 90 degrees. The coupling is in alignment when the hub ends are the same distance apart at all points (see figure 2A).

Align non-spider type couplings by using a feeler gauge or taper gauge between the coupling halves every 90 degrees. The coupling is in alignment when the hubs are the same distance apart at all points (see figure 2B).




Figure 2A. Aligning Spider-Type Couplings



Figure 2B. Aligning Non-Spider Type Couplings

Check parallel adjustment by laying a straightedge across both coupling rims at the top, bottom, and side. When the straightedge rests evenly on both halves of the coupling, the coupling is in horizontal parallel alignment. If the coupling is misaligned, use a feeler gauge between the coupling and the straightedge to measure the amount of misalignment.

V-Belt Driven Pumps

When using V-belt drives, the power source and the pump must be parallel. Use a straightedge along the sides of the pulleys to ensure that the pulleys are properly aligned (see figure 2C). In drive systems using two or more belts, make certain that the belts are a matched set; unmatched sets will cause accelerated belt wear.




Figure 2C. Alignment of V-Belt Driven Pumps

Tighten the belts in accordance with the belt manufacturer's instructions. If the belts are too loose, they will slip; if the belts are too tight, there will be excessive power loss and possible bearing failure. Select pulleys that will match the proper speed ratio; overspeeding the pump may damage both pump and power source.

WARNING

Do not operate the pump without a guard over the rotating parts. Exposed rotating parts can catch clothing, fingers, or tools, causing severe injury to personnel.

OPERATION

WARNING

Do not attempt to pump any liquids for which this pump has not been designed.

PRIMING

Install the pump and piping as described in INSTALLATION. Make sure that the piping connections are tight, and that the pump is securely mounted. Check that the pump is properly lubricated (see LUBRICATION in MAINTENANCE AND REPAIR).

This pump should never be operated unless there is liquid in the volute.

CAUTION

Never operate this pump unless the volute is filled with liquid. The pump will not prime when dry. Extended operation of a dry pump will destroy the seal assembly.

Add liquid to the volute housing:

1. When the pump is being put into service for the first time.
2. When the pump has not been used for a considerable length of time.
3. When the liquid in the volute housing has evaporated.

WARNING

After filling the volute housing, do not attempt to operate the pump unless all connecting piping is securely installed. Otherwise, liquid in the pump forced out under pressure could cause injury to personnel.



STARTING

Rotation

The correct direction of pump rotation is indicated by an arrow on the pump body, and on the accompanying decal. If the pump is operated in the wrong direction, the impeller could become loosened from the shaft and seriously damage the pump.

CAUTION

Only operate this pump in the direction indicated by the arrow on the pump body and on the accompanying decal. Otherwise, the impeller could become loosened from the shaft and seriously damage the pump.

Consult the operating manual furnished with the power source before attempting to start the power source.

If a three-phase electric motor is being used, check rotation by starting the pump for a moment to see if the rotation is correct. If the shaft, coupling, or V-belt is not visible, rotation can usually be determined by observing the motor cooling fan. If the rotation is incorrect, have qualified personnel interchange any two of the three-phase wires to change direction.

Leakage

No leakage should be visible at pump mating surfaces, or at pump connections or fittings. Keep all line connections and fittings tight to maintain maximum pump efficiency.

Overheating

Overheating can occur if the valves in the suction or discharge lines are closed. Operating against closed valves could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode. If overheating occurs, stop the pump and allow it to cool before servicing it. Refill the volute casing with cool liquid.

WARNING

Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to cool before servicing.

Strainer Check

If a suction strainer has been shipped with the pump or installed by the user, check the strainer regularly, and clean it as necessary. The strainer should also be checked if pump flow rate begins to drop.

Pump Vacuum Check

Since this pump does not have a suction check valve, the discharge line must be fitted with a check valve if a pump vacuum reading is to be taken.

With the pump inoperative, install a vacuum gauge in the system, using pipe dope on the threads. Block the suction line and start the pump. At operating speed the pump should pull a vacuum of 20 inches or more of mercury. If it does not, check for air leaks in the seal or gasket.

Open the suction line, and read the vacuum gauge with the pump primed and at operating speed. Shut off the pump, and read the gauge again to determine if the vacuum remains at the maximum developed by the pump. If the vacuum falls off rapidly, an air leak exists; check to make certain that the air leak is not from the vacuum gauge connection.

Stopping

After stopping the pump, disconnect the power source to ensure that the pump will remain inoperative.

In below freezing conditions, drain the pump to prevent damage from freezing. Also, clean out any solids by flushing with a hose. Operate the pump for approximately one minute; this will remove any remaining liquid that could freeze the pump rotating parts.

If the pump will be idle for more than a few hours, or if it has been pumping liquids containing a large amount of solids, drain the pump, and flush it thoroughly with clean water. To prevent large solids from clogging the drain port and preventing the pump from completely draining, operate the pump during the draining process. Clean out any remaining solids by flushing with a hose.

BEARING TEMPERATURE CHECK

Bearings normally run at higher than ambient temperatures because of heat generated by friction. Temperatures up to 160°F are considered normal for pedestal bearings, and they can operate safely to at least 180°F.

Checking bearing temperatures by hand is inaccurate. Bearing temperatures can be measured accurately by placing a contact-type thermometer against the housing. Record this temperature for future reference.

A sudden increase in bearing temperatures is a warning that the bearings are at the point of failing to operate properly. Make certain that the bearing lubricant is of the proper viscosity and at the correct level (see LUBRICATION in MAINTENANCE AND REPAIR). Bearing overheating can also be caused by shaft misalignment and/or excessive vibration.

When pumps are first started, the bearings may seem to run at temperatures above normal. Continued operation should bring the temperatures down to normal levels.



TROUBLESHOOTING

WARNING

Before attempting to open or service the pump:


1. Consult pump service manual.
2. Disconnect the power source to ensure that the pump will remain inoperative.
3. Allow pump to cool if overheated.
4. Close suction and discharge valves.
5. Drain pump.

Trouble	Possible Cause	Probable Remedy
<p>PUMP FAILS TO PRIME</p>	<p>Air leak in suction line.</p> <p>Lining of suction hose collapsed.</p> <p>Leaking or worn seal or pump gasket.</p> <p>Suction lift or discharge head too high.</p> <p>Strainer clogged.</p>	<p>Correct leak.</p> <p>Replace suction hose.</p> <p>Check pump vacuum. Replace leaking or worn seal or gasket.</p> <p>Check piping installation and install bypass line if needed. See INSTALLATION.</p> <p>Check strainer and clean if necessary.</p>
<p>PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE</p>	<p>Air leak in suction line.</p> <p>Suction intake not submerged at proper level or sump too small.</p> <p>Lining of suction hose collapsed.</p> <p>Impeller or other wearing parts worn or damaged.</p> <p>Impeller clogged.</p> <p>Pump speed too slow.</p> <p>Discharge head too high.</p> <p>Suction lift too high.</p> <p>Strainer clogged.</p>	<p>Correct leak.</p> <p>Check installation and correct as needed. Check submergence chart (Section B, page 4).</p> <p>Replace suction hose.</p> <p>Replace worn or damaged parts. Check that impeller is properly centered and rotates freely.</p> <p>Free impeller of debris.</p> <p>Check driver output; check belts or couplings for slippage.</p> <p>Install bypass line.</p> <p>Reduce suction lift.</p> <p>Check strainer and clean if necessary.</p>

Trouble	Possible Cause	Probable Remedy
PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE (cont)	Leaking or worn seal or pump gaskets.	Check pump vacuum. Replace leaking or worn seal or pump gaskets.
PUMP REQUIRES TOO MUCH POWER	Pump speed too high. Discharge head too low. Liquid solution too thick.	Check driver output; check that sheaves or couplings are correctly sized. Adjust discharge valve. Dilute if possible.
PUMP CLOGS FREQUENTLY	Discharge flow too slow.	Open discharge valve fully to increase flow rate, and run engine at maximum governed speed.
EXCESSIVE NOISE	Cavitation in pump. Pumping entrained air. Pump or drive not securely mounted. Impeller clogged or damaged.	Reduce suction lift and/or friction losses in suction line. Locate and eliminate source of air bubble. Secure mounting hardware. Clean out debris; replace damaged parts.
BEARINGS RUN TOO HOT	Bearing temperature is high, but within limits. Low or incorrect lubricant. Suction and discharge lines not properly supported. Drive misaligned.	Check bearing temperature frequently to monitor any increase. Check for proper type and level of lubricant. Check piping installation for proper support. Align drive properly.

Centrifugal Pump

Model 612B20-B



The only moving parts of this pump are the impeller, seal rotating elements, and the shaft. The wear plate, impeller, and seal, which receive the most wear, are easily accessible. Maintenance and replacement of these parts will maintain the peak operating efficiency of the pump.

SECTIONAL DRAWING




Figure 1. Pump Model 612B20-B



PARTS LIST

PUMP MODEL 612B20-B

(From S/N 744852 up)

Above Serial Numbers Do Not Apply To Pumps Made In Canada.

ITEM NO.	PART NAME	PART NUMBER	MATL CODE	QTY	ITEM NO.	PART NAME	PART NUMBER	MATL CODE	QTY
1	VOLUTE CASING	38222-702	—	1	39	LOCKWASHER	J-12	15991	12
2	★IMPELLER	38615-702	—	1	40	★SEAL PLATE	38272-702	—	1
3	★SEAL ASSEMBLY	46512-063	—	1	41	★SEAL PLATE O-RING	25152-283	—	1
4	HEX HEAD CAPSCREW	B-0610	15991	2	42	VOLUTE DRAIN PLUG	P-24	11990	1
5	VENTED PLUG	4823	11990	1	43	★WEAR PLATE O-RING	25152-283	—	1
6	EYE BOLT	NOT FURNISHED			44	PEDESTAL FOOT	38151-002	—	1
7	★SLINGER RING	31134-047	—	1	45	STUD	C-1215	15991	4
8	★BALL BEARING	23275-018	—	1	46	LOCKWASHER	J-12	15991	4
9	PEDESTAL	38251-507	—	1	47	HEX NUT	D-12	15991	4
10	★PEDESTAL AIR VENT	S-01703	—	1	48	STUD	C-0814	15991	4
11	★BEARING HOUSING O-RING	25152-266	—	1	49	LOCKWASHER	J-08	15991	4
12	★BEARING SHIM SET	48261-030	—	16	50	HEX NUT	D-08	15991	4
13	BEARING HOUSING	38331-603	—	1	51	★WEAR PLATE O-RING	25152-278	—	1
14	HEX HEAD CAPSCREW	B-0808	15991	8	52	SUCTION HEAD	38246-610	—	1
15	LOCKWASHER	J-08	15991	8	53	IMPELLER WASHER	31167-012	—	1
16	HEX HEAD CAPSCREW	B-0605	15991	6	54	IMPELLER CAPSCREW	BD-1206	15990	1
17	LOCKWASHER	J-06	15991	6	55	★IMPELLER KEY	N-1012	15990	1
18	BEARING HOUSING CAP	38322-416	—	1	56	ROLL PIN	S-2197	—	1
19	★CAP GSKT SET (not shown)	48211-041	—	1	57	WEAR PLATE ADJ SCREW	31871-040	—	4
20	BEARING LOCKNUT	23962-018	—	1	58	JAM NUT	AT-08	15991	4
21	BEARING LOCKWASHER	23962-518	—	1	59	WEAR PLATE	38691-851	—	1
22	★OIL SEAL	25258-880	—	1	60	HEX HEAD CAPSCREW	B-1209	15991	8
23	★SHAFT KEY	N-1216	15990	1	61	LOCKWASHER	J-12	15991	8
24	★IMPELLER SHAFT	38512-514	—	1	62	NAME PLATE	2613-D	13990	1
25	★BALL BEARING	23413-418	—	2	63	DRIVE SCREW	BM#04-03	15990	4
26	PEDESTAL DRAIN PLUG	P-12	11990	1	64	PIPE PLUG	P-08	11990	2
27	★OIL SEAL	25227-931	—	1	65	OIL CUP	S-0617	—	1
28	PIPE PLUG	P-02	11990	1	66	PIPE NIPPLE	T-0408	15070	1
29	HEX HEAD CAPSCREW	B-1211	15991	4	67	BOTTLE OILER	26713-025	—	1
30	LOCKWASHER	J-12	15991	4	68	GROOVED PIN	21142-268	—	1
31	HEX HEAD CAPSCREW	B-1212	15991	4	69	SPRING CENT WASHER	31512-025	—	1
32	LOCKWASHER	J-12	15991	4	70	★SHAFT SLEEVE	31572-002	17200	1
33	HEX NUT	D-12	15991	4		NOT SHOWN:			
34	★OIL SEAL	25258-910	—	1		STRAINER	4990-A	—	1
35	PEDESTAL FOOT	38151-002	—	1		OPTIONAL:			
36	INTERMEDIATE	38264-701	—	1		SUCTION FLANGE	4991-A	10010	1
37	PIPE PLUG	P-04	11990	1		SUCTION FLANGE GSKT	4991-G	18000	1
38	HEX HEAD CAPSCREW	B-1210	15991	12					

★ INDICATES PARTS RECOMMENDED FOR STOCK

CANADIAN SERIAL NO.....AND UP

PUMP AND SEAL DISASSEMBLY AND REASSEMBLY

This pump requires little service due to its rugged, minimum-maintenance design. If it becomes necessary to inspect and/or replace the wearing parts, however, follow these instructions, which are keyed to the sectional view (see figure 1) and the accompanying parts list.

Pump Disassembly

WARNING

Before attempting to open or service the pump:

1. Familiarize yourself with this manual.
2. Disconnect the power source to ensure that the pump will remain inoperative.
3. Allow the pump to cool if overheated.
4. Vent the pump slowly and cautiously.
5. Close the suction and discharge valves.
6. Check the temperature before opening any covers, plates, or plugs.
7. Drain the pump.

Close all connecting valves, and remove the volute housing drain plug (42) to drain the pump. Clean and reinstall the plug after the pump has been drained.

For access to the impeller (2), disengage the hex head capscrews (38) securing the volute casing (1) and intermediate (36), and separate the units.

Block the impeller, and disengage the socket head capscrew (54). Remove the impeller washer (53) from the roll pin (56), and slide the impeller off the shaft (24), retaining the impeller key (55). Use caution when sliding the impeller off the shaft; tension on the seal spring will be released as the impeller is removed.

Seal Disassembly

Remove the lower seal cavity plug (37) to drain the seal cavity. Clean and reinstall the plug.

Remove the spring centering washer (69) and the seal spring. Using a stiff wire with a hooked end if necessary, remove the remainder of the seal components and the shaft sleeve (70).

Bearing Disassembly


Remove the pedestal body drain plug (26) to drain the pedestal body. Clean and reinstall the plug.

Disengage the hex head capscrews (29), securing the pedestal body to the intermediate, and separate the units. Remove the slinger ring (7).

Disengage the hex head capscrews (14) securing the bearing housing (13) to the pedestal body, and remove the bearing housing, bearing housing shims (12), impeller shaft, and bearings from the pedestal body. Tie the bearing housing shims. Disengage the hex head capscrews (16) securing the bearing cap (18) to the bearing housing, and remove the bearing cap, oil seal (22), and bearing cap gasket set (19).

Remove the inboard bearing (8) from the shaft, and remove the outboard bearing housing. Disengage the tabs of the lockwasher (21) from the locknut (20), and disengage the locknut from the shaft. Remove the outboard bearings.

Clean the seal cavity, the impeller shaft, and the I.D. of the bearings with a soft cloth soaked in cleaning solvent.



Bearing Reassembly

If a Thermo Bearing Mounter is available, use it to heat the inner races of the outboard bearings to 300°F for a minimum of 6 minutes. If a Thermo Bearing Mounter is not available, use a heat lamp or other suitable device to heat the inner races.

Mount the heated outboard bearings on the impeller shaft, making certain that they are installed with the loading opening sides facing each other and the ball contact angles converging toward the center (see figure 2).




Figure 2. Correct Bearing Mounting

Also make certain that the inner bearing is seated squarely against the shaft shoulder, and that the inner races of the bearings are totally bottomed against each other.

While the bearings are still hot, promptly install the bearing lockwasher and locknut. Tighten the locknut, and bend the tabs of the lockwasher over the locknut.

Make certain that there are no burrs or dirt on the interior surfaces of the bearing housing, and use a heat lamp or other suitable device to heat the bearing housing to 300°F for a minimum of 10 minutes. Slip the cooled shaft and mounted outboard bearings into the heated bearing housing, making certain that the bearings are squarely seated against the step of the housing.

Inspect the bearing cap oil seal and replace it if worn. Install the oil seal in the bearing cap with the lip of the seal toward the bearings as shown in figure 1.

Position the bearing cap on the bearing housing, engage the hex head capscrews, and secure the bearing cap to the bearing housing. Use a feeler gauge to measure the gap between the outboard surface of the bearing housing and the inboard surface of the bearing cap. (This gap can also be measured by positioning pieces of solder wire between the two surfaces before the capscrews are fully tightened; tighten the screws, back them off, and measure the thickness of the crushed solder wire.) Add .002 inch to the measurement taken, remove the bearing cap, and add a corresponding thickness of bearing cap gaskets (19) between the bearing cap and the bearing housing. Since the bearing cap must clamp the outer ring of the outboard bearing to preload the bearings, measurement of the gap and installation of the correct thickness of bearing cap gaskets is critical.

Install the bearing cap gaskets, lockwashers (17) and hex head capscrews, and secure the bearing cap to the bearing housing. Recommended shaft end play is .002 inch; add or remove bearing shims (12) to adjust end play.

Use a Thermo Bearing Mounter, heat lamp, or other suitable device to heat the inner race of the inboard bearing to 300°F for a minimum of 6 minutes. Mount the bearing on the shaft, making certain that it seats squarely against the shaft shoulder.

Replace the bearing housing O-ring (11). Reinstall the bearing housing shims, and position the shaft, assembled bearings, and bearing housing in the pedestal body. Reinstall the lockwashers (15) and hex head capscrews, and secure the bearing housing to the pedestal body.

Inspect the pedestal body oil seal (27) and replace it if worn. Install the oil seal in the pedestal body with the lip of the seal toward the bearing as shown in figure 1. Install the slinger ring on the shaft. Secure the pedestal body to the intermediate.

Seal Reassembly

The seal is not normally reused because of the high polish on its lapped faces, but if it is necessary to reuse the old seal, wash all metallic parts in cleaning solvent and dry thoroughly.

Inspect the seal components for wear, scoring, grooves, and other damage that might cause leakage. If any components are worn, replace the complete seal; never mix old and new seal parts.

CAUTION

This seal is not designed for operation at temperatures above 160°F. Do not use at higher operating temperatures.

See figure 3 for the correct order of installation of seal components.




Figure 3. 46512-063 Seal Assembly

Clean and polish the shaft sleeve, or replace it if there are nicks or cuts on the end. Replace the shaft sleeve O-ring; lubricate the O-ring with soft grease or oil and install it on the impeller shaft. Install the shaft sleeve with the chamfered end facing the O-ring.

Lubricate the stationary seat O-rings with soft grease or oil, install them in the stationary seat, and install the stationary seat on the shaft sleeve, making certain that the lip of the stationary seat seats squarely on the shoulder of the seal plate. Install the groove pin (68). Place a drop of light lubricating oil on the lapped faces of the seal, and install the stationary and rotating elements. Lubricate the bellows with soft grease or oil, and install the bellows assembly. Install the seal spring and the spring centering washer.

Pump Reassembly

Inspect the impeller, and replace it if cracked or badly worn. Make certain that the seal components are seated squarely on the shaft sleeve, reinstall the impeller key, and slip the impeller on the shaft. Reinstall the roll pin and the impeller washer. Block the impeller, and reinstall and tighten the impeller socket head capscrew.

For maximum pump efficiency, there should be a clearance of .015 inch between the impeller and the seal plate. Measure this clearance, and adjust it by adding or removing bearing housing shims.



Inspect the adjustable wear plate (59), and replace it if worn or grooved. To remove the wear plate, disengage the hex nuts (50) securing it to the suction head (52). If the wear plate is removed or replaced, replace the O-rings (43 and 51) before securing it to the suction head.

Replace the seal plate O-ring (41), and reassemble the intermediate and the volute casing.

For maximum pump efficiency, there should be a clearance of .015 inch between the impeller and the wear plate. To arrive at this clearance, loosen the hex nuts securing the wear plate to the suction head. Back off the jam nuts (58) to the heads of the adjusting screws (57), and tighten the adjusting screws evenly no more than a half turn at a time while rotating the impeller shaft by hand. When the wear plate makes contact with the impeller at all points, back off each of the adjusting screws a half turn, and tighten the jam nuts until they are snug against the suction head. Tighten the hex nuts securing the wear plate to the suction head. The impeller clearance should now be correct.

Add clean liquid to the volute, make certain that all piping is securely tightened, and open all connecting valves before starting the pump.

LUBRICATION

Seal Assembly

Fill the seal cavity through the oil cup (65) with a good grade of SAE 30 non-detergent motor oil.

Bearings

Remove the pedestal body air vent (10), and fill the pedestal body through the bottle oiler (67) with a good grade of SAE 30 non-detergent motor oil. Do not fill beyond the level of the oil cup pipe nipple (66). Clean and reinstall the air vent.

Check the oil level regularly. In normal service, drain and fill the pedestal body with clean oil yearly.

**For U.S. and International Warranty Information,
Please Visit www.grpumps.com/warranty
or call:
U.S.: 419-755-1280
International: +1-419-755-1352**

**For Canadian Warranty Information,
Please Visit www.grcanada.com/warranty
or call:
519-631-2870**