
INSTALLATION, OPERATION, PARTS LIST, AND MAINTENANCE MANUAL

GORMAN-RUPP
OM-01398-0E01

ACEG

January 22, 1981



THE GORMAN-RUPP COMPANY · MANSFIELD, OHIO

GORMAN-RUPP OF CANADA LIMITED • ST. THOMAS, ONTARIO, CANADA Printed in U.S.A.



This Installation, Operation, and Maintenance Manual is designed specifically to help you get the best performance and longest life from your Gorman-Rupp pump.

This pump is a 60 Series, enclosed impeller, centrifugal model designed for straight-in suction where the medium being pumped enters directly to the impeller eye.

If there are any questions regarding the pump which are not covered in this manual or in other literature accompanying the unit, please contact your Gorman-Rupp distributor, or write:

The Gorman-Rupp Company P.O. Box 1217 Mansfield, Ohio 44902 Gorman-Rupp of Canada Limited 70 Burwell Road

St. Thomas, Ontario N5P 3R7

For information or technical assistance on the power source, contact the power source manufacturer's local dealer or representative.

The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:

NOTE

Instructions to aid in installation, operation, or maintenance or which clarify a procedure.

CAUTION

Instructions which must be followed to avoid causing damage to the product or other equipment incidental to the installation. These describe the procedure required and the damage which could result from failure to follow the procedure.

WARNING

Instructions which must be followed to avoid causing injury or death to personnel. These describe the procedure required and the injury which could result from failure to follow the procedure.

TABLE OF CONTENTS

WARNINGS Section A
INSTALLATION Section B
OPERATION Section C
TROUBLESHOOTING Section D
MAINTENANCE AND REPAIR Section E
WARRANTY




WARNINGS

THESE WARNINGS APPLY TO ENGINE DRIVEN PUMPS. REFER TO THE MANUAL ACCOMPANYING THE ENGINE BEFORE ATTEMPTING TO START THE ENGINE.

Before attempting to open or service the pump: 1. Familiarize yourself with this manual. 2. Remove or ground the spark plug to ensure that the pump will remain inoperative. 3. Drain the pump. This pump has not been designed to pump volatile or corrosive materials. Do not operate the pump against a closed discharge nozzle for long periods of time. This could bring the liquid to a boil, build pressure, and cause the pump to rupture. Do not operate an internal combustion engine in an explosive atmosphere. When operating internal combustion engines in an enclosed area, make certain that exhaust fumes are piped to the outside. These fumes contain carbon monoxide, a deadly gas that is colorless, tasteless, and odorless.

Section A. Page 1







INSTALLATION

Seldom are two pump installations identical. The information presented in this section is a summary of the recommended installation practices related to inspection, pump positioning, hardware, suction and discharge piping, and sumps. For further assistance, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before it was shipped from the factory. Before installation, inspect the pump for damage which may have occurred during shipment. Check as follows:

- a. Inspect the pump assembly for cracks, dents, damaged threads, and other obvious damage.
- b. Check for and tighten loose bolts, nuts, capscrews, and other attaching hardware. Since gaskets tend to shrink after drying, check for and tighten loose nuts and capscrews securing mating surfaces.
- c. Carefully read all tags, decals, and markings on the pump assembly, and perform all duties indicated. Note the direction of rotation indicated on the pump.
- d. Check engine lubricant levels, and lubricate the engine according to the engine manufacturer's recommendations.

POSITIONING THE PUMP

Mounting

Locate the pump in an accessible place as close as practical to the liquid to be pumped. Level mounting is essential for proper operation. The pump may have to be supported to provide for level operation or to eliminate vibration.

SUCTION AND DISCHARGE PIPING

Materials

Either pipe or hose may be used for suction and discharge lines, but hose used in suction lines must be the rigid-wall, reinforced type to prevent collapse under suction. Using pipe couplings in suction lines is not recommended.

Line Configuration

Keep suction and discharge lines as straight as possible to minimize friction losses. Make minimum use of elbows and fittings, which substantially increase friction loss. If elbows are necessary, use the long-radius type to minimize friction loss.

Gauges

Most pumps are drilled and tapped for installing discharge pressure and vacuum suction gauges. If these gauges are desired for pumps that are not tapped, drill and tap the suction and discharge lines close to the pump before installing the lines.

Section B. Page 1



SUCTION LINES

To avoid air pockets which could affect pump priming, the suction line must be as short and direct as possible. When operation involves a suction lift, the line must always slope upward to the pump from the source of the liquid being pumped; if the line slopes down to the pump at any point along the suction run, air pockets will be created.

Fittings

Suction lines should be the same size as the pump inlet. If reducers are used in suction lines, they should be the eccentric type, and should be installed with the flat part of the reducers uppermost to avoid creating air pockets. Valves are not normally used in suction lines, but if a valve is used, install it with the stem horizontal to avoid air pockets.

Strainers

Install a strainer at the end of the suction line to avoid possible clogging or damage to the pump. The total area of the openings in the strainer should be at least three or four times the cross section of the suction line, but no opening should be larger than the solids handling capability of the pump. Clean the strainer regularly during operation.

Sealing

All connections in the suction line should be sealed with pipe dope to ensure an airtight seal. Even a slight leak will affect priming, head, and capacity, especially when operating with a high suction lift. After installation, inspect the suction line carefully for potential leaks.

DISCHARGE LINES

Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line. Otherwise, a siphoning action could result, causing damage to the pump.

Throttling Valves


If a throttling valve is desired, install it in the discharge line. Use a valve as large as the largest pipe in the line to minimize friction losses. Never install a throttling valve in the suction line.

Page 2 Section B.



SUCTION LINE POSITIONING

The depth of submergence of the suction line is critical to efficient pump operation. Figure 1 shows recommended minimum submergence vs. velocity.



VELOCITY IN FEET PER SEC. = $\frac{\text{QUAN. [G.P.M.] x .321}}{\text{AREA}}$ OR $\frac{\text{G.P.M. x .4085}}{\text{D}^2}$

Figure 1. Recommended Minimum Suction Line Submergence Vs. Velocity



OPERATION



PRIMING

Install the pump and piping as described in INSTALLATION, and make sure that the piping connections are tight. Check that the engine is properly lubricated.

To prime the pump, set the exhaust primer valve handle in the closed position, and open the gas cock in the volute housing exhaust primer line.

Start the engine in accordance with the engine manufacturer's instructions.

When there is a continuous discharge of liquid from the exhaust primer venturi, open the exhaust primer valve, and close the gas cock in the volute housing exhaust primer line.

OPERATION

Leakage

No leakage should be visible at pump mating surfaces, or at pump connections or fittings. Keep all line connections and fittings tight to maintain maximum pumping efficiency.

Strainer Check

Check the suction strainer regularly during pump operation, or if the pump flow rate begins to drop.

Pump Vacuum Check

With the pump inoperative, install a vacuum gauge on the suction side of the pump, using pipe dope on the threads. Block the suction line and start the pump. At operating speed the pump should pull a vacuum of 20 inches or more of mercury. If it does not, check for air leaks in the seal or gasket.

Open the suction line, and read the vacuum gauge with the pump primed and at operating speed. Shut off the pump, and read the vacuum gauge again to determine if the vacuum remains at the maximum developed by the pump. If the vacuum falls off rapidly, an air leak exists; check to make certain that the air leak is not from the vacuum gauge connection.

Stopping

After stopping the pump, remove or ground the spark plug to ensure that the pump will remain inoperative.

Page 1 Section C.



In below-freezing conditions, a stopped pump should be drained, and any solids cleaned out by flushing with a hose, to prevent damage from freezing. After draining and flushing, operate the pump for approximately one minute to remove any remaining liquid that could freeze pump rotating parts.

In above-freezing conditions, a pump which has been idle for more than a few hours, or which has been pumping liquids containing solids, should be drained and flushed thoroughly. Operate the pump during the draining process.

Section C. Page 2



TROUBLESHOOTING

WARNING

Before attempting to open or service the pump:

- 1. Consult pump service manual.
- 2. Remove or ground the spark plug to ensure that the pump will remain inoperative.
- 3. Drain pump.

Trouble	Possible Cause	Probable Remedy		
PUMP FAILS TO PRIME	Air leak in suction line.	Correct leak.		
	Lining of suction hose collapsed.	Replace suction hose.		
	Leaking or worn seal or pump gasket.	Check pump vacuum. Replace leaking or worn seal or gasket.		
	Suction lift or discharge head too high.	Check piping installation and install bypass line if needed. See INSTALLATION.		
	Suction strainer clogged.	Clean suction strainer.		
PUMP STOPS OR FAILS TO DE-	Air leak in suction line.	Correct leak.		
LIVER RATED FLOW OR PRESSURE	Suction intake not sub- merged at proper level or sump too small.	Check installation and correct as needed. Check submergence chart (Section B)		
	Lining of suction hose collapsed.	Replace suction hose.		
	Impeller or other wearing parts worn or damaged.	Check impeller clearance. Replace worn parts as needed.		
	Impeller clogged.	Free impeller of debris.		
	Pump speed too slow.	Check engine output.		
	Suction lift too high.	Reduce suction lift.		

Page 1 Section D.




Trouble	Possible Cause	Probable Remedy		
PUMP STOPS OR FAILS TO DE- LIVER RATED FLOW OR PRESSURE (cont)	Leaking or worn seal or pump gaskets.	Check pump vacuum. Replace leaking or worn seal or pump gaskets.		
PUMP REQUIRES TOO MUCH POWER Liquid solution too thick.		Check engine output. Dilute if possible.		
EXCESSIVE NOISE	Cavitation in pump.	Reduce suction lift and/or friction losses in suction line.		
	Pumping entrained air.	Locate and eliminate source of air bubble.		
	Pump or drive not securely mounted.	Secure mounting hardware.		
	Impeller clogged or damaged.	Clean out debris; replace damaged parts.		




Portable Engine Driven Centrifugal Fire-fighter Pump

Model 621/2 A1-23 FF



The only moving parts of this pump are the impeller, seal rotating elements, and the shaft. The wear ring, impeller, and seal, which receive the most wear, are easily accessible and can be replaced without disturbing the piping. Maintenance and replacement of these parts will maintain the peak operating efficiency of the pump.





SECTIONAL DRAWING




Figure 1. Pump Model 62½A1-23 FF

Page 2 Section E.



PARTS LIST

PUMP MODEL 62½A1-23 FF

(From S/N 547860 up)

ITEM NO.	PART NAME	PART NUMBER	MATL	QTY	ITEM NO.	PART NAME	PART NUMBER	MATL	QTY
110.		HOMBEN			140.			CODE	
1	VOLUTE HOUSING	1492	13000	1	38	★ CHECK VALVE GASKET	6323-G	19080	1
2	★IMPELLER	1493-Y	13010	1	39	STUD	C-1008	15991	4
3	★SEAL ASSEMBLY	25271-192	_	1	40	HEX NUT	D-10	15991	4
4	COTTER PIN	M-0406	15990	2	41	PIPE NIPPLE	2434	15070	1
5	SPRING WASHER	S-0165	_	2	42	HOSE CLAMP	S-887	_	1
6	VALVE HANDLE	1458	15990	1	43	PRIMING LINE	2435-E	19170	1
7	PRIMER VALVE CAP	1469	10010	1	44	HOSE CLAMP	S-887	_	1
8	EXHAUST PRIMER VALVE	3643	10010	1	45	PIPE NIPPLE	2434	15070	1
9	MUFFLER	S-337	_	1	46	GAS COCK	S-2	_	1
10	PIPE ELBOW	R-16	11990	1	47	PIPE NIPPLE	T-0606	15070	1
11	STREET ELBOW	AGS-04	11990	1	тои	SHOWN:			
12	PIPE PLUG	P-04	11990	1		B & S 23 ENGINE	201-F1	_	1
13	VENTURI	2345-A	14000	1		STRAINER	2184-A		1
14	EJECTOR BODY	3552	14000	1		COUPLING	2469	14000	2
15	EJECTOR JET	3645-A	14000	1		NAME PLATE	2613-BF	13990	1
16	PIPE NIPPLE	T-08	15070	1		EXHAUST PRIMER TAG	6588-X	00000	1
17	HEX HEAD CAPSCREW	B-0604	15991	1		BASE	5931	24000	1
18	LOCKWASHER	J-06	15991	1		MOUNTING HARDWARE			
19	HEX NUT	D-06	15991	1		HEX HEAD CAPSCREW	B-0606	15991	4
20	PIPE NIPPLE	T-1614	15070	1		HEX NUT	D-06	15991	4
21	PIPE ELBOW	R-16	11990	1		LOCKWASHER	J-06	15991	4
22	PIPE NIPPLE	T-1612	15070	1		FLAT WASHER	K-06	15991	4
23	SUPPORT	6055	15990	1		PRESSURE GAUGE	S-0180	_	1
24	STUD	C-0606	15991	8		EXHAUST PRIME DECAL	6588-AS	00000	1
25	HEX NUT	D-06	15991	8		SPRING WASHER	S-0165	_	1
26	STUD	C-0709	15991	4		CARRY HANDLE ASSY	44724-002	-	4
27	LOCKWASHER	J-07	15991	4		SPRING	6077	16030	4
28	HEX NUT	D-07	15991	4		HANDLE	6078	15070	4
29	*SHAFT SLEEVE	2146	14000	1		POSITION LOCK	11680	12030	4
30	★ SEAL RING	2-A	15020	1		MACHINE BOLT	A-0820	15991	4
31	INTERMEDIATE BRACKET	1495	13000	1		HEX NUT	D-08	15991	4
32	★IMPELLER ADJUST SHIMS	2-X	17090	1		LOCKWASHER	AK-08	15991	4
[*] 33	★ VOLUTE HSNG GSKT SET	3-G	18000	1		JAM NUT	AT-08	15991	4
34	VOLUTE HSNG DRN PLUG	P-04	11990	1	OPT	IONAL:			
35	★WEAR RING	1494	14000	1		2 WHEEL KIT	GRP30-18		1
36	CHECK VALVE BODY	6323	13000	1		FRONT DISCHARGE FLNG	2145	13000	1
37	CHECK VALVE ARM	6324	14000	1					

★INDICATES PARTS RECOMMENDED FOR STOCK Above Serial Numbers Do Not Apply To Pumps Made In Canada.


CANADIAN SERIAL NO. AND UP



PUMP AND SEAL DISASSEMBLY AND REASSEMBLY

This pump requires little service due to its rugged, minimum-maintenance design. If it becomes necessary to inspect or replace components in and adjacent to the rotating assembly, however, follow these instructions, which are keyed to the sectional view (see figure 1) and the accompanying parts list.

Pump Disassembly



Disconnect the power source, making certain that it will remain inoperative while the pump is being serviced, and close all connecting valves.

Remove the volute housing drain plug (34) to drain the pump. Clean and reinstall the plug after the pump has been drained.

For access to the impeller (2) and seal assembly (3), loosen hose clamp (42) securing the priming line (43) to the volute housing (1) and separate the line from the housing. Remove hex nuts (25) securing the volute to the intermediate bracket (31) and separate the assemblies. The impeller is now accessible.

To remove the impeller, immobilize it by inserting a pry bar or other suitable device between the vanes, and loosen the impeller by prying it in the direction of pump rotation. Use caution not to damage the impeller vanes. Use caution when unscrewing the impeller from the shaft; tension on the seal spring will be released as the impeller is removed.

Remove the impeller adjusting shims (32). For ease of reassembly, tag and tie the shims, or measure and record their thickness.

Page 4 Section E.



Seal Disassembly

Remove the seal spring. Using a stiff wire with a hooked end if necessary, remove the remainder of the seal components, the shaft sleeve (29) and the seal ring (30).

Clean the seal cavity and the shaft with a soft cloth soaked in cleaning solvent.



Seal Reassembly

The seal is not normally reused because of the high polish on its lapped faces, but if it is necessary to reuse the old seal, wash all metallic parts in cleaning solvent and dry thoroughly.

Inspect the seal components for wear, scoring, grooves, and other damage that might cause leakage. If any components are worn, replace the complete seal; never mix old and new seal parts.

CAUTION

This seal is not designed for operation at temperatures above 160°F. Do not use at higher operating temperatures.

See figure 2 for the correct order of installation of seal components.

Section E. Page 5




Figure 2. 25271-192 Seal Assembly

Clean and polish the seal ring and shaft sleeve, or replace them if there are nicks or cuts on the end; reinstall the seal ring and shaft sleeve.

Place a drop of light lubricating oil on the lapped faces of the seal, lubricate the stationary seat O-ring with soft grease or oil and install the O-ring in the stationary seat.

Install the stationary seat and the rotating element. Lubricate the bellows with soft grease or oil and install the bellows assembly. Install the seal spring, making certain that all components of the seal are seated squarely.

Pump Reassembly

For maximum pump efficiency, the impeller must be centered in the volute scroll.

Install the impeller adjusting shims. If the same number and thickness of shims are reinstalled as were removed, the impeller should be centered with the volute scroll.

Inspect the impeller, and replace it if cracked or badly worn. Install and block the impeller, and turn the shaft until the impeller is secure.

Inspect the volute housing wear ring (35) and replace it if cracked or badly worn.





Replace the volute housing gasket (33) and reassemble the volute housing and the intermediate, securing the attaching hex nuts.

Turn the shaft to check that the impeller rotates freely. If it does not, add or remove additional shims until the impeller rotates freely when the pump is completely assembled.

Fill the volute — through the pipe nipple — with clean liquid and reconnect the priming line, securing the hose clamp. Make certain that all piping is securely tightened before starting the pump.

LUBRICATION

Seal Assembly

The seal assembly is lubricated by the medium being pumped.

For U.S. and International Warranty Information, Please Visit www.grpumps.com/warranty or call:

U.S.: 419-755-1280 International: +1-419-755-1352

For Canadian Warranty Information,
Please Visit www.grcanada.com/warranty
or call:
519-631-2870