

**INSTALLATION, OPERATION,
AND MAINTENANCE MANUAL**
WITH PARTS LIST



10-SERIES PUMP

MODEL
13A63-B

TABLE OF CONTENTS

INTRODUCTION	I-1
WARNINGS - SECTION A	A-1
INSTALLATION - SECTION B	B-1
Pump Dimensions	B-1
PREINSTALLATION INSPECTION	B-2
POSITIONING PUMP	B-2
Mounting	B-2
Clearance	B-2
Lifting	B-3
SUCTION AND DISCHARGE PIPING	B-3
Materials	B-3
Line Configuration	B-3
Connections to Pump	B-3
Gauges	B-3
SUCTION LINES	B-4
Fittings	B-4
Strainers	B-4
Sealing	B-4
Suction Lines In Sumps	B-4
Suction Line Positioning	B-5
DISCHARGE LINES	B-6
Siphoning	B-6
Valves	B-6
Bypass Lines	B-7
ALIGNMENT	B-7
Coupled Drives	B-8
V-Belt Drives	B-9
OPERATION - SECTION C	C-1
PRIMING	C-1
STARTING	C-2
Rotation	C-2
OPERATION	C-2
Lines With a Bypass	C-2
Lines Without a Bypass	C-3
Leakage	C-3
Overheating	C-3
Strainer Check	C-3
Pump Vacuum Check	C-4
STOPPING	C-4
Cold Weather Preservation	C-4
BEARING TEMPERATURE CHECK	C-4
TROUBLESHOOTING - SECTION D	D-1
MAINTENANCE AND REPAIR - SECTION E	E-1
PERFORMANCE CURVE	E-1
PUMP MODEL - PARTS LIST	E-3
PUMP AND PACKING DISASSEMBLY AND REASSEMBLY	E-4
Suction Check Valve Disassembly	E-4
Pump Disassembly	E-4
Packing Disassembly	E-5
Impeller Shaft And Bearing Disassembly	E-5
Impeller Shaft And Bearing Reassembly	E-6
Packing Reassembly	E-7
Pump Reassembly	E-8
Suction Check Valve Reassembly	E-8
Final Packing Adjustment	E-8
LUBRICATION	E-9
Seal Assembly	E-9
Bearings	E-9

INTRODUCTION

This Installation, Operation, and Maintenance Manual is designed to help you achieve the best performance and longest life from your Gorman-Rupp pump.

This pump is an 10 Series, semi-open impeller, self-priming centrifugal model designed for pumping liquids with specified entrained solids, residues, and materials that can be highly corrosive and abrasive.

If there are any questions regarding the pump which are not covered in this manual or in other literature accompanying this unit, please contact your Gorman-Rupp distributor, or write:

The Gorman-Rupp Company	or	Gorman-Rupp of Canada Limited
P.O. Box 1217		70 Burwell Road
Mansfield, Ohio 44901		St. Thomas, Ontario N5P 3R7

For information or technical assistance on the POWER SOURCE, contact the POWER SOURCE manufacturer's local dealer or representative.

The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:

NOTE

Instructions to aid in installation, operation, and maintenance or which clarify a procedure.

CAUTION

Instructions which must be followed to avoid causing damage to the product or other equipment incidental to the installation. These instructions describe the requirements and the possible damage which could result from failure to follow the procedures.

WARNING

```

////////////////////////////////////
//
// These instructions must be followed to avoid causing in- //
// jury or death to personnel, and describe the procedure //
// required and the injury which could result from failure //
// to follow the procedure. //
// //
////////////////////////////////////

```


WARNINGS - SECTION A

THESE WARNINGS APPLY TO 10 SERIES BASIC PUMPS. GORMAN-RUPP HAS NO CONTROL OVER OR PARTICULAR KNOWLEDGE OF THE POWER SOURCE WHICH WILL BE USED. REFER TO THE MANUAL ACCOMPANYING THE POWER SOURCE BEFORE ATTEMPTING TO START THE POWER SOURCE.

WARNING

Before attempting to open or service the pump:
1. Familiarize yourself with this manual.
2. Disconnect the POWER SOURCE to ensure that the pump will remain inoperative.
3. Allow the pump to cool if overheated.
4. Vent the pump slowly and cautiously.
5. Close the suction and discharge valves.
6. Check the temperature before opening any covers, plates, or plugs.
7. Drain the pump.

WARNING

This pump is designed to pump materials which could cause serious illness or injury through direct exposure or emitted fumes. Wear protective clothing, such as rubber gloves, face mask, and rubber apron, as necessary before disassembling the pump or piping.

WARNING

Do not attempt to pump any liquids for which this pump has not been designed.

WARNING

If this pump is used to pump volatile or corrosive fluids, wear protective safety equipment, such as goggles and rubber gloves and apron, when working on the pump.

WARNINGS

WARNING

```

////////////////////////////////////
//
// After the pump has been installed, make certain that the
// pump and all piping connections are secure before at-
// tempting to operate the pump.
//
////////////////////////////////////

```

WARNING

```

////////////////////////////////////
//
// Do not operate the pump without shields and/or guards in
// place over the drive shafts, belts and/or couplings, or
// other rotating parts. Exposed rotating parts can catch
// clothing, fingers, or tools, causing severe injury to
// personnel.
//
////////////////////////////////////

```

WARNING

```

////////////////////////////////////
//
// Do not operate the pump against a closed discharge valve
// for long periods of time. This could bring the liquid
// to a boil, build pressure, and cause the pump to rupture
// or explode.
//
////////////////////////////////////

```

WARNING

```

////////////////////////////////////
//
// Overheated pumps can cause severe burns and injury. If
// overheating of the pump casing occurs:
//
// 1. Stop the pump immediately.
// 2. Allow the pump to cool.
// 3. Refer to instructions in this manual before re-
// starting the pump.
//
////////////////////////////////////

```

WARNING

```

////////////////////////////////////
//
// Do not remove plates, covers, gauges, pipe plugs, or
// fittings from an overheated pump. Vapor pressure within
// the pump can cause parts being disengaged to be ejected
// with great force. Allow the pump to cool before servic-
// ing.
//
////////////////////////////////////

```


INSTALLATION - SECTION B

Seldom are two pump installations identical. The information presented in this section is a summary of the recommended installation practices related to inspection, pump positioning, hardware, suction and discharge piping, and sumps. For further assistance, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

Pump Dimensions

See Figure 1 for the approximate physical dimensions of this pump.

OUTLINE DRAWING




Figure 1. Pump Model 13A63-B

PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before shipment from the factory. Before installation, inspect the pump for damage which may have occurred during shipment. Check as follows:

- a. Inspect the pump assembly for cracks, dents, damaged threads, and other obvious damage.
- b. Check for and tighten loose bolts, nuts, capscrews, and other attaching hardware. Since gaskets tend to shrink after drying, check for and tighten loose nuts and capscrews securing mating surfaces.
- c. Carefully read all tags, decals, and markings on the pump assembly, and perform all duties indicated. Note the direction of rotation indicated on the pump. Check that the pump shaft rotates in the required direction.

CAUTION

Only operate this pump in the direction indicated by the arrow on the pump body and on the accompanying decal. Otherwise, the impeller could become loosened from the shaft and seriously damage the pump.

- d. Check all lubricant levels and lubricate as necessary. Refer to LUBRICATION in the MAINTENANCE AND REPAIR section of this manual and perform duties as instructed.
- e. If the pump and POWER SOURCE have been stored for more than 12 months, some of the components and lubricants may have exceeded their maximum shelf life. These components **must be inspected or replaced** to insure maximum pump service. Contact the factory or your Gorman-Rupp distributor to determine the specific policy and procedures for updating your pump.

POSITIONING PUMP

Mounting

Locate the pump in an accessible place as close as practical to the liquid being pumped. Level mounting is essential for proper operation. The pump may have to be supported or shimmed to provide for level operation or to eliminate vibration.

Clearance

A minimum clearance of **18 inches** in front of the cover plate is required to permit removal of the cover and easy access to the pump interior.

Lifting

Use lifting equipment with a capacity of a least **1000 pounds**. This pump weighs approximately **225 pounds**, not including the weight of accessories and base.

CAUTION

The pump assembly can be seriously damaged if the cables or chains used to lift and move the unit are improperly wrapped around the pump.

SUCTION AND DISCHARGE PIPING

Materials

Either pipe or hose may be used for suction and discharge lines. Piping materials must be compatible with the liquid being pumped. If hose is used in suction lines, it must be the rigid-wall, reinforced type to prevent collapse under suction. Using piping couplings in suction lines is not recommended.

Line Configuration

Keep suction and discharge lines as straight as possible to minimize friction losses. Make minimum use of elbows and fittings, which substantially increase friction loss. If elbows are necessary, use the long-radius type to minimize friction loss.

Connections to Pump

Before tightening a connecting flange, align it exactly with the pump port. Never pull a pipe line into place by tightening the flange bolts and/or couplings.

Lines near the pump must be independently supported to avoid strain on the pump which could cause excessive vibration, decreased bearing life, and increased shaft and seal wear. If hose-type lines are used, they should have adequate support to secure them when filled with liquid and under pressure.

Gauges

Most pumps are drilled and tapped for installing discharge pressure and vacuum suction gauges. If these gauges are desired for pumps that are not tapped,

drill and tap the suction and discharge lines close to the pump before installing the lines.

SUCTION LINES

To avoid air pockets which could affect pump priming, the suction line must be as short and direct as possible. When operation involves a suction lift, the line must always slope upward to the pump from the source of the liquid being pumped; if the line slopes down to the pump at any point along the suction run, air pockets will be created.

Fittings

Suction lines should be the same size as the pump inlet. If reducers are used in suction lines, they should be the eccentric type, and should be installed with the flat part of the reducers uppermost to avoid creating air pockets. Valves are not normally used in suction lines, but if a valve is used, install it with the stem horizontal to avoid air pockets.

Strainers

If a strainer is furnished with the pump, be certain to use it; any entrained solids which pass through a strainer furnished with the pump will also pass through the pump itself.

If a strainer is not furnished with the pump, but is installed by the pump user, make certain that the total area of the openings in the strainer is at least three or four times the cross section of the suction line, and that the openings will not permit passage of solids larger than the solids handling capability of the pump.

Sealing

Since even a slight leak will affect priming, head, and capacity, especially when operating with a high suction lift, all connections in the suction line should be sealed with pipe dope to ensure an airtight seal. In volatile and/or corrosive service, the pipe dope should be compatible with the liquid being pumped.

Suction Lines In Sumps

If a single suction line is installed in a sump, it should be positioned away from the wall of the sump at a distance equal to one and one-half times the diameter of the suction line.

INSTALLATION

If there is a liquid flow from an open pipe into the sump, the flow should be kept away from the suction inlet because the inflow will carry air down into the sump, and air entering the suction line will reduce pump efficiency.

If it is necessary to position inflow close to the suction inlet, install a baffle between the inflow and the suction inlet at a distance one and one-half times the diameter of the suction pipe. The baffle will allow entrained air to escape from the liquid before it is drawn into the suction inlet.

If two suction lines are installed in a single sump, the flow paths may interact, reducing the efficiency of one or both pumps. To avoid this, position the suction inlets so that they are separated by a distance equal to at least three times the diameter of the suction pipe.

Suction Line Positioning

The depth of submergence of the suction line is critical to efficient pump operation. Figure 2 shows recommended minimum submergence vs. velocity.

NOTE

The pipe submergence required may be reduced by installing a standard pipe increaser fitting at the end of the suction line. The larger opening size will reduce the inlet velocity. Calculate the required submergence using the following formula based on the increased opening size (area or diameter).




Figure 2. Recommended Minimum Suction Line Submergence Vs. Velocity

DISCHARGE LINES

Siphoning

Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line. Otherwise, a siphoning action causing damage to the pump could result.

Valves

If a throttling valve is desired in the discharge line, use a valve as large as the largest pipe in the line to minimize friction losses. Never install a throttling valve in a suction line.

A check valve in the discharge line is normally recommended, but is not necessary in low discharge head applications.

With high discharge heads, it is recommended that a throttling valve and a check valve be installed in the discharge line to protect the pump from excessive shock pressure and reverse rotation when it is stopped.

Bypass Lines

If it is necessary to permit the escape of air to atmosphere during initial priming or in the repriming cycle, install a bypass line between the pump and the discharge check valve. The bypass line should be sized so that it does not affect pump discharge capacity.

It is recommended that a Gorman-Rupp Automatic Air Release Valve be installed in the bypass line. Do not install a manual shut-off valve in a bypass line. If a manual shut-off valve is installed to facilitate service of the Air Release Valve, the valve **must not** be left closed during operation. See the supplement at the end of this section for additional information on bypass lines and the Gorman-Rupp Automatic Air Release Valve.

NOTE

The bypass line may clog occasionally, particularly when pumping liquids containing large solids. If clogging occurs, locate and remove the clog. If the clog is located between the discharge check valve and the Air Release Valve, the valve will not close. If the clog is located in the Relief Valve itself, or in the line between the Relief Valve and the sump, the valve will not open.

Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line; otherwise, a siphoning action could result, causing damage to the pump.

ALIGNMENT

The alignment of the pump and its power source is critical for trouble-free mechanical operation. In either a flexible coupling or V-belt driven system, the driver and pump must be mounted so that their shafts are aligned with and parallel to each other. It is imperative that alignment be checked after the pump is installed, and before operation.

NOTE

Check **Rotation**, Section C, before final alignment of the pump.

When mounted at the Gorman-Rupp factory, driver and pump are aligned before shipment. Misalignment can occur in transit and handling. Pumps should be checked, and realigned if necessary, before being put into operation. Before checking alignment, tighten the foundation bolts. The pump casing feet and/or pedestal feet, and the driver mounting bolts should also be tightly secured.

WARNING

////////////////////////////////////
//
// When checking alignment, disconnect the power source to //
// ensure that the pump will remain inoperative. //
// //
////////////////////////////////////

CAUTION

Adjusting the alignment in one direction may alter the alignment in another direction. Check each procedure after altering alignment.

Coupled Drives

When using couplings, the axis of the power source must be aligned to the axis of the pump shaft in both the horizontal and vertical planes. Most couplings require a specific gap or clearance between the driving and the driven shafts. Refer to the coupling manufacturer's service literature.

Align spider insert type couplings by using calipers to measure the dimensions on the circumference of the outer ends of the coupling hub every 90 degrees. The coupling is in alignment when the hub ends are the same distance apart at all points (see figure 2A).

Align non-spider type couplings by using a feeler gauge or taper gauge between the coupling halves every 90 degrees. The coupling is in alignment when the hubs are the same distance apart at all points (see figure 2B).




Figure 2A. Aligning Spider-Type Couplings



Figure 2B. Aligning Non-Spider Type Couplings

Check parallel adjustment by laying a straightedge across both coupling rims at the top, bottom, and side. When the straightedge rests evenly on both halves of the coupling, the coupling is in horizontal parallel alignment. If the coupling is misaligned, use a feeler gauge between the coupling and the straightedge to measure the amount of misalignment.

V-Belt Drives

When using V-belt drives, the power source and the pump must be parallel. Use a straightedge along the sides of the pulleys to ensure that the pulleys are properly aligned (see figure 2C). In drive systems using two or more belts, make certain that the belts are a matched set; unmatched sets will cause accelerated belt wear.




Figure 2C. Alignment of V-Belt Driven Pumps

Tighten the belts in accordance with the belt manufacturer's instructions. If the belts are too loose, they will slip; if the belts are too tight, there will be excessive power loss and possible bearing failure. Select pulleys that will match the proper speed ratio; overspeeding the pump may damage both pump and power source.

WARNING

```

////////////////////////////////////
//
// Do not operate the pump without a guard over the rotat- //
// ing parts. Exposed rotating parts can catch clothing, //
// fingers, or tools, causing severe injury to personnel. //
//
////////////////////////////////////


```


**GORMAN-RUPP
AUTOMATIC AIR RELEASE VALVE**

Bypass Lines

Self-priming pumps are not air compressors. During the priming cycle, air from the suction line must be vented to atmosphere on the discharge side. If a check valve has been installed in the discharge line, the discharge side of the pump must be opened to atmospheric pressure through a bypass line between the pump discharge and the check valve. A self-priming centrifugal pump **will not prime** if there is sufficient static liquid head to hold the discharge check valve closed.

In low discharge head applications (less than 30 feet), it is recommended that the bypass line be run back to the wet well, and located 6 inches below the water level or cut-off point of the low level pump. The bypass line should be at least 1 inch in diameter to minimize the chance of plugging. The bypass line may be terminated with a six-to-eight foot length of 1 1/4 inch I.D. **smooth-bore** hose; air and liquid will then agitate the hose and break up any substances likely to cause clogging. It is also recommended that pipe unions be installed at each 90° elbow in a bypass line to ease disassembly and maintenance.




A BYPASS LINE THAT IS RETURNED TO A WET WELL MUST BE SECURED AGAINST BEING DRAWN INTO THE PUMP SUCTION INLET.

In high discharge head applications (more than 30 feet), an excessive amount of liquid may be bypassed and forced back to the wet well under the full working pressure of the pump; this will reduce overall pumping efficiency. **Therefore, it is recommended that a Gorman-Rupp Automatic Air Release Valve be installed in the bypass line.**

When properly installed and correctly adjusted to the application, the Gorman-Rupp Automatic Air Release Valve will permit air to escape through the bypass line, and then close automatically when the pump is fully primed and pumping at full capacity.

If the installation involves a flooded suction such as a below-ground lift station, a pipe union and manual shut-off valve may be installed in the bleed line to allow service of the valve without shutting down the station, and to eliminate the possibility of flooding. If a manual shut-off valve is installed **anywhere** in the air release piping, it **must** be a full-opening **ball type** valve to prevent plugging by solids.



IF A MANUAL SHUT-OFF VALVE IS INSTALLED IN A BYPASS LINE, IT MUST NOT BE LEFT CLOSED DURING OPERATION. A CLOSED MANUAL SHUT-OFF VALVE MAY CAUSE A PUMP WHICH HAS LOST PRIME TO CONTINUE TO OPERATE WITHOUT REACHING PRIME, CAUSING DANGEROUS OVERHEATING AND POSSIBLE EXPLOSIVE RUPTURE OF THE PUMP CASING. **PERSONNEL COULD BE SEVERELY INJURED.**

ALLOW AN OVER-HEATED PUMP TO COOL BEFORE SERVICING. DO NOT REMOVE PLATES, COVERS, GAUGES, OR FITTINGS FROM AN OVER-HEATED PUMP. LIQUID WITHIN THE PUMP CAN REACH BOILING TEMPERATURES, AND VAPOR PRESSURE WITHIN THE PUMP CAN CAUSE PARTS BEING DISENGAGED TO BE EJECTED WITH GREAT FORCE. AFTER THE PUMP COOLS, DRAIN THE LIQUID FROM THE PUMP BY REMOVING THE CASING DRAIN PLUG.

Theory of Operation

During the priming cycle, air from the pump casing is discharged through the bypass line, passing through the Air Release Valve (Figure 1). When the pump is fully primed, pressure against the valve diaphragm compresses the spring and closes the valve (Figure 2). The valve will remain closed until the pump loses its prime or stops.

When the pump shuts down, the spring returns the diaphragm to its original position. Any solids that may have accumulated in the diaphragm chamber settle to the bottom and are flushed out during the next priming cycle.

AIR RELEASE VALVE SUPPLEMENT




Figure 1. Valve in Open Position



SOME LEAKAGE (1 TO 5 GPM) WILL OCCUR WHEN THE VALVE IS FULLY CLOSED. BE SURE THE BYPASS LINE IS DIRECTED BACK TO THE WET WELL OR TANK TO PREVENT HAZARDOUS SPILLS.

NOTE

The valve will remain open if the pump does not reach its designed capacity or head. The range of the valve closing pressure is established by the tension rate of the spring as ordered from the factory, and by adjusting the spring retaining pin up or down.




Figure 2. Valve in Closed Position

the plunger rod to increase or decrease spring tension.

Air Release Valve Installation

The Automatic Air Release Valve must be independently mounted in a horizontal position between the pump discharge port and the non-pressurized side of the discharge check valve (see Figure 3). The valve inlet is at the large end of the valve body, and is provided with standard 1 inch NPT pipe threads.

NOTE

If the Air Release Valve is to be installed on a staged pump application, contact the factory for specific installation instructions.




Figure 3. Typical Automatic Air Release Valve Installation

The valve outlet is located at the opposite end of the valve, and is also equipped with standard 1 inch NPT pipe threads. The outlet should be connected to a bleed line which slopes back to the wet well or sump. The bleed line must be the same size as the inlet piping, or larger. If piping is used for the bleed line, avoid the use of elbows whenever possible.

NOTE

It is recommended that each Air Release Valve be fitted with an independent bleeder line. However, if multiple Air Release Valves are installed in a system, the bleeder lines may be directed to a common manifold pipe. Contact the Gorman-Rupp Company for information about your specific application.

OPERATION - SECTION C

WARNING

```

////////////////////////////////////
//
// Do not attempt to pump any liquids for which this pump //
// has not been designed. //
// //
////////////////////////////////////

```

PRIMING

Install the pump and piping as described in INSTALLATION. Make sure that the piping connections are tight, and that the pump is securely mounted. Check that the pump is properly lubricated (see LUBRICATION in MAINTENANCE AND REPAIR).

This pump is self-priming, but the pump should never be operated unless there is liquid in the volute.

CAUTION

<p>Never operate a self-priming pump unless there is liquid in the volute. The pump will not prime when dry. Extended operation of a dry pump will destroy the seal assembly.</p>

Add liquid to the volute casing when:

1. The pump is being put into service for the first time.
2. The pump has not been used for a considerable length of time.
3. The liquid in the volute casing has evaporated.

Once the volute housing has been filled, the pump will prime and reprime as necessary.

WARNING

```

////////////////////////////////////
//
// After filling the volute casing, do not attempt to oper- //
// ate the pump unless all connecting piping is securely //
// installed. Otherwise, liquid in the pump forced out un- //
// der pressure could cause injury to personnel. //
// //
////////////////////////////////////

```

To fill the pump, remove the volute fill cover or fill plug at the top of the casing and add clean liquid until the pump is filled. Replace the fill cover or fill plug before operating the pump.

STARTING

Consult the operations manual furnished with the POWER SOURCE.

Rotation

The correct direction of pump rotation is indicated by an arrow on the pump body and on the accompanying decal. If the pump is operated in the wrong direction, the impeller could become loosened from the shaft and seriously damage the pump.

CAUTION

Only operate this pump in the direction indicated by the arrow on the pump body and on the accompanying decal. Otherwise, the impeller could become loosened from the shaft and seriously damage the pump.

Consult the operating manual furnished with the pump power source before attempting to start the power source.

If an electric motor is being used as a power source, remove V-belts, couplings, or otherwise disconnect the pump from the motor before checking motor rotation. Operate the motor independently, and check rotation. If incorrect, have the motor wiring checked by qualified personnel.

If a three-phase electric motor is being used, check rotation by starting the pump for a moment to see if the rotation is correct. If the shaft, coupling, or V-belt is not visible, rotation can usually be determined by observing the motor cooling fan. If the rotation is incorrect, have qualified personnel interchange any two of the three-phase wires to change direction.

OPERATION

Lines With a Bypass

It is recommended that a Gorman-Rupp Automatic Air Release Valve be installed in the bypass line. **Do not** install a manual shut-off valve in a bypass line. If a manual shut-off valve is installed to facilitate service of the Air Release Valve, the valve **must not** be left closed during operation. See the supplement in Section B for additional information on bypass lines and the Gorman-Rupp Automatic Air Release Valve.

When operating with a Gorman-Rupp Automatic Air Release Valve, close the throttling valve in the discharge line. The Automatic Air Release Valve will automatically open to allow the pump to prime, and automatically close when priming has been accomplished. After the pump has primed and liquid is flowing steadily from the bypass line, open the discharge throttling valve.

Lines Without a Bypass

Open all valves in the discharge line and start the power source. Priming is indicated by a positive reading on the discharge pressure gauge or by a quieter operation. The pump may not prime immediately because the suction line must first fill with liquid. If the pump fails to prime within five minutes, stop it and check the suction line for leaks.

After the pump has been primed, partially close the discharge line throttling valve in order to fill the line slowly and guard against excessive shock pressure which could damage pipe ends, gaskets, sprinkler heads, and any other fixtures connected to the line. When the discharge line is completely filled, adjust the throttling valve to the required flow rate.

Leakage

No leakage should be visible at pump mating surfaces, or at pump connections or fittings. Keep all line connections and fittings tight to maintain maximum pump efficiency.

Overheating

Overheating can occur if the valves in the suction or discharge lines are closed. Operating against closed valves could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode. If overheating occurs, stop the pump and allow it to cool before servicing it. Refill the volute casing with cool liquid.

WARNING

Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to cool before servicing.

Strainer Check

If a suction strainer has been shipped with the pump or installed by the user, check the strainer regularly, and clean it as necessary. The strainer should also be checked if pump flow rate begins to drop.

OPERATION

Pump Vacuum Check

With the pump inoperative, install a vacuum gauge in the system, using pipe dope on the threads. Block the suction line and start the pump. At operating speed the pump should pull a vacuum of 20 inches or more of mercury. If it does not, check for air leaks in the seal, gasket, or discharge valve.

Open the suction line, and read the vacuum gauge with the pump primed and at operation speed. Shut off the pump. The vacuum gauge reading will immediately drop proportionate to static suction lift, and should then stabilize. If the vacuum reading falls off rapidly after stabilization, an air leak exists. Before checking for the source of the leak, check the point of installation of the vacuum gauge.

STOPPING

Never halt the flow of liquid suddenly. If the liquid being pumped is stopped abruptly, damaging shock waves can be transmitted to the pump and piping system. Close all connecting valves slowly.

After stopping the pump, disconnect the power source to ensure that the pump will remain inoperative.

Cold Weather Preservation

In below freezing conditions, drain the pump to prevent damage from freezing. Also, clean out any solids by flushing with a hose. Operate the pump for approximately one minute; this will remove any remaining liquid that could freeze the pump rotating parts.

If the pump will be idle for more than a few hours, or if it has been pumping liquids containing a large amount of solids, drain the pump, and flush it thoroughly with clean water. To prevent large solids from clogging the drain port and preventing the pump from completely draining, insert a rod or stiff wire in the drain port, and agitate the liquid during the draining process. Clean out any remaining solids by flushing with a hose.

BEARING TEMPERATURE CHECK

Bearings normally run at higher than ambient temperatures because of heat generated by friction. Temperatures up to 160°F are considered normal for pedestal bearings, and they can operate safely to at least 180°F.

Checking bearing temperatures by hand is inaccurate. Bearing temperatures can be measured accurately by placing a contact-type thermometer against the housing. Record this temperature for future reference.

A sudden increase in bearing temperatures is a warning that the bearings are at the point of failing to operate properly. Make certain that the bearing lubricant is of the proper viscosity and at the correct level (see LUBRICATION

OPERATION

in MAINTENANCE AND REPAIR). Bearing overheating can also be caused by shaft misalignment and/or excessive vibration.

When pumps are first started, the bearings may seem to run at temperatures above normal. Continued operation should bring the temperatures down to normal levels.

TROUBLESHOOTING - SECTION D

WARNING

```

////////////////////////////////////
//                                                                    //
// Before attempting to open or service the pump:                    //
//                                                                    //
// 1. Familiarize yourself with this manual.                          //
// 2. Disconnect the POWER SOURCE to ensure that the                 //
//    pump will remain inoperative.                                    //
// 3. Allow the pump to cool if overheated.                            //
// 4. Vent the pump slowly and cautiously.                             //
// 5. Close the suction and discharge valves.                          //
// 6. Check the temperature before opening any covers,                //
//    plates, or plugs.                                                //
// 7. Drain the pump.                                                 //
//                                                                    //
////////////////////////////////////
    
```


TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
PUMP FAILS TO PRIME	Air leak in suction line.	Correct leak.
	Lining of suction hose collapsed.	Replace suction hose.
	Suction check valve clogged or binding.	Clean valve.
	Leaking or worn seal or pump gasket.	Check pump vacuum. Replace leaking or worn seal or gasket.
	Suction lift or discharge head too high.	Check piping installation and install bypass line if needed. See INSTALLATION.
	Strainer clogged.	Check strainer and clean if necessary.
PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE	Air leak in suction line.	Correct leak.
	Suction intake not submerged at proper level or sump too small.	Check installation and correct as needed. Check submergence chart (Section B).
	Lining of suction hose collapsed.	Replace suction hose.
	Impeller or other wearing parts worn or damaged.	Replace worn or damaged parts. Check that impeller is properly centered and rotates freely.

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE (cont.)	<p>Impeller clogged.</p> <p>Pump speed too slow.</p> <p>Discharge head too high.</p> <p>Suction lift too high.</p> <p>Leaking or worn seal or pump gasket.</p> <p>Strainer clogged.</p>	<p>Free impeller of debris.</p> <p>Check driver output; check belts or couplings for slippage.</p> <p>Install bypass line.</p> <p>Reduce suction lift.</p> <p>Check pump vacuum. Replace leaking or worn seal or gasket.</p> <p>Check strainer and clean if necessary.</p>
PUMP REQUIRES TOO MUCH POWER	<p>Pump speed too high.</p> <p>Discharge head too low.</p> <p>Liquid solution too thick.</p>	<p>Check driver output; check that sheaves or couplings are correctly sized.</p> <p>Adjust discharge valve.</p> <p>Dilute if possible.</p>
PUMP CLOGS FREQUENTLY	<p>Discharge flow too slow.</p> <p>Suction check valve clogged or binding.</p>	<p>Open discharge valve fully to increase flow rate, and run engine at maximum governed speed.</p> <p>Clean valve.</p>
EXCESSIVE NOISE	<p>Cavitation in pump.</p> <p>Pumping entrained air.</p> <p>Pump or drive not securely mounted.</p> <p>Impeller clogged or damaged.</p>	<p>Reduce suction lift and/or friction losses in suction line.</p> <p>Locate and eliminate source of air bubble.</p> <p>Secure mounting hardware.</p> <p>Clean out debris; replace damaged parts.</p>

TROUBLE	POSSIBLE CAUSE	PROBABLE REMEDY
BEARINGS RUN TOO HOT	Bearing temperature is high, but within limits. Low or incorrect lubricant. Suction and discharge lines not properly supported. Drive misaligned.	Check bearing temperature regularly to monitor any increase. Check for proper type and level of lubricant. Check piping installation for proper support. Align drive properly.

MAINTENANCE AND REPAIR - SECTION E

MAINTENANCE AND REPAIR OF THE WEARING PARTS OF THE PUMP WILL MAINTAIN PEAK OPERATING PERFORMANCE.



*STANDARD PERFORMANCE FOR PUMP MODEL 13A63-B

*Based on 70°F clear water at sea level with minimum suction lift. Since pump installations are seldom identical, your performance may be different due to such factors as viscosity, specific gravity, elevation, temperature, and impeller trim.

If your pump serial number is followed by an "N", your pump is NOT a standard production model. Contact the Gorman-Rupp Company to verify performance or part numbers.

SECTIONAL DRAWING




Figure 1. Pump Model 13A63-B

PARTS LIST
Pump Model 13A63-B
 (From S/N 776101 up)

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify part numbers.

ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY	ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY
1	VOLUTE HOUSING	2985-A	1718H	1	39 *	IMPELLER SHIM SET	2-X	17090	1
2 *	IMPELLER	2996-C	1718H	1	40 *	IMPELLER WASHER	10474	17090	1
3 *	PACKING ASSEMBLY	PP0520 1/2	22100	4	41 *	WEAR PLATE ASSY	2634-C	1718H	1
4 *	DISCH FLANGE GSKT	1674-GC	19370	1	42 *	IMPELLER CAPSCREW	DM0603	17090	1
5	DISCHARGE FLANGE	1753-A	17070	1	43	HEX NUT	D06	17090	2
6	ACCESSORY PLUG	P04	17090	1	44	LOCKWASHER	J06	17090	2
7	HEX HD CAPSCREW	B1007	17090	4	45	VOL HSG DRAIN PLUG	P08	17090	1
8	LOCKWASHER	J10	17090	4	46 *	COVER PLATE ASSY	42111-943	-----	1
9	FILL PLUG ASSEMBLY	48271-098	-----	1	47	-WARNING PLATE	2613-EV	17090	1
10	EYE BOLT	NOT FURNISHED			48	- DRIVE SCREW	BM#04-03	17000	4
11 *	VOLUTE GSKT SET	3-GD	19370	1	49	-COVER PLATE	NOT AVAILABLE		1
12 *	SEAL PLATE	3115-D	1718H	1	50	-DRAIN PLUG	P04	17090	1
13	SEAL PLT PIPE PLUG	P04	17090	1	51	COVER CLAMP	2987	11010	1
14 *	SPLIT PACKING GLAND	3117-A	17070	1	52	COVER CLAMP SCREW	2536	24000	1
15 *	SPLIT GLAND CLIP	3025-A	17000	2	53 *	COVER PLATE GSKT	2985-GA	19370	1
16	STUD	C0606	17090	2	54	NAME PLATE	38818-023	17010	1
17	GLAND NUT	DD06	17090	2	55	DRIVE SCREW	BM#04-03	17000	4
18 *	SLINGER RING	3272	19120	1	56	STUD	C0808	17090	4
19 *	OIL SEAL	25227-311	-----	1	57	HEX NUT	D08	17090	4
20 *	BALL BEARING	23275-008	-----	1	58	FLAP VALVE ASSY	9845-C	-----	1
21 *	LUB AIR VENT	S1703	-----	1	59 *	-FLAP VALVE GSKT	9843-G	19540	1
22	PEDESTAL	3114-B	10010	1	60 *	-VALVE WEIGHT	9843	17190	1
23	ROTATION DECAL	2613-M	-----	1	61 *	-VALVE WEIGHT	9844	17090	1
24 *	BALL BEARING	23275-008	-----	1	62	-RD HD MACH SCREW	X0503	17090	1
25 *	BRG RETAINER O-RING	25152-235	-----	1	63	-LOCKWASHER	J05	17090	1
26 *	BRG RETAINING RING	S247	-----	1	64	PIPE PLUG	P04	17090	1
27 *	OIL SEAL	25227-303	-----	1	65	SUCTION FLANGE	2943	17070	1
28 *	SHAFT KEY	N0407	15990	1	66 *	CHECK VALVE GSKT	9842-G	19370	1
29 *	IMPELLER SHAFT	38514-549	1706H	1	67	CHECK VALVE SEAT	9842	17190	1
30 *	BEARING SHIM SET	48261-009	-----	1	68 *	CHECK VALVE GSKT	9842-G	19370	1
31 *	BEARING RETAINER	38322-521	26000	1	69 *	SETScrew	GA#10-01S	15990	2
32	OIL LEVEL SIGHT GAUGE	26714-011	-----	1	70	PIPE NIPPLE	T0412	15070	1
33	PIPE PLUG	P06	11990	1	71	PIPE COUPLING	AE04	11990	1
34	PEDESTAL DRAIN PLUG	P06	11990	1	72	SUCTION STICKER	6588-AG	-----	1
35	STUD	C0608	17090	8	73	DISCHARGE STICKER	6588-BJ	-----	1
36	HEX NUT	D06	17090	8		OPTIONAL:			
37 *	LANTERN RING	3420-A	19250	1		HI TEMP SHUT-DOWN KITS:			
38 *	SHAFT SLEEVE	5129	17090	1		-145° F	48313-186	-----	1
						-130° F	48313-256	-----	1
						-120° F	48313-257	-----	1

* INDICATES PARTS RECOMMENDED FOR STOCK

Above Serial Numbers Do Not Apply To Pumps Made In Canada.

CANADIAN SERIAL NO. AND UP

PUMP AND PACKING DISASSEMBLY AND REASSEMBLY

This pump requires little service due to its rugged, minimum-maintenance design. If it becomes necessary to inspect and/or replace the wearing parts, however, follow these instructions, which are keyed to the sectional view (see figure 1) and the accompanying parts list.

By removing the back cover plate and power source, all service functions except check valve maintenance can be performed without disconnecting the suction or discharge piping.

Before attempting to service the pump, disconnect the power source, and close all connecting valves.

WARNING

```

////////////////////////////////////
//
// This pump is designed to pump materials which could //
// cause serious illness or injury through direct exposure //
// or emitted fumes. Wear protective clothing, such as //
// rubber gloves, face mask, and rubber apron, as necessary //
// before disassembling the pump or piping. //
// //
////////////////////////////////////

```

Suction Check Valve Disassembly

Remove the suction piping. Remove the hex nuts (57) securing the suction flange (65) to the volute casing (1). Pull the check valve assembly (58) along with gaskets (66 and 68), and valve seat (67) from the suction port opening. Remove the round head machine screw and lockwasher (62 and 63) securing check valve weights (60 and 61) to the check valve gasket (59).

Pump Disassembly

Remove the volute drain plug (45) to drain the pump. For access to the wear plate (41), impeller (2), and packing assembly (3), loosen the cover clamp screw (52) and release the cover clamp bar (51) and remove the cover assemble (46). After removing the cover, inspect the wear plate, and replace it if scored or worn.

Immobilize the impeller by placing a block of wood between the impeller vanes. Remove the socket head capscrew (42) and the impeller washer (40). Turn the drive end of the shaft counterclockwise and unscrew the impeller. Inspect the impeller and replace it if cracked or badly worn.

Remove the impeller adjusting shims (39). For ease of reassembly, tag and tie the shims, or measure and record their thickness.

Packing Disassembly

Packings should be inspected, and replaced if necessary.

Reach through the openings in the pedestal (22) with a wrench, and remove the gland nuts (17) securing the gland clips (15) and split packing gland (14). Carefully slide the packings from the stuffing box, using a stiff wire with a hooked end if necessary, and remove them from the shaft.

Clean the stuffing box and impeller shaft with a soft cloth soaked in cleaning solvent.

WARNING

```

////////////////////////////////////
//
// Most cleaning solvents are toxic and flammable. Use //
// them only in a well-ventilated area free from excessive //
// heat, sparks, and flame. Read and follow all prec- //
// autions printed on solvent containers. //
// //
////////////////////////////////////

```

If no further disassembly is required see **Packing Reassembly**.

Impeller Shaft And Bearing Disassembly

Remove power source and pedestal mounting hardware to provide clearance.

Remove pipe coupling (71), pipe nipple (70), and pipe plug (13) from seal plate (12).

Remove hex nuts (36) and separate volute gasket set (11), seal plate (12), and pedestal (22) from volute casing. Record thickness of gasket set.

Drain bearing lubricant by removing pedestal drain plug (34). Clean and reinstall the drain plug.

Remove the slinger ring (18) and shaft key (28).

Remove the bearing retaining ring (26) and shim set (30). Tie and tag the shim set, or measure and record their thickness.

Remove the setscrews (69) from the bearing retainer (31) and install two machine screws (#10-32 x 1" long).

Pry the bearing retainer from the pedestal bore using a screwdriver against the head of the machine screws. Remove machine screws and reinstall setscrews. Press the oil seal (27) from the bearing retainer.

Remove the bearing retainer O-ring (25).

Place a block of wood against the threaded end of the shaft and drive the shaft and bearings out of the pedestal.

Use a bearing puller to remove the inboard bearing (20) and outboard bearing (24) from the impeller shaft.

Press inboard oil seal (19) from the pedestal.

Impeller Shaft And Bearing Reassembly

Clean the bore of the pedestal, seal plate, shaft sleeve, impeller shaft, and bearing retainer with a cloth soaked in cleaning solvent. Inspect the parts for wear, and replace as necessary.

WARNING

```

////////////////////////////////////
//
// Most cleaning solvents are toxic and flammable. Use //
// them only in a well-ventilated area free from excessive //
// heat, sparks, and flame. Read and follow all prec- //
// autions printed on solvent containers. //
// //
////////////////////////////////////

```

Soak the bearings in cleaning solvent, free of grit or metallic particles. Inspect the bearings, and replace as necessary.

Press the inboard and outboard bearings onto the impeller shaft until they seat squarely against the shaft shoulders.

Install the inboard oil seal in the pedestal with the lip positioned as shown in Figure 1.

Install the outboard oil seal in the bearing retainer with lip positioned as shown in Figure 1.

Press the shaft and assembled bearings into the pedestal bore until the inboard bearing seats squarely against the pedestal shoulder.

Replace the bearing retainer O-ring. Apply a light coat of soft grease on O-ring and O-ring groove.

Install the bearing retainer with the setscrews horizontally in line. Make sure the undercut seats against outer race of bearing and the oil seal lip points inboard.

Install required number of bearing shims.

NOTE

Shaft end play should be between .002 and .010 inch.

Install the bearing retaining ring and check the shaft travel.

Install slinger ring and shaft key.

Secure volute gasket set, seal plate, and pedestal to volute housing. Be sure to use same thickness of gaskets as previously removed.

Install the pedestal mounting hardware and connect power source.

Lubricate the pedestal as indicated in **LUBRICATION**, Section E.

Packing Reassembly

CAUTION

These packings are not designed for operation at temperatures above 212°F. Do not use at higher operating temperatures.

Clean and polish the shaft sleeve, or replace it if there are nicks or cuts on the end. Reinstall the shaft sleeve.




Figure 2. PP00520 1/2 Packing Assembly

Dip new packings in non-detergent SAE No. 30 oil before installation, and install enough packing rings so that the lantern ring will be in line with the pipe nipple mounted at the top of the stuffing box when the packings are compressed. Install the lantern ring, and add enough packings to fill the stuffing box. When installing packing rings, rotate each successive layer by 90 degrees to prevent leakage through the joints (see figure 2).

Install the packing gland and gland clip, draw up the gland nuts evenly until they are snug, then back off the nuts until they are only finger tight. Final packing adjustment should be made after the pump has been reassembled.

Pump Reassembly

Slide the required number of impeller shims onto the shaft and screw the impeller completely on.

A clearance of .020 to .040 inch between the impeller and the seal plate is necessary for maximum pump efficiency. This clearance can be reached by adjusting the impeller shims.

Rotate the shaft by hand, and subtract impeller shims until the impeller binds against the seal plate. After the impeller binds, add .030 inch of impeller shims. Apply a light coat of "Never-Seez" compound on the threads of the impeller capscrew and install the impeller washer. Torque the capscrew to 90 ft. lbs..

A clearance of .010 to .020 inch between the impeller and wear plate is also critical to pump performance. This clearance may be adjusted by adding or subtracting volute casing gaskets.

To measure the clearance, install the back cover assembly and reach through the discharge port with a feeler gauge. If disassembly of the discharge piping is not practical, rotate the shaft by hand and subtract gaskets until the impeller binds against the wear plate. After the impeller binds, add .015 inch of gaskets then reassemble the pump.

Suction Check Valve Reassembly

Clean and inspect all the components of the check valve assembly, replace any parts that is worn or damaged.

Secure the check valve gasket between the valve weights using the round head machine screw. Gasket should sit flush against pivot pin.

Assemble check valve assembly to valve seat using pivot brackets.

Place new flange gasket on each side of valve seat and install the complete assembly into suction port.

Secure suction flange using hex nuts.

Check the operation of the suction check valve to insure proper setting and free movement. Reinstall suction piping.

Before starting the pump, clean and reinstall the volute drain plug and fill the volute with liquid.

Final Packing Adjustment

Start the pump, and tighten the packing gland nuts evenly while the pump is operating. A slight flow of liquid through the packing (approximately 50 drops per minute) must be maintained for lubrication. Do not overtighten the gland nuts and cut off this flow. After the gland has been adjusted, stop the pump. The shaft should rotate by hand; if it does not, the gland is too tight.

If the old packings have been reinstalled, and the flow of medium through the packings cannot be controlled by adjusting the gland, the old packings must be replaced by new ones.

LUBRICATION

Seal Assembly

The packing in the stuffing box is lubricated either by the liquid being pumped, or by the flow of fresh liquid into it from an external source.

When pumping clear liquids, proper lubrication can be achieved by controlling the packing compression (see **Final Packing Adjustment**) to permit a slight flow of liquid through the packings.

When pumping liquids such as mud, slurries, or thick residues, fresh liquid should be piped to a flushing port provided in the seal plate. Be sure liquid supplied to the seal is compatible with liquid being pumped, and that its flow is controlled to prevent dilution.

Bearings

The bearing housing oil level **must be maintained** at the midpoint of the oil level sight gauge. (28).

When oil is required, remove the pedestal air vent (17), and fill the bearing housing with a good grade of non-detergent SAE # 30 motor oil to the midpoint of the oil level sight gauge. Clean and reinstall the pedestal air vent. **Do not overfill**. Overfilling will cause excessive heat resulting in shortened bearing life.

Under normal conditions, change the oil each 5000 hours of operation, or at 12 month intervals, which ever occurs first. In dirty or humid conditions change more frequently.

For cold weather operation, consult factory or lubricant supplier for recommended grade of oil.

**For U.S. and International Warranty Information,
Please Visit www.grpumps.com/warranty
or call:
U.S.: 419-755-1280
International: +1-419-755-1352**

**For Canadian Warranty Information,
Please Visit www.grcanada.com/warranty
or call:
519-631-2870**