

**INSTALLATION, OPERATION,  
AND MAINTENANCE MANUAL**  
WITH PARTS LIST



PA SERIES® PUMP

| MODEL                      |
|----------------------------|
| <b>PA6D60C-B-E50 460/3</b> |

**GORMAN-RUPP PUMPS**

[www.grpumps.com](http://www.grpumps.com)

Register your new  
Gorman-Rupp pump online at  
**www.grpumps.com**

Valid serial number and e-mail address required.

**RECORD YOUR PUMP MODEL AND SERIAL NUMBER**

Please record your pump model and serial number in the spaces provided below. Your Gorman-Rupp distributor needs this information when you require parts or service.

Pump Model: \_\_\_\_\_

Serial Number: \_\_\_\_\_

# TABLE OF CONTENTS

|   |                   |
|---|-------------------|
| <b>INTRODUCTION</b> .....                       | <b>PAGE I – 1</b> |
| <b>SAFETY - SECTION A</b> .....                 | <b>PAGE A – 1</b> |
| <b>INSTALLATION – SECTION B</b> .....           | <b>PAGE B – 1</b> |
| Pump Dimensions .....                           | PAGE B – 1        |
| PREINSTALLATION INSPECTION .....                | PAGE B – 2        |
| POSITIONING PUMP .....                          | PAGE B – 2        |
| Lifting .....                                   | PAGE B – 2        |
| Mounting .....                                  | PAGE B – 2        |
| SUCTION AND DISCHARGE PIPING .....              | PAGE B – 3        |
| Materials .....                                 | PAGE B – 3        |
| Line Configuration .....                        | PAGE B – 3        |
| Connections to Pump .....                       | PAGE B – 3        |
| Gauges .....                                    | PAGE B – 3        |
| SUCTION LINES .....                             | PAGE B – 3        |
| Fittings .....                                  | PAGE B – 3        |
| Strainers .....                                 | PAGE B – 3        |
| Sealing .....                                   | PAGE B – 3        |
| Suction Lines In Sumps .....                    | PAGE B – 3        |
| Suction Line Positioning .....                  | PAGE B – 4        |
| DISCHARGE LINES .....                           | PAGE B – 5        |
| Siphoning .....                                 | PAGE B – 5        |
| Valves .....                                    | PAGE B – 5        |
| ELECTRICAL CONNECTIONS .....                    | PAGE B – 5        |
| Grounding Methods .....                         | PAGE B – 5        |
| Field Wiring Connections (Incoming Power) ..... | PAGE B – 6        |
| Voltage Imbalance .....                         | PAGE B – 6        |
| Power Cable Connections .....                   | PAGE B – 6        |
| ALIGNMENT .....                                 | PAGE B – 7        |
| AUTO-START .....                                | PAGE B – 7        |
| Float Switch Installation .....                 | PAGE B – 7        |
| COLD WEATHER INSTALLATION .....                 | PAGE B – 8        |
| <b>OPERATION – SECTION C</b> .....              | <b>PAGE C – 1</b> |
| STARTING AND OPERATION .....                    | PAGE C – 1        |
| Rotation .....                                  | PAGE C – 1        |
| Control Box Function .....                      | PAGE C – 1        |
| Priming .....                                   | PAGE C – 2        |
| Leakage .....                                   | PAGE C – 2        |
| Pump Vacuum Check .....                         | PAGE C – 2        |
| Priming Chamber Discharge Line .....            | PAGE C – 2        |
| Liquid Temperature And Overheating .....        | PAGE C – 2        |
| Strainer Check .....                            | PAGE C – 2        |
| STOPPING .....                                  | PAGE C – 3        |
| Manual Stopping .....                           | PAGE C – 3        |

**TABLE OF CONTENTS**  
**(continued)**

|  |                   |
|--|-------------------|
| Automatic Stopping .....                                       | PAGE C – 3        |
| PERIODIC CHECKS .....  | PAGE C – 3        |
| Seal Cavity and Bearing Lubrication .....                      | PAGE C – 3        |
| Bearing Temperature Check .....                                | PAGE C – 3        |
| COLD WEATHER PRESERVATION .....                                | PAGE C – 3        |
| <b>TROUBLESHOOTING – SECTION D .....</b>                       | <b>PAGE D – 1</b> |
| PREVENTIVE MAINTENANCE .....                                   | PAGE D – 3        |
| <b>PUMP MAINTENANCE AND REPAIR - SECTION E .....</b>           | <b>PAGE E – 1</b> |
| STANDARD PERFORMANCE CURVE .....                               | PAGE E – 1        |
| PARTS LISTS:   |                   |
| Pump Model .....   | PAGE E – 3        |
| Pump End Assembly .....  | PAGE E – 5        |
| Pump Sub Assembly .....  | PAGE E – 7        |
| Repair Rotating Assembly .....                                 | PAGE E – 9        |
| Priming Chamber Kit .....                                      | PAGE E – 10       |
| Priming Chamber Assembly .....                                 | PAGE E – 11       |
| Air Compressor Assembly .....                                  | PAGE E – 12       |
| PUMP AND SEAL DISASSEMBLY AND REASSEMBLY .....                 | PAGE E – 13       |
| Priming Chamber Removal and Disassembly .....                  | PAGE C – 14       |
| Discharge Check Valve Removal and Disassembly .....            | PAGE C – 14       |
| Suction Spool and Wear Plate Removal .....                     | PAGE C – 14       |
| Draining Oil From Seal Cavity .....                            | PAGE C – 15       |
| Separating Pump End From Power Source .....                    | PAGE C – 15       |
| Loosening Impeller .....                                       | PAGE C – 15       |
| Pump Casing Removal .....                                      | PAGE C – 16       |
| Impeller Removal .....   | PAGE C – 16       |
| Seal Removal .....   | PAGE C – 16       |
| Shaft and Bearing Removal and Disassembly .....                | PAGE C – 16       |
| Shaft and Bearing Reassembly and Installation .....            | PAGE C – 17       |
| Seal Reassembly and Installation .....                         | PAGE C – 18       |
| Impeller Installation And Adjustment .....                     | PAGE C – 20       |
| Pump Casing Installation .....                                 | PAGE C – 20       |
| Securing Pump End To Power Source .....                        | PAGE C – 20       |
| Suction Spool and Wear Plate Installation And Adjustment ..... | PAGE C – 21       |
| Discharge Check Valve Reassembly And Installation .....        | PAGE C – 22       |
| Priming Chamber Assembly And Installation .....                | PAGE C – 22       |
| LUBRICATION .....  | PAGE C – 23       |
| Seal Assembly .....  | PAGE C – 23       |
| Bearings .....   | PAGE C – 23       |

## INTRODUCTION

**Thank You** for purchasing a Gorman-Rupp pump. **Read this manual** carefully to learn how to safely install and operate your pump. Failure to do so could result in personal injury or damage to the pump.

Because pump installations are seldom identical, this manual cannot possibly provide detailed instructions and precautions for every aspect of each specific application. Therefore, it is the responsibility of the owner/installer of the pump to ensure that applications not addressed in this manual are performed **only** after establishing that neither operator safety nor pump integrity are compromised by the installation. Pumps and related equipment **must** be installed and operated according to all national, local and industry standards.

If there are any questions regarding the pump or its application which are not covered in this manual or in other literature accompanying this unit, please contact your Gorman-Rupp distributor, or The Gorman-Rupp Company:

**The Gorman-Rupp Company**  
**P.O. Box 1217**  
**Mansfield, Ohio 44901—1217**  
**Phone: (419) 755—1011**  
 or:  
**Gorman-Rupp of Canada Limited**  
**70 Burwell Road**  
**St. Thomas, Ontario N5P 3R7**  
**Phone: (519) 631—2870**

For information or technical assistance on the power source, contact the power source manufacturer's local dealer or representative.

## HAZARD AND INSTRUCTION DEFINITIONS

The following are used to alert maintenance personnel to procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel:



**Immediate hazards which WILL result in severe personal injury or death. These instructions describe the procedure required and the injury which will result from failure to follow the procedure.**



**Hazards or unsafe practices which COULD result in severe personal injury or death. These instructions describe the procedure required and the injury which could result from failure to follow the procedure.**



Hazards or unsafe practices which COULD result in minor personal injury or product or property damage. These instructions describe the requirements and the possible damage which could result from failure to follow the procedure.

### NOTE

*Instructions to aid in installation, operation, and maintenance or which clarify a procedure.*

## SAFETY - SECTION A

This information applies to Prime Air® Series pumps. Refer to the manual accompanying the power source before attempting to begin operation.

This manual will alert personnel to known procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel. However, this manual cannot possibly anticipate and provide detailed instructions and precautions for every situation that might occur during maintenance of the unit. Therefore, it is the responsibility of the owner/maintenance personnel to ensure that only safe, established maintenance procedures are used, and that any procedures not addressed in this manual are performed only after establishing that neither personal safety nor pump integrity are compromised by such practices.



Before attempting to install, operate, or wire the pump control box, familiarize yourself with this manual, and with all other literature shipped with the control box. Unfamiliarity with all aspects of control operation covered in this manual could lead to destruction of equipment, injury, or death to personnel.



Before connecting any cable to the control box, be sure to ground the control box. See Section B for suggested grounding methods.



The control box provides overload protection and power control. Do not connect the pump motor directly to the incoming power lines. If the power circuit breaker or overload relay is tripped during operation, correct the problem before resetting or replacing.



The electrical power used to operate the pump control box is high enough to cause injury or death. Obtain the services of a qualified electrician to make all electrical connections. Make certain that the enclosure is properly grounded; never use gas pipe as an electrical ground. Be sure that the incoming power matches the voltage and phase of the control before connecting the power source. Do not make electrical connections if the voltage is not within the limits. If the overload unit is tripped during operation, correct the problem before restarting.



The electrical power used to operate the pump control box is high enough to cause injury or death. Make certain that the control handle on the control box is in the OFF position and locked out before attempting to service the pump. Before attempting to open or service the control box, disconnect and/or lock out the power supply to the control box. Tag electrical circuits to prevent accidental start-up.

**WARNING!**

Obtain the services of a qualified electrician to troubleshoot, test and/or service the electrical components of the control box.

**WARNING!**

Before attempting to open or service the pump:

1. Familiarize yourself with this manual.
2. Turn the control box selector switch to 'OFF' and lock it out to ensure that the pump will remain inoperative.
3. Allow the pump to completely cool if overheated.
4. Check the temperature before opening any covers, plates, or plugs.
5. Close the suction and discharge valves.
6. Vent the pump slowly and cautiously.
7. Drain the pump.

**WARNING!**

This pump is equipped with an automatic starting system, and therefore subject to automatic restart. Keep hands and clothing away from the unit to prevent injury during automatic operation. Lock out the power from the control box to ensure that the pump will remain inoperative. Failure to do so may result in serious personal injury.

**WARNING!**

Do not attempt to disengage any part of an overheated pump unit. Vapor pressure within the pump casing can eject

these parts with great force when they are disengaged. Allow the pump to completely cool before servicing it.

**WARNING!**

This pump is designed to handle most non-volatile, non-flammable liquids containing specified entrained solids. Do not attempt to pump volatile, corrosive, or flammable liquids which may damage the pump or endanger personnel as a result of pump failure.

**WARNING!**

Death or serious personal injury and damage to the pump or components can occur if proper lifting procedures are not observed. Make certain that hoists, chains, slings or cables are in good working condition and of sufficient capacity and that they are positioned so that loads will be balanced and the pump or components will not be damaged when lifting. Suction and discharge hoses and piping must be removed from the pump before lifting. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.

**WARNING!**

After the pump has been installed, make certain that the pump and all piping or hose connections are tight, properly supported and secure before operation.

**WARNING!**

Do not operate the pump against a closed discharge valve. If operated against a closed discharge valve, pump components will deteriorate, and the liquid could come to a boil, build pressure, and cause the pump casing to rup-

ture or explode. Momentary closure of a discharge valve is acceptable only when required for startup or shutdown procedures.




Do not remove plates, covers, gauges, pipe plugs, or fittings from an overheated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to cool completely before servicing.




Do not operate the pump without guards

in place over the rotating parts. Exposed rotating parts can catch clothing, fingers or tools, causing severe injury to personnel.



Pumps and related equipment must be installed and operated according to all national, local and industry standards.



Make sure the pump is level. Lower jack stands and chock the wheels, if so equipped.



## INSTALLATION – SECTION B

**Review all SAFETY information in Section A.**

Since pump installations are seldom identical, this section offers only general recommendations and practices required to inspect, position, and arrange the pump and piping.

Most of the information pertains to a standard **static lift** application where the pump is positioned above the free level of liquid to be pumped.

If installed in a **flooded suction application** where the liquid is supplied to the pump under pressure, some of the information such as mounting, line


configuration, and priming must be tailored to the specific application. Since the pressure supplied to the pump is critical to performance and safety, **be sure** to limit the incoming pressure to 50% of the maximum permissible operating pressure as shown on the pump performance curve.

For further assistance, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

**Pump Dimensions**

See Figure 1 for the approximate physical dimensions of this pump.

### OUTLINE DRAWING



**Figure 1. Pump Model PA6D60C-B-E50 460/3**

## PREINSTALLATION INSPECTION

The pump assembly was inspected and tested before shipment from the factory. Before installation, inspect the pump for damage which may have occurred during shipment. Check as follows:

- a. Inspect the pump for cracks, dents, damaged threads, and other obvious damage.
- b. Check for and tighten loose attaching hardware. Since gaskets tend to shrink after drying, check for loose hardware at mating surfaces.
- c. Compare the amperes, phase, voltage and hertz indicated on the pump motor nameplate to the ratings indicated for the control box.
- d. Carefully read all tags, decals, and markings on the pump assembly, and perform all duties indicated. Note that the pump shaft rotates in the required direction.



Only operate this pump in the direction indicated by the arrow on the pump body and on the accompanying decal. Otherwise, the impeller could become loosened from the shaft and seriously damage the pump.

- e. Check levels and lubricate as necessary. Refer to **LUBRICATION** in the **Maintenance and Repair Manual** and perform duties as instructed.
- f. If the pump has been stored for more than 12 months, some of the components or lubricants may have exceeded their maximum shelf life. These **must be inspected or replaced** to ensure maximum pump service.

If the maximum shelf life has been exceeded, or if anything appears to be abnormal, contact your Gorman-Rupp distributor or the factory to determine the repair or updating policy. **Do not** put the pump into service until appropriate action has been taken.

## POSITIONING PUMP



**Death or serious personal injury and damage to the pump or components can occur if proper lifting procedures are not observed. Make certain that hoists, chains, slings or cables are in good working condition and of sufficient capacity and that they are positioned so that loads will be balanced and the pump or components will not be damaged when lifting. Suction and discharge hoses and piping must be removed from the pump before lifting. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.**

### Lifting

Pump unit weights will vary depending on the mounting and drive provided. Check the shipping tag on the unit packaging for the actual weight, and use lifting equipment with appropriate capacity. Drain the pump and remove all customer-installed equipment such as suction and discharge hoses or piping before attempting to lift existing, installed units.

### Mounting

Locate the pump in an accessible place as close as practical to the liquid being pumped. Level mounting is essential for proper operation.

The pump may have to be supported or shimmed to provide for level operation or to eliminate vibration.



**If the pump has been mounted on a movable base, do not attempt to operate the pump unless the unit is level. Be sure the leveling stands are positioned on a solid surface, and the wheels are chocked.**

## SUCTION AND DISCHARGE PIPING

Pump performance is adversely effected by increased suction lift, discharge elevation, and friction losses. See the performance curve and operating range shown on Page E-1 to be sure your overall application allows pump to operate within the safe operation range.

### Materials

Either pipe or hose may be used for suction and discharge lines; however, the materials must be compatible with the liquid being pumped. If hose is used in suction lines, it must be the rigid-wall, reinforced type to prevent collapse under suction. Using piping couplings in suction lines is not recommended.

### Line Configuration

Keep suction and discharge lines as straight as possible to minimize friction losses. Make minimum use of elbows and fittings, which substantially increase friction loss. If elbows are necessary, use the long-radius type to minimize friction loss.

### Connections to Pump

Before tightening a connecting flange, align it exactly with the pump port. Never pull a pipe line into place by tightening the flange bolts and/or couplings.

Lines near the pump must be independently supported to avoid strain on the pump which could cause excessive vibration, decreased bearing life, and increased shaft and seal wear. If hose-type lines are used, they should have adequate support to secure them when filled with liquid and under pressure.

### Gauges

The pump is drilled and tapped for installing discharge pressure and vacuum suction gauges. It is recommended that gauges be installed to monitor pump performance. Seal the gauge threads with pipe dope to ensure an airtight seal. Follow the sealant manufacturer's recommendations when selecting and applying the pipe dope. The pipe

dope should be compatible with the liquid being pumped.

## SUCTION LINES

To avoid air pockets which could affect pump priming, the suction line must be as short and direct as possible. When operation involves a suction lift, the line must always slope upward to the pump from the source of the liquid being pumped; if the line slopes down to the pump at any point along the suction run, air pockets will be created.

### Fittings

Suction lines should be the same size as the pump inlet. If reducers are used in suction lines, they should be the eccentric type, and should be installed with the flat part of the reducers uppermost to avoid creating air pockets. Valves are not normally used in suction lines, but if a valve is used, install it with the stem horizontal to avoid air pockets.

### Strainers

Be certain to use the strainer furnished with the pump; any spherical solids which pass through the strainer will also pass through the pump itself.

If a strainer not furnished with the pump is installed by the pump user, make certain that the total area of the openings in the strainer is at least three or four times the cross section of the suction line, and that the openings will not permit passage of solids larger than the solids handling capability of the pump.

This pump is designed to handle up to 3 inch (76,2 mm) diameter spherical solids.

### Sealing

Since even a slight leak will affect priming, head, and capacity, especially when operating with a high suction lift, all connections in the suction line should be sealed with pipe dope to ensure an airtight seal. Follow the sealant manufacturer's recommendations when selecting and applying the pipe dope. The pipe dope should be compatible with the liquid being pumped.

### Suction Lines In Sumps

If a single suction line is installed in a sump, it should be positioned away from the wall of the

sump at a distance equal to 1 1/2 times the diameter of the suction line.

If there is a liquid flow from an open pipe into the sump, the flow should be kept away from the suction inlet because the inflow will carry air down into the sump, and air entering the suction line will reduce pump efficiency.

If it is necessary to position inflow close to the suction inlet, install a baffle between the inflow and the suction inlet at a distance 1-1/2 times the diameter of the suction pipe. The baffle will allow entrained air to escape from the liquid before it is drawn into the suction inlet.

If two suction lines are installed in a single sump, the flow paths may interact, reducing the efficiency of one or both pumps. To avoid this, position the suction inlets so that they are separated by a distance equal to at least 3 times the diameter of the suction pipe.

### Suction Line Positioning

The depth of submergence of the suction line is critical to **efficient** pump operation. Figure 2 shows recommended minimum submergence vs. velocity.

Although not recommended, the vacuum assisted priming feature allows the pump to be operated temporarily in a “slurping” application with varying water levels.

### NOTE

*The pipe submergence required may be reduced by installing a standard pipe increaser fitting at the end of the suction line. The larger opening size will reduce the inlet velocity. Calculate the required submergence using the following formula based on the increased opening size (area or diameter).*




Figure 2. Recommended Minimum Suction Line Submergence vs. Velocity

## DISCHARGE LINES

### Siphoning


Do not terminate the discharge line at a level lower than that of the liquid being pumped unless a siphon breaker is used in the line. Otherwise, a siphoning action causing damage to the pump could result.

### Valves

This pump is designed with a check valve in the discharge line.

If a throttling valve is desired in the discharge line, use a valve as large as the largest pipe to minimize friction losses. Never install a throttling valve in a suction line.

With high discharge heads, it is recommended that a throttling valve be installed in the discharge line to protect the pump from excessive shock pressure and reverse rotation when it is stopped.



If the application involves a high discharge head, gradually close the discharge throttling valve before stopping the pump.

## ELECTRICAL CONNECTIONS



**Obtain the services of a qualified electrician to make all electrical connections and to service the control box.**



**The electrical power used in this control box is high enough to cause injury or death. Make certain that the control box is properly grounded after installation. Make certain that the power source phase and voltage matches the data on the control box. Complete all electrical connections before connecting the power supply to the control box. Make certain to ground the appropriate lead of the power source before connecting power to the control. Make certain that the control box is properly grounded after installation.**

### Grounding Methods

Electrically ground the installation before connecting the field wiring to the control box. Install a grounding terminal to the enclosure and connect it to a properly embedded electrode.

The material used for the electrode **must** be an excellent conductor of electricity, such as copper. If iron or steel is used, it must be galvanized or otherwise metal plated to resist corrosion. **Do not** coat the electrode with any material of poor conductivity, such as paint or plastic.

The electrode must conform to the recommendations of N.E.C. ARTICLE 250. Follow all installation requirements of the N.E.C., and all applicable codes. See Figure 3 for some suggested grounding methods.




Figure 3. Suggested Grounding Methods

- a. **Plate Electrode:** An iron or steel plate, 1/4 inch (6,4 mm) thick, completely impeded in the ground. The plate must present a surface area of at least 2 square feet (1858,1 sq. cm).
- b. **Driven Electrode:** A rod or pipe, 3/4 inch (19,1 mm) in diameter minimum, 8 feet (2,4 m) long, completely driven into the ground.
- c. **Buried electrode:** If rock or stone prevents embedding the full 8 foot (2,4 m) length of the ground rod, bury it horizontally in a trench.

Space the ground rod or plates at least 6 feet (1,8 m) from any other electrode or ground rod, such as those used for signal circuits, radio grounds, lightning rods, etc.

The earth surrounding the ground rod or plate **must** contain enough moisture to make a good electrical connection. In dry or sandy areas, pour water around the rod, or consult qualified personnel to devise a method of improving the connection.

**Field Wiring Connections (Incoming Power)**



The electrical power used to operate this pump is high enough to cause injury or death. Obtain the services of a qualified electrician to make all electrical connections. Make certain that the pump and enclosure are properly grounded; never use gas pipe as an electrical ground. Be sure that the incoming power matches the voltage and

**phase of the pump and control before connecting the power source. Do not run the pump if the voltage is not within the limits.**

The control is designed to regulate the power supply. The field wiring must be properly sized to ensure an adequate voltage supply. The voltage available **at the pump motor** must be within the indicated range.

Table 1. Pump Motor Voltage Limits

| Nominal Voltage | Phase | Minimum Voltage | Maximum Voltage |
|-----------------|-------|-----------------|-----------------|
| 460             | 3     | 414             | 506             |
| 575             | 3     | 517             | 632             |

If the voltage is not within the recommended limits, obtain the services of a qualified electrician to determine the correct field wiring size and other details to ensure an adequate voltage supply.

Make certain all connections are tight and that cable entry points are rainproof. Support the cable weight, if required, to prevent excessive strain on cable clamps and cable.

**NOTE**

*After the power cables have been connected to the control box, make certain the connection is water-proof.*

**Voltage Imbalance**

Each phase of the incoming three-phase power must be balanced with the other two as accurately as a commercial voltmeter will read. If the phases

are out of balance, contact your power company and request that they correct the condition.

### Power Cable Connections



The electrical power used to operate the control box is high enough to cause injury or death. Obtain the services of a qualified electrician to make all electrical connections. Make certain that incoming power to the control box is in the off position and locked out, or that the power supply to the control box has been otherwise cut off and locked out, before connecting power or accessory cables.

When necessary to change or connect power cables to the control box, make certain the incoming power is **OFF** and **LOCKED OUT**. Make certain the control box is **properly grounded** and that the electrical data on the control matches the pump motor name plate data.

Connect the power cable to the control box as shown in the wiring diagrams in this section or inside the control box door. Use conduit or cable clamps to secure the power and accessory cables to the control box. Make certain that all connections are tight and that cable entry points are rainproof.

## ALIGNMENT

The alignment of the pump and motor is critical for trouble-free mechanical operation. In a flexible coupling system, the driver and pump must be mounted so that their shafts are aligned with and parallel to each other. It is imperative that alignment be checked after the pump and piping are installed, and before operation.

### NOTE


*Check **Rotation**, Section C, before final alignment of the pump.*

When mounted at the Gorman-Rupp factory, driver and pump are aligned before shipment. Misalign-

ment will occur in transit and handling. Pumps **must** be checked and realigned before operation. Before checking alignment, tighten the foundation bolts. The pump casing feet and/or pedestal feet, and the driver mounting bolts should also be tightly secured.



**When checking alignment, disconnect the power source to ensure that the pump will remain inoperative.**



Adjusting the alignment in one direction may alter the alignment in another direction. Check each procedure after altering alignment.

## AUTO-START

The pump is equipped with an auto-start control system which allows the pump to start and stop as the liquid level in the wet well or sump rises and falls.

Refer to the information which follows for installation details for the optional liquid level sensing system.

### Float Switch Installation

The Float Switch autostart system employs either a single or double float switch, where a bulb raises or lowers (floats) with the liquid level, thus activating an enclosed miniature switch. The floats are equipped with a socket type connector that plugs into a matching receptacle on the auto-start control box.

Standard floats are equipped with 50 feet (15,2 m) of cable.

When installing the floats, note the following:

- a. **Be sure** to provide sufficient room in the wet well or sump so that floats do not get obstructed or drawn into the suction line. If a flexible suction hose is used, it may be extended

to lay along the bottom of the wet well or sump and the float can be attached to the hose above the point where it bends along the bottom. Direct the suction line toward the flow, and the float(s) away from the flow. If a standpipe is available, attach the float switch cable to the standpipe in the sump at the approximate desired liquid level.

- b. In a single float system, the cable can be tethered to the suction line or standpipe approximately 6 inches (152 mm) above the float. This setting allows approximately 9 inches (229 mm) of liquid rise between pump start/

stop. The start/stop interval may be increased by extending the float end of the cable. The liquid level in the sump will increase approximately 8 inches (203 mm) between start/stop intervals for every 6 inches (152 mm) of cable increase.

- c. If a double float switch system is used, position the "Start" float at the desired high water level in the sump, and the "Stop" float at the desired low water level in the pump.
- d. Refer to Figure 4 for additional float switch data.




Figure 4. Float Switch Data

**COLD WEATHER INSTALLATION**

If the pump is to be installed in an environment where sub-freezing temperatures will occur during operation, consideration must be given to prevent the pump and components from freezing when the pump is idle between pumping cycles. With Gorman-Rupp priming assisted pumps, there are two methods of accomplishing this.

One method is through the use of an optional heated priming chamber, which is available as a factory-installed option or as a retrofit kit. This method pumps heated liquid from the engine cooling system through the priming chamber to heat the chamber and its contents. This method is particularly effective where pumping cycles are short enough to ensure that the liquid in the priming chamber never fully freezes.

The second method involves configuring the pumping system to drain both the priming chamber and pump casing after each pumping cycle. With no liquid remaining in the system, freezing cannot occur.

To configure the pump to drain between pumping cycles, the first step is to remove the check valve from the line that runs between the top of the priming hopper and the priming venturi. This check valve is located close to the venturi end of the line. Remove the check valve, then reconnect the line directly to the venturi. This will allow air to enter the pump through the top of the priming hopper when the pump shuts off, providing for complete drainage of the pump and priming hopper.

Next, install a drain line between the pump drain and the wet well or sump. This line must remain submerged in the liquid below the pump down lev-



el of the liquid level control device; otherwise, the pump may not prime. If the application involves liquids that could clog the drain line, make sure to check the line periodically to ensure it remains open; otherwise, liquid could remain in the casing, resulting in freezing and potential damage to the pumping system.

Configuring the system to drain between cycles will help ensure that the pump will not freeze during cold weather applications. **However, it should be noted that the time required for the pump to begin to discharge liquid will increase, as the pump will have to fully re-prime at the beginning of each pumping cycle.**

## OPERATION – SECTION C

Review all SAFETY information in Section A.

Follow the instructions on all tags, labels and decals attached to the pump.



The electrical power used to operate this control box is high enough to cause injury or death. Make certain that the control handle on the control box is in the OFF position and locked out, or that the power supply to the control box has been otherwise cut off and locked out, before attempting to open or service the control box. Tag electrical circuits to prevent accidental start-up.



Obtain the services of a qualified electrician to make all electrical connections, and to troubleshoot, test and/or service the electrical components of the control box.



This pump is designed to handle most non-volatile, non-flammable liquids containing specified entrained solids and corrosives. Do not attempt to pump volatile, corrosive, or flammable liquids which may damage the pump or endanger personnel as a result of pump failure.

### STARTING AND OPERATION

#### Rotation

The correct direction of pump rotation is indicated by an arrow on the pump body or accompanying decals. If the pump is operated in the wrong direction, the impeller could become loosened from the shaft and seriously damage the pump.



The pump must operate in the direction indicated by the arrow on the pump, or accompanying decals. Reverse rotation could damage the pump and adversely affect performance.

Disconnect the pump from the motor before checking motor rotation. To check rotation, operate the motor independently while observing the direction of the motor shaft or cooling fan.

If rotation is incorrect, have a qualified electrician interchange any two of the three phase wires at the line connection to change direction.

#### Control Box Function



The control box provides overload protection and power control. Do not connect the pump motor directly to the incoming power lines.

The control box is provided to facilitate operation of the pump. It contains controls for starting and stopping the pump and provides overload protection for the pump motor. The pump control also contains low voltage circuits for the automatic liquid level sensing device(s).

The motor used to power this pump is controlled by a Variable Frequency Drive (VFD), which can be adjusted to control the performance of the pump based on the requirements of the specific applica-

tion. The VFD is programmed from the factory to operate the pump within the maximum and minimum speed range shown on the Performance Curve in Section E.

The **selector switch** controls the mode of operation. In the OFF position, it prevents all operation of the pump. In the ON position, it allows the pump to run continuously. When used in conjunction with liquid level controls, the AUTO position allows the pump to be controlled automatically by the liquid level control system.

Turn the selector switch to the desired setting (ON/AUTO) and follow the instructions provided with the Variable Frequency Drive Control Unit to start and stop the unit and to set the motor speed for the desired pump performance.

### Priming

The pump will begin to prime upon startup. The air in the suction line will be discharged from the priming chamber discharge line. Complete priming is indicated by a positive discharge pressure reading.

If full priming is not achieved, the discharge check valve may be malfunctioning. If this occurs, shut down the pump and consult the separate **Maintenance and Repair** manual for further details.

### Leakage

Once the pump is fully primed, no leakage should be visible at pump mating surfaces, or at pump connections or fittings. Keep all line connections and fittings tight to maintain maximum pump efficiency.

### Pump Vacuum Check

Read the vacuum gauge with the pump primed and at operation speed. Shut off the pump. The vacuum gauge reading will immediately drop proportionate to static suction lift, and should then stabilize. If the vacuum reading falls off rapidly after stabilization, an air leak exists. Before checking for

the source of the leak, check the point of installation of the vacuum gauge.

### Priming Chamber Discharge Line

Check the priming chamber discharge line for liquid bypass. If bypass occurs, shut down the pump. Refer to the Maintenance and Repair Manual, disassemble and clean the float and valve assembly inside the priming chamber.

### Liquid Temperature and Overheating

Overheating can occur if operated with valves in the suction or discharge lines closed. Operating against closed valves could bring the liquid to a boil, build pressure, and cause the pump to rupture or explode. If overheating occurs, stop the pump immediately and allow it to completely cool before servicing it. **Approach any over-heated pump cautiously.**



**Do not remove plates, covers, gauges, pipe plugs, or fittings from an over-heated pump. Vapor pressure within the pump can cause parts being disengaged to be ejected with great force. Allow the pump to completely cool before servicing.**

### Strainer Check

Check the strainer regularly and clean it as necessary. The strainer should also be checked if pump flow rate begins to drop. Monitor and record the vacuum suction gauge readings regularly to detect strainer blockage.

**Never** introduce air or steam pressure into the pump casing or piping to remove a blockage. This could result in personal injury or damage to the equipment. If backflushing is absolutely necessary, **liquid pressure** must be limited to 50% of the maximum permissible operating pressure shown on the pump performance curve.

## STOPPING

### Manual Stopping

Turn the selector switch on the control box to the OFF position.

After stopping the pump, lock out and tag out the control box to ensure that the pump will remain inoperative.

### Automatic Stopping

In the automatic mode, the pump will stop when the liquid in the wet well or sump lowers and activates the “Off” liquid level device(s). The pump will restart automatically when the liquid rises and activates the “On” liquid level device(s).

## PERIODIC CHECKS

### Seal And Bearing Cavity Lubrication

Both the seal and bearing cavities were fully lubricated at the factory. Check the lubrication levels before startup and regularly thereafter as indicated in the Maintenance and Repair Manual. When lubrication is required, use **only** SAE No. 30 non-detergent oil.

### Bearing Temperature Check

Bearings normally run at higher than ambient temperatures because of heat generated by friction.

Temperatures up to 160°F (71°C) are considered normal for bearings, and they can operate safely to at least 180°F (82°C).

Checking bearing temperatures by hand is inaccurate. Bearing temperatures can be measured accurately by placing a contact-type thermometer against the housing. Record this temperature for future reference.

A sudden increase in bearing temperatures is a warning that the bearings are at the point of failing to operate properly. Make certain that the bearing lubricant is of the proper viscosity and at the correct level (see **LUBRICATION** in the Maintenance and Repair Manual). Bearing overheating can also be caused by shaft misalignment and/or excessive vibration.

When pumps are first started, the bearings may seem to run at temperatures above normal. Continued operation should bring the temperatures down to normal levels.

## COLD WEATHER OPERATION

If the pump is to be installed in an environment where sub-freezing temperatures will occur during operation, consideration must be given to prevent the pump and components from freezing when the pump is idle between pumping cycles. Refer to **COLD WEATHER INSTALLATION** in Section B for cold weather applications.

## TROUBLESHOOTING – SECTION D

Review all **SAFETY** information in Section A.

The following information is divided into two categories; Pump Troubleshooting and Control Box Troubleshooting. Additionally, there is a Pump Preventive Maintenance Schedule at the end of this section. Refer to the appropriate chart for possible causes and remedies for your specific problem.



**Before attempting to open or service the pump:**

1. Familiarize yourself with this manual.
2. Turn the control box selector switch to 'OFF' and lock it out to ensure that the pump will remain inoperative.
3. Allow the pump to completely cool if overheated.
4. Check the temperature before opening any covers, plates, or plugs.

5. Close the suction and discharge valves.
6. Vent the pump slowly and cautiously.
7. Drain the pump.



This pump is equipped with an optional automatic starting system, and therefore subject to automatic restart. Keep hands and clothing away from the unit to prevent injury during automatic operation. Disconnect the positive battery cable before performing any maintenance. Failure to do so may result in serious personal injury.



Obtain the services of a qualified electrician to troubleshoot, test and/or service the electrical components of the control box.

### Pump Troubleshooting

| TROUBLE   | POSSIBLE CAUSE   | PROBABLE REMEDY  |
|---|--|--|
| PUMP FAILS TO PRIME                                   | Discharge check valve contaminated, damaged, or unable to seat.<br>Air leak in suction line.<br>Lining of suction hose collapsed.<br>Leaking or worn seal or pump gasket.<br><br>Suction lift or discharge head too high.<br><br>Air compressor damaged/belts broken.<br>Strainer clogged. | Clean or replace check valve.<br><br>Correct leak.<br>Replace suction hose.<br>Check pump vacuum. Replace leaking or worn seal or gasket.<br>Check piping installation and install bypass line if needed. See <b>INSTALLATION</b> .<br>Check and repair/replace.<br>Check strainer and clean if necessary. |
| PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE | Eductor clogged.<br>Air leak in suction line.<br>Lining of suction hose collapsed.<br>Leaking or worn seal or pump gasket.   | Check and clean eductor.<br>Correct leak.<br>Replace suction hose.<br>Check pump vacuum. Replace leaking or worn seal or gasket.   |

### Pump Troubleshooting (Cont'd)

| TROUBLE   | POSSIBLE CAUSE   | PROBABLE REMEDY  |
|---|--|--|
| PUMP STOPS OR FAILS TO DELIVER RATED FLOW OR PRESSURE (cont.) | Strainer clogged.<br><br>Discharge check valve clogged.<br><br>Suction intake not submerged at proper level or sump too small.<br><br>Impeller or other wearing parts worn or damaged.<br><br>Impeller clogged.<br><br>Discharge head too high.<br><br>Suction lift too high.<br><br>Pump speed too slow.<br><br>Belt or flexible coupling broken. | Check strainer and clean if necessary.<br><br>Check and clean check valve.<br><br>Check installation and correct submergence as needed.<br><br>Replace worn or damaged parts. Check that impeller is properly centered and rotates freely.<br><br>Free impeller of debris.<br><br>Install bypass line.<br><br>Measure lift w/vacuum gauge. Reduce lift and/or friction losses in suction line.<br><br>Check engine output; consult engine operation manual.<br><br>Check and replace as necessary. |
| PUMP REQUIRES TOO MUCH POWER                                  | Pump speed too high.<br>Extreme ambient temperature.<br>Discharge head too low.<br>Fuel filter clogged.<br><br>Liquid solution too thick.<br>Fuel contaminated.<br>Pump or jack shaft bearing(s) frozen.   | Check engine output.<br>Reduce pump output.<br>Adjust discharge valve.<br>Check & replace often in extreme operating conditions.<br><br>Dilute if possible.<br>Check and replace as required.<br>Disassemble, check and replace bearing(s) as required..   |
| PUMP CLOGS FREQUENTLY   | Discharge flow too slow.<br><br>Suction check valve or foot valve clogged or binding.<br><br>Liquid solution too thick.  | Open discharge valve fully to increase flow rate, and run engine at maximum governed speed.<br><br>Clean valve.<br><br>Dilute if possible.   |
| EXCESSIVE NOISE   | Cavitation in pump.<br><br>Pumping entrained air.<br><br>Pump or drive not securely mounted.<br>Impeller clogged or damaged.   | Reduce suction lift and/or friction losses in suction line. Record vacuum and pressure gauge readings and consult local representative or factory.<br><br>Locate and eliminate source of air bubble.<br><br>Secure mounting hardware.<br><br>Clean out debris; replace damaged parts.  |

### Pump Troubleshooting (Cont'd)

| TROUBLE              | POSSIBLE CAUSE  | PROBABLE REMEDY   |
|----------------------|---|---|
| BEARINGS RUN TOO HOT | <p>Bearing temperature is high, but within limits.</p> <p>Low or incorrect lubricant.</p> <p>Suction and discharge lines not properly supported.</p> <p>Drive misaligned.</p> <p>Excessive tension on drive belt.</p> | <p>Check bearing temperature regularly to monitor any increase.</p> <p>Check for proper type and level of lubricant.</p> <p>Check piping installation for proper support.</p> <p>Align drive properly.</p> <p>Check belt tension. Adjust as required.</p> |

### Control Box Troubleshooting

| TROUBLE  | POSSIBLE CAUSE  | PROBABLE REMEDY   |
|--|---|---|
| PUMP FAILS TO START, OVERLOAD UNIT NOT TRIPPED (MANUAL MODE) | <p>Power source incompatible with control box.</p> <p>No voltage at line side of circuit breaker.</p> <p>No voltage at line terminals on bottom of overload unit in control box.</p>  | <p>Correct power source.</p> <p>Check power source for blown fuse, open overload unit, broken lead, or loose connection.</p> <p>Check power source for blown fuse, open disconnect, broken wire, or loose connection.</p>   |
| OVERLOAD UNIT TRIPS  | <p>Low or high voltage, or excessive voltage drop between pump and control box.</p> <p>Power input phases not balanced.</p> <p>Control box not compatible with pump.</p> <p>Foreign object locking impeller or bearing frozen.</p> <p>Motor windings short-circuited.</p> | <p>Measure voltage at control box. Check that wiring is correct type, size, and length. (See <b>Field Wiring Connections</b>, Section B).</p> <p>If imbalance exceeds 1 percent, notify power company</p> <p>Electrical data on control box and pump name plate must agree. Replace control box if not in agreement.</p> <p>Remove foreign material or replace damaged bearing. If bearing is damaged, check for water in motor housing.</p> <p>Check motor windings with ohmmeter.</p> |

### PUMP PREVENTIVE MAINTENANCE

Since pump applications are seldom identical, and pump wear is directly affected by such things as the abrasive qualities, pressure and temperature of the liquid being pumped, this section is intended only to provide general recommendations and practices for preventive maintenance. Regardless of the application however, following a routine preventive maintenance schedule will help assure trouble-free performance and long life from your Gorman-Rupp pump. For specific questions concerning your application, contact your Gorman-Rupp distributor or the Gorman-Rupp Company.

Record keeping is an essential component of a good preventive maintenance program. Changes in suction and discharge gauge readings (if so

equipped) between regularly scheduled inspections can indicate problems that can be corrected before system damage or catastrophic failure occurs. The appearance of wearing parts should also be documented at each inspection for comparison as well. Also, if records indicate that a certain part (such as the seal) fails at approximately the same duty cycle, the part can be checked and replaced before failure occurs, reducing unscheduled down time.

For new applications, a first inspection of wearing parts at 250 hours will give insight into the wear rate for your particular application. Subsequent inspections should be performed at the intervals shown on the chart below. Critical applications should be inspected more frequently.

| <b>Preventive Maintenance Schedule</b>   |                   |        |         |               |          |
|--|-------------------|--------|---------|---------------|----------|
| Item   | Service Interval* |        |         |               |          |
|  | Daily             | Weekly | Monthly | Semi-Annually | Annually |
| General Condition (Temperature, Unusual Noises or Vibrations, Cracks, Leaks, Loose Hardware, Etc.) | I                 |        |         |               |          |
| Pump Performance (Gauges, Speed, Flow)   | I                 |        |         |               |          |
| Bearing Lubrication  |                   | I      |         |               | R        |
| Seal Lubrication (And Packing Adjustment, If So Equipped)  |                   | I      |         |               | R        |
| V-Belts (If So Equipped)   |                   |        | I       |               |          |
| Air Release Valve Plunger Rod (If So Equipped)   |                   |        | I       | C             |          |
| Front Impeller Clearance (Wear Plate)  |                   |        |         | I             |          |
| Rear Impeller Clearance (Seal Plate)   |                   |        |         | I             |          |
| Check Valve  |                   |        |         |               | I        |
| Pressure Relief Valve (If So Equipped)   |                   |        |         |               | C        |
| Pump and Driver Alignment  |                   |        |         |               | I        |
| Shaft Deflection   |                   |        |         |               | I        |
| Bearings   |                   |        |         |               | I        |
| Bearing Housing  |                   |        |         |               | I        |
| Piping   |                   |        |         |               | I        |
| Driver Lubrication – See Mfgr’s Literature   |                   |        |         |               | I        |


**Legend:**  
 I = Inspect, Clean, Adjust, Repair or Replace as Necessary  
 C = Clean  
 R = Replace

\* Service interval based on an intermittent duty cycle equal to approximately 4000 hours annually. Adjust schedule as required for lower or higher duty cycles or extreme operating conditions.



## PUMP MAINTENANCE AND REPAIR – SECTION E


MAINTENANCE AND REPAIR OF THE WEARING PARTS OF THE PUMP WILL MAINTAIN PEAK OPERATING PERFORMANCE.



**\* STANDARD PERFORMANCE FOR PUMP MODEL PA6D60C-B-E50 460/3**

\* Based on 70°F (21°C) clear water at sea level with minimum suction lift. Since pump installations are seldom identical, your performance may be different due to such factors as viscosity, specific gravity, elevation, temperature, and impeller trim.

Contact the Gorman-Rupp Company to verify performance or part numbers.



Pump speed and operating condition points must be within the continuous performance range shown on the curve.

ILLUSTRATION




Figure 1. Pump Model PA6D60C-B-E50 460/3

## Pump Model PA6D60C-B-E50 460/3

### Parts List

(From S/N 1632400 Up)

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify part numbers.

| ITEM NO. | PART NAME           | PART NUMBER         | QTY | ITEM NO.   | PART NAME            | PART NUMBER     | QTY |
|----------|---------------------|---------------------|-----|------------|----------------------|-----------------|-----|
| 1        | PUMP END ASSEMBLY   | PA6D60C-B-(E50) /S1 | 1   | 25         | HEX HEAD CAP SCREW   | B1010 15991     | 4   |
| 2        | 50 HP 3P TEFC MOTOR | 28260-698           | 1   | 26         | FLAT WASHER          | K10 15991       | 4   |
| 3 *      | COUPLING            | 24360-302           | 1   | 27         | HEX HEAD CAP SCREW   | B0806 15991     | 6   |
| 4        | LOCK WASHER         | J06 15991           | 10  | 28         | HEX NUT              | D06 15991       | 2   |
| 5        | HEX HEAD CAP SCREW  | B0607 15991         | 10  | 29         | HEX HEAD CAP SCREW   | B0807 15991     | 4   |
| 6        | THREADED INSERT     | 21769-163           | 8   | 30         | INTERMEDIATE BRACKET | 34258-020 15080 | 1   |
| 7        | COUPLING GUARD ASSY | 42342-258 24150     | 1   | 31         | VALVE SUPPORT ASSY   | 41881-753 24150 | 1   |
| 8        | CORD GRIP           | 27112-031           | 1   | 32         | HEX HEAD CAP SCREW   | B1210 15991     | 4   |
| 9        | RED PIPE BUSHING    | AP2420 11999        | 1   | 33         | FLAT WASHER          | KB12 17040      | 2   |
| 10       | HOIST BAIL ASSY     | 44713-061 24150     | 1   | 34         | HEX HEAD CAP SCREW   | B0805-1/2 15991 | 2   |
| 11       | LOCK WASHER         | J04 15991           | 4   | 35         | HEX NUT              | D12 15991       | 4   |
| 12       | HEX NUT             | D04 15991           | 4   | 36         | LOCK WASHER          | J12 15991       | 4   |
| 13       | MTG BRACKET ASSY    | 41888-341 24150     | 1   | 37         | PUMP FOOT BRACKET    | 34258-021 15080 | 1   |
| 14       | CONTROL BOX KIT     | 48122-568           | 1   | 38         | HEX HEAD CAP SCREW   | B0804 15991     | 1   |
| 15       | HEX HEAD CAP SCREW  | B0404 15991         | 4   | 39         | CLAMP                | 27111-348       | 1   |
| 16       | FLAT WASHER         | K04 15991           | 4   | NOT SHOWN: |                      |                 |     |
| 17       | HEX NUT             | D08 15991           | 18  |            | OIL FILL DECAL       | 38816-194       | 1   |
| 18       | LOCK WASHER         | J08 15991           | 19  |            | MOTOR VOLTAGE TAG    | 38816-460       | 1   |
| 19       | HEX HEAD CAP SCREW  | B0805 15991         | 6   |            | G-R DECAL 6 IN       | GR-06           | 3   |
| 20       | HEX NUT             | D10 15991           | 4   |            | PRIME AIRE DECAL     | 38812-078       | 2   |
| 21       | LOCK WASHER         | J10 15991           | 4   |            | WARNING DECAL        | 38816-345       | 2   |
| 22       | FLAT WASHER         | K08 15991           | 24  |            | INSTRUCTION TAG      | 38817-085       | 1   |
| 23       | CONT BOX/MTR CABLE  | 47325-016           | 1   |            | INSTRUCTION DECAL    | 38816-331       | 2   |
| 24       | FLEX SKID BASE ASSY | 41568-003 24150     | 1   |            | FLOAT SWITCH         | 48312-980       | 1   |
|          |                     |                     |     |            | WIRING INSTRUCTIONS  | 47117-010       | 1   |

\* INDICATES PARTS RECOMMENDED FOR STOCK

ILLUSTRATION




Figure 2. PA6D60C-B-(E50) Pump End Assembly

**PA6D60C-B-(E50) Pump End Assembly  
Parts List**

| ITEM NO.   | PART NAME                | PART NUMBER     | QTY |
|------------|--------------------------|-----------------|-----|
| 1          | PUMP SUB ASSY            | 46133-544       | 1   |
| 2          | PRIMING CHAMBER KIT      | 48275-005       | 1   |
| 3          | CONNECTOR                | S1598           | 1   |
| 4          | HOSE BARB FTG            | 26523-047       | 1   |
| 5          | 1/2" ID X 30" LG HOSE    | 18513-113       | 1   |
| 6          | AIR COMPRESSOR ASSY      | 46181-906       | 1   |
| 7          | BELT GUARD ASSY          | 42351-326 24150 | 1   |
| 8          | HEX HEAD CAP SCREW       | B0402 15991     | 2   |
| 9          | LOCK WASHER              | J04 15991       | 2   |
| 10         | FLAT WASHER              | K04 15991       | 2   |
| 11         | * SYNCHRONOUS BELT       | 24186-008       | 1   |
| 12         | HEX HEAD CAP SCREW       | B0610 15991     | 4   |
| 13         | LOCK WASHER              | J06 15991       | 4   |
| 14         | FLAT WASHER              | K06 15991       | 4   |
| 15         | 3/8" BARB X 1/2" NPT FTG | 26523-387       | 1   |
| 16         | HOSE CLAMP               | 26518-642       | 1   |
| 17         | 1/2" CHECK VALVE         | 26641-092       | 1   |
| 18         | HOSE BARB FITTING        | 26523-446       | 2   |
| 19         | SPROCKET                 | 24271-112       | 1   |
| 20         | BUSHING                  | 24131-498       | 1   |
| 21         | HOSE CLAMP               | 26518-666       | 1   |
| 22         | SPACER                   | 31141-034 15000 | 4   |
| 23         | 3/8" ID X 24" LG HOSE    | 18513-302       | 1   |
| 24         | 1/2" ID X 20" LG HOSE    | 18513-113       | 1   |
| 25         | CLAMP                    | 27111-348       | 1   |
| 26         | CHECK VALVE KIT 6"       | 48274-015       | 1   |
|            | -6" CHECK VALVE          | 26642-126       | 1   |
|            | * --FLAPPER              | 26688-001       | 1   |
|            | * --COVER O-RING         | 25152-377       | 1   |
| NOT SHOWN: |                          |                 |     |
|            | ROTATION DECAL           | 2613M           | 1   |
|            | OIL LEVEL DECAL          | 38816-123       | 1   |
|            | LUBRICATION DECAL        | 11421A          | 1   |
|            | G-R DECAL 6 IN           | GR-06           | 1   |
|            | WARNING DECAL            | 2613FE          | 1   |
|            | DISCHARGE STICKER        | 6588BJ          | 1   |
|            | SUCTION STICKER          | 6588AG          | 1   |
|            | GUARD WARNING STK        | 38816-063       | 1   |
|            | 6" STRAINER ASSEMBLY     | 7823A 24000     | 1   |

\* INDICATES PARTS RECOMMENDED FOR STOCK

ILLUSTRATION




Figure 3. 46133-544 Pump Sub Assembly

**PARTS LIST**  
**46133-544 Pump Sub Assembly**

| ITEM NO. | PART NAME                          | PART NUMBER     | QTY |
|----------|------------------------------------|-----------------|-----|
| 1        | PUMP CASING                        | SEE NOTE BELOW  | 1   |
| 2        | REPAIR ROTATING ASSEMBLY           | 44163-604       | 1   |
| ☞ 3      | PIPE PLUG                          | P16 10009       | 1   |
| ☞ 4      | STUD                               | C1213 15991     | 4   |
| ☞ 5      | PIPE PLUG                          | P06 15079       | 5   |
| 6        | VENTED PIPE PLUG                   | 4823A 15079     | 1   |
| 7        | * O-RING                           | S1676           | 1   |
| 8        | SIGHT GAUGE                        | S1471           | 2   |
| ☞ 9      | PIPE PLUG                          | P12 15079       | 2   |
| ☞ 10     | PIPE PLUG                          | P08 15079       | 1   |
| 11       | PIPE NIPPLE                        | T1622 15079     | 1   |
| 12       | BALL VALVE                         | 26631-024       | 1   |
| 13       | PUMP FOOT BRACKET                  | 34258-022 15080 | 1   |
| 14       | HEX NUT                            | D06 15991       | 3   |
| 15       | LOCK WASHER                        | J06 15991       | 7   |
| 16       | HEX HEAD CAP SCREW                 | B1205 15991     | 2   |
| 17       | LOCK WASHER                        | J12 15991       | 2   |
| 18       | WASHER SAE 3/4                     | 21161-446       | 2   |
| 19       | HEX HEAD CAP SCREW                 | B0804 15991     | 4   |
| 20       | LOCK WASHER                        | J08 15991       | 8   |
| 21       | BACK COVER NUT                     | 31871-073 15000 | 4   |
| 22       | ADJUSTING SCREW                    | 31871-070 1500G | 4   |
| 23       | SUCTION SPOOL 6"                   | 38642-625 10000 | 1   |
| 24       | * GASKET                           | 38687-552 18000 | 1   |
| 25       | MOUNTING PAD                       | 33541-030 15080 | 1   |
| 26       | HEX HEAD CAP SCREW                 | B0606 15991     | 4   |
| 27       | LOCK COLLAR                        | 38115-551 15001 | 4   |
| 28       | * O-RING                           | 25154-449       | 1   |
| 29       | * O-RING                           | 25154-265       | 1   |
| 30       | * WEAR PLATE ASSEMBLY              | 46451-768       | 1   |
| 31       | * O-RING                           | 25154-381       | 2   |
| 32       | HEX HEAD CAP SCREW                 | B0806 15991     | 4   |
| 33       | ROT ASSY ADJ SHIM                  | 13131-3 17040   | 8   |
| ☞        | INCLUDED W/REPAIR PUMP CASING ASSY | 46474-912       | 1   |

\* INDICATES PARTS RECOMMENDED FOR STOCK

ILLUSTRATION




Figure 4. Repair Rotating Assembly



**PARTS LIST**  
**Repair Rotating Assembly**

| ITEM NO.   | PART NAME                 | PART NUMBER     | QTY |
|------------|---------------------------|-----------------|-----|
| 1          | IMPELLER                  | 38628-036 11000 | 1   |
| 2          | IMP ADJ SHIM SET          | 48261-057       | REF |
| 3          | * SEAL ASSEMBLY           | 46512-149       | 1   |
| 4          | * SHAFT SLEEVE            | 31163-019 1706H | 1   |
| 5          | O-RING                    | 25154-131       | REF |
| 6          | SEAL PLATE                | 38272-256 10000 | 1   |
| 7          | * OIL SEAL                | 25227-771       | 1   |
| 8          | SIGHT GAUGE               | S1471           | 2   |
| 9          | PIPE PLUG                 | P08 15079       | 1   |
| 9A         | BEARING CAVITY DRAIN PLUG | P08 15079       | 1   |
| 9B         | SEAL CAVITY DRAIN PLUG    | P08 15079       | 1   |
| 10         | BEARING HOUSING           | 38251-513 10000 | 1   |
| 11         | VENTED PIPE PLUG          | 4823A 15079     | 1   |
| 12         | AIR VENT                  | S1530           | 1   |
| 13         | REDUCER PIPE BUSHING      | AP0802 15079    | 1   |
| 14         | HEX HEAD CAP SCREW        | B0805-1/2 15991 | 4   |
| 15         | LOCK WASHER               | J08 15991       | 4   |
| 16         | HEX HEAD CAP SCREW        | 21632-937       | 6   |
| 17         | LOCK WASHER               | J06 15991       | 6   |
| 18         | * OIL SEAL                | S1907           | 1   |
| 19         | DRIVE FLANGE              | 38545-009 11010 | 1   |
| 20         | INTERMEDIATE GUARD        | 42381-509 24152 | 2   |
| 21         | * GASKET                  | 38683-474 18000 | 1   |
| 22         | RETAINING RING            | S720            | 1   |
| 23         | * BALL BEARING            | 23422-414       | 1   |
| 24         | KEY                       | N0810-1/2 15990 | 1   |
| 25         | IMPELLER SHAFT            | 38515-586 1706H | 1   |
| 26         | * BALL BEARING            | 23422-019       | 1   |
| 27         | SOCKET HEAD CAP SCREW     | DM1004S 17090   | 1   |
| 28         | IMPELLER WASHER           | 31514-015 17000 | 1   |
| 29         | * O-RING                  | 25154-381       | 1   |
| 30         | * O-RING                  | S1676           | 1   |
| 31         | ROT ASSY ADJ SHIM SET     | 13131-3 17040   | 8   |
| 32         | SHIPPING PLUG             | 11495B 15079    | 2   |
| NOT SHOWN: |                           |                 |     |
|            | INSTRUCTION TAG           | 6588U           | 1   |

\* INDICATES PARTS RECOMMENDED FOR STOCK

ILLUSTRATION




Figure 5. 48275-005 Priming Chamber Kit

| ITEM NO. | PART NAME            | PART NUMBER     | QTY |
|----------|----------------------|-----------------|-----|
| 1        | PRIMING CHAMBER ASSY | 46112-709       | 1   |
| 2        | PIPE BUSHING         | AP1608 11999    | 1   |
| 3        | STREET ELBOW         | RS08 11999      | 1   |
| 4        | BALL VALVE           | 26631-052       | 1   |
| 5        | STUD                 | C0809 15991     | 4   |
| 6        | HEX NUT              | D08 15991       | 4   |
| 7        | LOCK WASHER          | J08 15991       | 4   |
| 8        | * GASKET             | 38687-053 19060 | 1   |
| 9        | BAFFLE               | 31113-011 17000 | 1   |

\* INDICATES PARTS RECOMMENDED FOR STOCK

ILLUSTRATION




Figure 6. 46112-709 Priming Chamber Assembly

PARTS LIST

| ITEM NO. | PART NAME              | PART NUMBER     | QTY |
|----------|------------------------|-----------------|-----|
| 1        | PRIMING VALVE          | 26664-007       | 1   |
|          | -ORIFICE BUTTON        | 26688-021       | 1   |
| 2        | HEX HD CAPSCREW        | B0806 15991     | 8   |
| 3        | LOCKWASHER             | J08 15991       | 8   |
| 4        | * PRIMING VALVE GASKET | 38683-657 19060 | 1   |
| 5        | PRIMING CHAMBER        | 38343-020 10000 | 1   |
| 6        | STRAINER ASSY          | 46641-222 17000 | 1   |

\* INDICATES PARTS RECOMMENDED FOR STOCK

ILLUSTRATION




Figure 7. 46181-906 Air Compressor Assembly

| ITEM NO. | PART NAME             | PART NUMBER     | QTY |
|----------|-----------------------|-----------------|-----|
| 1        | MACH SCREW            | X#10-02 15991   | 4   |
| 2        | HEX NUT               | D#10 15991      | 4   |
| 3        | LOCK WASHER           | J#10 15991      | 4   |
| 4        | FLAT WASHER           | K#10 15991      | 4   |
| 5        | AIR COMPRESSOR COVER  | 38354-043 15120 | 1   |
| 6        | AIR COMPRESSOR        | 26813-111       | 1   |
| 7        | PIPE CAP              | V06 15079       | 1   |
| 8        | PIPE NIPPLE           | T0616 15079     | 1   |
| 9        | 90° ADAPTER 3/8"      | 25412-003       | 1   |
| 10       | PULLEY ASSEMBLY       | 44112-003       | 1   |
| 11       | AIR COMPRESSOR KNOB   | 38429-501 19220 | 1   |
| 12       | SERVICE TEE           | US08 11999      | 1   |
| 13       | REDUCER PIPE BUSHING  | AP0806 15079    | 1   |
| 14       | VENTURI               | 26817-002       | 1   |
| 15       | PIPE CPLG             | AE08 15079      | 1   |
| 16       | PIPE ELBOW            | R08 11999       | 1   |
| 17       | PRESSURE RELIEF VALVE | 26662-028       | 1   |

## PUMP AND SEAL DISASSEMBLY AND REASSEMBLY

Review all SAFETY information in Section A.

Follow the instructions on all tags, label and decals attached to the pump.

This pump requires little service due to its rugged, minimum-maintenance design. However, if it becomes necessary to inspect or replace the wearing parts, follow these instructions which are keyed to the illustrations (see Figures 1 through 7) and the corresponding Parts Lists. Maintenance and repair instructions for the air compressor are covered separately in specific literature available from the manufacturer.

Some pump service functions may be performed without separating the pump end assembly from the power source. However, the priming chamber and discharge check valve assembly must be removed to service most pump components. The following instructions assume complete disassembly of the pump is required.

Before attempting to service the pump, lock out and tag out incoming power to the control box and take precautions to ensure that it will remain inoperative. Close all valves in the suction and discharge lines and drain the pump casing.



This manual will alert personnel to known procedures which require special attention, to those which could damage equipment, and to those which could be dangerous to personnel. However, this manual cannot possibly anticipate and provide detailed instructions and precautions for every situation that might occur during maintenance of the unit. Therefore, it is the responsibility of the owner/maintenance personnel to ensure that only safe, established maintenance procedures are used, and that any procedures not addressed in this manual are performed only after establishing that neither personal safety nor

pump integrity are compromised by such practices.



Before attempting to open or service the pump:

1. Familiarize yourself with this manual.
2. Turn the control box selector switch to 'OFF' and lock it out to ensure that the pump will remain inoperative.
3. Allow the pump to completely cool if overheated.
4. Check the temperature and make sure it is cool before opening any covers, plates, gauges, or plugs.
5. Close the suction and discharge valves.
6. Vent the pump slowly and cautiously.
7. Drain the pump.



Death or serious personal injury and damage to the pump or components can occur if proper lifting procedures are not observed. Make certain that hoists, chains, slings or cables are in good working condition and of sufficient capacity and that they are positioned so that loads will be balanced and the pump or components will not be damaged when lifting. Suction and discharge hoses and piping must be removed from the pump before lifting. Lift the pump or component only as high as necessary and keep personnel away from suspended objects.



This pump is equipped with an automatic starting system, and therefore subject to automatic restart. Keep hands

and clothing away from the unit to prevent injury during automatic operation. Lock out the power from the control box to ensure that the pump will remain inoperative. Failure to do so may result in serious personal injury.



Obtain the services of a qualified electrician to troubleshoot, test and/or service the electrical components of the control box.



Use **only** replacement parts provided or approved by Gorman-Rupp. Use of non-authorized parts may result in damage to the equipment and/or injury to personnel and **will** invalidate the warranty.

### Priming Chamber Removal and Disassembly

(Figure 5)

Disconnect the air discharge tubing from the priming chamber assembly (2, Figure 2). Support the priming chamber assembly using a sling and a suitable lifting device. Remove the hardware (6 and 7) and separate the priming chamber assembly (1), gasket (8) and baffle (9) from the pump casing.

(Figure 6)

Remove the hardware (2 and 3) securing the priming valve (1) to the priming chamber (5). Carefully lift the valve components from the priming chamber. Remove the gasket (4) and clean the mating surfaces.

If the priming valve float is stuck or the strainer (6) is clogged, it can usually be cleaned without further disassembly.

The only serviceable part of the priming valve is the orifice button (not shown). If liquid continues to bypass through the priming chamber after adjusting the orifice button (see **Priming Chamber Reassembly and Installation** for adjustment), the but-

ton may require replacement. To replace the orifice button, remove one of the “e-clips” from the pivot pin closest to the orifice button and remove the pivot pin. This will allow the linkage to be raised high enough to access the orifice button.

Remove the hex nut and lock washer securing the orifice button to the linkage bar and unscrew the orifice button from the linkage bar.

### Discharge Check Valve Removal and Disassembly

(Figure 2)

Support the discharge check valve assembly (26) using a sling and a suitable lifting device. Remove the hardware (not shown) securing the check valve to the pump and separate the discharge check valve assembly and gasket (not shown) from the pump assembly (1).

The flapper and cover O-ring are the only serviceable parts of the check valve. If the flapper requires replacement, remove the hardware securing the cover. Separate the cover and O-ring and remove the flapper.

### Suction Spool and Wear Plate Removal

(Figure 3)

The wear plate (30) is easily accessible and may be serviced by removing the suction spool (27). Before attempting to service the pump, open the ball valve (12) and drain the pump casing. Close the ball valve when draining is complete.

Support the pump casing (1) with wood blocks and shims, or a suitable lifting device and slings.

See Figure 1 and remove the hardware (17, 18, 22 and 29) securing the pump foot brackets (13, Figure 3 and 37, Figure 1) to the base (24).

Disengage the hardware (16, 17 and 18) and remove the foot bracket (13) from the suction spool.

Remove the back cover nuts (21). Install two 5/8-11 UNC-2B capscrews (not supplied) in the tapped holes in the suction spool and use them to “push” the suction spool and assembled wear plate out of the pump casing (1).

Remove the hardware (14 and 15) securing the wear plate to the suction spool. Use a soft-faced

mallet to tap on the wear plate studs until the wear plate is free from the suction spool. Remove the wear plate and remove and discard the O-rings (28, 29 and 31).

### Draining Oil From Seal Cavity

(Figures 3 and 4)

If any further disassembly is to be performed on the pump, the seal oil cavity must be drained to prevent the oil in the seal cavity from escaping as the pump casing is removed.

Position a, **clean** container (2 gallons [7,8 liters] minimum) under the seal cavity drain plugs (10, Figure 3 and 9B, Figure 4). Remove the plugs and drain the oil from the seal cavity into the container. For shorter drain time, remove the vented plugs (6, Figure 3 and 11, Figure 4). Clean and reinstall the drain and vent plugs. Inspect the oil for water, dirt or a cloudy condition which could indicate seal failure.

### Separating Pump End From Power Source

(Figure 1)

Further disassembly of the pump requires separating the pump end from the power source. Disconnect the discharge piping from the pump casing.

Disengage the hardware (4 and 5) and remove the coupling guard (7) and intermediate guards (20, Figure 4).

See Figure 2 and disengage the hardware (8, 9 and 10) and remove the belt guard (7). Remove the hardware (12, 13 and 14) securing the air compressor assembly (6) to the drive flange (19, Figure 4). Use a pry bar to raise the air compressor high enough to remove the spacers (21). Remove the belt (11) from the air compressor drive pulley (not shown).

Disconnect all hoses and fittings from the air compressor and use a suitable hoist and sling to remove the air compressor assembly.

Disconnect the hardware securing the halves of the coupling (3) and separate the coupling halves. Remove the half of the coupling and the drive key (24, Figure 4) from the impeller shaft.

Use a sling and suitable lifting device to pull the pump end straight away from the motor. Remove the coupling half from the impeller shaft.

(Figure 2)

Remove the belt (11). Remove the setscrews from the center of the bushing (20). Reinstall the setscrews in the tapped holes in the bushing and tighten them in an alternating pattern until the bushing is “jacked” out of the sprocket (19). Slide the bushing and sprocket off the shaft. Remove the key (24, Figure 4).

### Loosening Impeller

(Figure 4)

With the pump end separated from the power source, wedge a block of wood between the vanes of the impeller (1) and the pump casing (1, Figure 3) to prevent rotation. Remove the impeller screw and washer (27 and 28).

Install the drive key (24) in the shaft keyway. Install a lathe dog on the drive end of the shaft (25) with the “V” notch positioned over the shaft key.

With the impeller rotation still blocked, see Figure 8 and use a long piece of heavy bar stock to pry against the arm of the lathe dog in a counterclockwise direction (when facing the drive end of the shaft). **Use caution** not to damage the shaft or keyway. When the impeller breaks loose, remove the lathe dog, key and wood block.

### NOTE

*Do not remove the impeller until the rotating assembly has been removed from the pump casing.*




Figure 8. Loosening Impeller

### Pump Casing Removal

#### (Figure 3)

Position the pump assembly on a flat work surface with the rotating assembly (2) positioned up. Support the pump casing (1) using wood blocks or other suitable material. Make sure the pump assembly is secure and stable before proceeding with pump disassembly.

#### NOTE

*Drain the oil from the seal cavity before removing the pump casing. See **Draining Oil From Seal Cavity**.*

See Figure 4 and install a pair of “S” hooks in two opposing holes in the drive flange (19). Connect a sling and suitable lifting device to the “S” hooks.

Remove the hardware (20 and 32) securing the pump casing to the rotating assembly. Use the lifting device to pull the rotating assembly up out of the pump casing and position it on the work surface. Remove the shims (33) and clean the contacting surfaces. Tie and tag the shims or measure and record their thickness for ease of reassembly.

### Impeller Removal

#### (Figure 4)

With the rotating assembly removed from the pump casing, unscrew the impeller (1) in a counterclockwise direction (when facing the impeller). Use caution when unscrewing the impeller; tension on the shaft seal spring will be released as the impeller is removed. Inspect the impeller and replace it if cracked or badly worn.

Remove the impeller adjusting shims (2); tie and tag the shims, or measure and record their thickness for ease of reassembly.

### Seal Removal

#### (Figures 4 and 9)

Remove the spring centering washer and seal spring. Slide the shaft sleeve (4) and rotating portion of the seal (consisting of the bellows, retainer, and rotating element) off the shaft as a unit.

Apply oil to the sleeve and work it up under the rubber bellows. Slide the rotating portion of the seal off the sleeve.

Slide a pair of stiff wires with hooked ends along the shaft and hook the stationary seat from the back side. Pull the stationary seat and O-ring from the seal plate.

An alternate method of removing the stationary seal components is to remove the hardware (14 and 15) and separate the seal plate (6) from the bearing housing (10). Position the seal plate on a flat surface with the impeller side down. Use a wooden dowel or other suitable tool to press on the back side of the stationary seat until the seat and O-ring can be removed.

Remove the shaft sleeve O-ring (5) and seal plate O-ring (29).

If no further disassembly is required, refer to **Seal Installation**.

### Shaft and Bearing Removal and Disassembly

#### (Figure 4)

When the pump is properly operated and maintained, the bearing housing should not require dis-



assembly. Disassemble the shaft and bearings **only** when there is evidence of wear or damage.



Shaft and bearing disassembly in the field is not recommended. These operations should be performed only in a properly equipped shop by qualified personnel.

Remove the bearing housing drain plug (9A) and drain the lubricant. Clean and reinstall the drain plug.

Disengage the hardware (16 and 17) and remove the drive flange (19), gasket (21) and oil seal (18). Use a suitably sized dowel to press the oil seal from the drive flange.

Place a block of wood against the impeller end of the shaft (25) and tap the shaft and assembled bearings (23 and 26) from the bearing housing. Press the oil seal (7) from the bearing housing.

Remove the bearing housing O-ring (30).

After removing the shaft and bearings, clean and inspect the bearings **in place** as follows.



To prevent damage during removal from the shaft, it is recommended that bearings be cleaned and inspected **in place**. It is **strongly** recommended that the bearings be replaced **any** time the shaft and bearings are removed.

Clean the bearing housing, shaft and all component parts (except the bearings) with a soft cloth soaked in cleaning solvent. Inspect the parts for wear or damage and replace as necessary.



**Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area free from excessive heat, sparks, and flame. Read and follow all**

### precautions printed on solvent containers.

Clean the bearings thoroughly in **fresh** cleaning solvent. Dry the bearings with filtered compressed air and coat with light oil.



Bearings must be kept free of all dirt and foreign material. Failure to do so will greatly shorten bearing life. **Do not** spin dry bearings. This may scratch the balls or races and cause premature bearing failure.

Rotate the bearings by hand to check for roughness or binding and inspect the bearing balls. If rotation is rough or the bearing balls are discolored, replace the bearings.


The bearing tolerances provide a tight press fit onto the shaft and a snug slip fit into the bearing housing. Replace the bearings, shaft, or bearing housing if the proper bearing fit is not achieved.

If bearing replacement is required, remove the snap ring (22) and use a bearing puller to remove the inboard and outboard bearings from the shaft.

### Shaft and Bearing Reassembly and Installation (Figure 4)

Inspect the shaft (25) for distortion, nicks or scratches, or for thread damage on the impeller end. Dress small nicks and burrs with a fine file or emery cloth. Replace the shaft if defective.

Clean and inspect the bearings as indicated in **Shaft and Bearing Removal and Disassembly**.



To prevent damage during removal from the shaft, it is recommended that bearings be cleaned and inspected **in place**. It is **strongly** recommended that the bearings be replaced **any** time the shaft and bearings are removed.

### NOTE

*The inboard bearing (26) comes from the manufac-*

turer with a retaining ring installed on the bearing O.D. This retaining ring **must** be removed prior to installation.

The bearings may be heated to ease installation. An induction heater, hot oil bath, electric oven, or hot plate may be used to heat the bearings. Bearings should **never** be heated with a direct flame or directly on a hot plate.

#### NOTE

If a hot oil bath is used to heat the bearings, both the oil and the container must be **absolutely** clean. If the oil has been previously used, it must be **thoroughly** filtered.

Heat the bearings to a uniform temperature **no higher than 250°F (120°C)** and slide the bearings onto the shaft, one at a time, until they are fully seated. This should be done quickly, in one continuous motion, to prevent the bearings from cooling and sticking on the shaft.

#### NOTE

Position the outboard bearing (23) on the shaft with the integral O.D. retaining ring positioned toward the drive end of the shaft.

After the bearings have been installed and allowed to cool, check to ensure that they have not moved away from the shaft shoulders in shrinking. If movement has occurred, use a suitably sized sleeve and a press to reposition the bearings against the shaft shoulders.

If heating the bearings is not practical, use a suitably sized sleeve and an arbor (or hydraulic) press to install the bearings on the shaft.



When installing the bearings onto the shaft, **never** press or hit against the outer race, balls, or ball cage. Press **only** on the inner race.

Secure the outboard bearing to the shaft with the retaining ring (22).

Apply a light coating of oil to the lip of the oil seal (7) and press it into the bearing housing bore with the lip positioned as shown in Figure 4. Press the oil seal into the housing until the face is **just flush** with the machined surface on the housing.

Slide the shaft and assembled bearings into the bearing housing until the retaining ring on the outboard bearing seats against the bearing housing. Use caution not to damage the lip of the oil seal (7) on the shaft threads.



When installing the shaft and bearings into the bearing bore, push against the outer race. **Never** hit the balls or ball cage.

Apply a light coating of oil to the lip of the oil seal (18) and press it into the drive flange (19) with the lip positioned as shown in Figure 4. The face of the oil seal should be just flush with the outer face of the drive flange.

Install the drive flange gasket (21). Apply “Loctite Threadlocker No. 242” or equivalent compound on the threads of the capscrews (16). Install the lock washers (17) and secure the drive flange to the bearing housing by torquing the capscrews to 40 ft. lbs. (480 in. lbs. or 5,5 m. kg.). **Be careful** not to damage the lip of the oil seal (18) on the shaft keyway.

Lubricate a new bearing housing O-ring (30) with grease and install it in the groove in the bearing housing.

Lubricate the bearings as indicated in **LUBRICATION** at the end of this section.


#### Seal Reassembly and Installation

(Figures 4 and 10)



**Most cleaning solvents are toxic and flammable. Use them only in a well ventilated area free from excessive heat, sparks, and flame. Read and follow all precautions printed on solvent containers.**

Clean the seal cavity and shaft with a cloth soaked in fresh cleaning solvent. Inspect the stationary seat bore in the seal plate for dirt, nicks and burrs, and remove any that exist. The stationary seat bore **must** be completely clean before installing the seal.



A new seal assembly should be installed **any time** the old seal is removed from the pump. Wear patterns on the finished faces cannot be realigned during reassembly. Reusing an old seal could result in premature failure.

The seal is not normally reused because wear patterns on the finished faces cannot be realigned during reassembly. This could result in premature failure. If necessary to reuse an old seal in an emergency, **carefully** wash all metallic parts in **fresh** cleaning solvent and allow to dry thoroughly.

Handle the seal parts with extreme care to prevent damage. Be careful not to contaminate precision finished faces; even fingerprints on the faces can shorten seal life. If necessary, clean the faces with a non-oil based solvent and a clean, lint-free tissue. Wipe **lightly** in a concentric pattern to avoid scratching the faces.

Inspect the seal components for wear, scoring, grooves, and other damage that might cause leakage. Clean and polish the shaft sleeve, or replace it if there are nicks or cuts on either end. If any components are worn, replace the complete seal; **never mix old and new seal parts.**

If a replacement seal is being used, remove it from the container and inspect the precision finished faces to ensure that they are free of any foreign matter.

To ease installation of the seal, lubricate the shaft sleeve O-ring and the external stationary seat O-ring with a very **small** amount of light lubricating oil. See Figure 9 for seal part identification.




Figure 9. Seal Assembly



This seal is not designed for operation at temperatures above 160°F (71°C). Do not use at higher operating temperatures.

Lubricate the stationary seat O-ring with water or light oil. Press the stationary seat into the seal plate (6) until fully seated.

Position the seal plate over the shaft and secure it to the bearing housing (10) with the hardware (14 and 15). **Be careful** not to damage the stationary seat on the shaft threads.

Lubricate a new seal plate O-ring (29) with grease and install it in the groove in the seal plate.

To prevent damaging the shaft sleeve O-ring (5) on the shaft threads, cover the threads with electrical or duct tape. Slide the O-ring over the shaft until it seats against the shaft shoulder. Remove the tape covering the threads. Check to ensure that the shaft threads are free of any tape residue and clean as required before proceeding with seal installation.

Lubricate the O.D. of the seal sleeve with a **small** amount of light oil. Slide the rotating subassembly (consisting of rotating element, bellows and retainer) onto the shaft sleeve (4) until the sealing face is just flush with the undercut end of the sleeve.

Slide the assembled shaft sleeve and rotating portion of the seal onto the shaft until the seal faces contact. Continue to press the sleeve onto the shaft until it is fully seated against the shaft shoulder.

Install the seal spring and centering washer. Lubricate the seal as indicated in **LUBRICATION** after the impeller is installed.

### Impeller Installation and Adjustment

#### (Figure 4)

Inspect the impeller (1) and replace it if cracked or badly worn.



The shaft and impeller threads **must** be completely clean before reinstalling the impeller. Even the slightest amount of dirt on the threads can cause the impeller to seize to the shaft, making future removal difficult or impossible without damage to the impeller or shaft.

Install the same thickness of impeller adjusting shims (2) as previously removed and screw the impeller onto the shaft until tight.

### NOTE

*At the slightest sign of binding, **immediately** back the impeller off, and check the threads for dirt. **Do not** try to force the impeller onto the shaft.*

A clearance of .025 to .040 inch (0,64 to 1,02 mm) between the impeller and the seal plate is necessary for maximum pump efficiency. Measure this clearance and add or remove impeller adjusting shims as required.

### Pump Casing Installation

#### (Figure 3)

Install a pair of “S” hooks in two opposing holes in the drive flange (19, Figure 4). Connect a sling and suitable lifting device to the “S” hooks.


Use the lifting device to lower the rotating assembly into the pump casing. Align the holes in the bearing housing for the mounting hardware (20 and 32) with those in the pump casing.

Install the adjusting shims (33) and secure the rotating assembly to the pump casing with the hardware (20 and 32).

### Securing Pump End to Power Source

#### (Figure 2)

Align the integral key in the bushing (20) with the shaft keyway and slide the bushing and sprocket (19) onto the shaft to the dimension shown in Figure 10.



**Figure 10. Drive Sprocket Positioning**

Secure the bushing and sprocket to the shaft by torquing the bushing screws to 23.3 ft. lbs. (280 in. lbs. or 3,2 m. kg.). Install the belt (11) over the sprocket and up through the slot in the drive flange (19, Figure 4).

Use a suitable hoist and sling to position the air compressor assembly (6) on the drive flange (19, Figure 4). Slide the belt (11) over the air compressor sprocket. Use a pry bar to raise the compressor high enough to install the spacers (22) between the compressor and the drive flange. Secure the compressor to the drive flange with the hardware (12, 13 and 14). Reinstall the guard (7) and secure it with the hardware (8, 9 and 10).

**(Figure 1)**

Install shaft key (24, Figure 4) in the impeller shaft keyway. Install half of the coupling (3) on the impeller shaft. Using a suitable lifting device, position the pump end assembly on the base. Support the pump end assembly with suitable wood blocks and shims.

Align the coupling halves and reinstall the attaching hardware. Align the coupling halves as described in **Installation, Section B**. Install the inter-

mediate guards (20, Figure 4) and the coupling guard (7) and secure the guards to the drive flange with the previously removed hardware (4, 5 and 6).

**Suction Spool and Wear Plate Installation and Adjustment**

**(Figures 3 and 11)**


If the wear plate (30) was removed for replacement, install the small O-ring (29) in the groove in the suction head and the large O-ring (28) on the shoulder of the wear ring and lubricate them with a light coating of grease.

Align the wear ring studs with the corresponding holes in the suction spool (23) and press it into the suction spool until fully seated. Secure the wear ring with the previously removed hardware (14 and 15).

Install the O-ring (31) in the groove in the suction spool and lubricate it with a light coating of grease. If the foot bracket (13) was removed, secure it to the suction spool with the previously removed hardware (16, 17 and 18).

Align the suction spool over the casing studs (4) and slide it into the pump casing. Use two back cover nuts (21) on diagonally opposing studs to press the suction spool into the pump casing until the wear plate **just touches** the impeller when the shaft is turned by hand. **Tighten the hand nuts evenly to avoid binding.**

Clearance between the impeller and wear plate is adjusted using the four back cover nuts and locking collars (27). There are 18 detents on the I.D. of each locking collar. Indexing the collars one detent on the adjusting screws represents approximately .005 inch (0,13 mm) of wear plate clearance. The recommended clearance between the wear plate and the impeller is .010 to .012 inch (0,25 to 0,30 mm).



**Figure 11. Installing and Adjusting Suction Spool**

Screw two of the adjusting screws (22) into the tapped holes in the suction spool until they are **just flush** with the machined surface on the suction spool.

With the wear plate just touching the impeller, position the locking collars (27) over the adjusting screws so the holes in the collars for the locking screws (19) align approximately with the holes in the suction spool.

Loosen the back cover nuts used to press the suction spool into the pump casing one full turn.

Pull the collars off the adjusting screws, index them three detents counterclockwise, and reinstall the collars on the adjusting screws. Use the collars to turn the adjusting screws clockwise until the holes in the locking collars realign with the tapped screw holes in the back cover plate. Secure the locking collars to the back cover plate with the hardware (19 and 20). Install the two remaining back cover nuts snugly against the adjusting screws.

Remove the first two back cover nuts from their studs. Turn the adjusting screws clockwise until they engage the pump casing. Install the locking

collars and hardware (19 and 20). Reinstall the back cover nuts.

Be sure the wear plate does not scrape against the impeller.

Over time it may be necessary to repeat the adjustment process to compensate for normal wear between the impeller and wear plate. When all of the adjustment has been used on the suction spool side of the pump, an additional 0.120 inch (3 mm) of adjustment may be obtained by removing the rotating assembly adjusting shims (33).

Allow an installed pump to completely cool before draining liquid from the pump casing. Remove the suction spool. Remove the rotating assembly adjusting shims, then reinstall the hardware securing the rotating assembly to the pump casing. Perform the suction spool adjustment procedure described above to obtain the proper face clearance.

### Discharge Check Valve Reassembly and Installation

#### (Figure 2)

If the discharge check valve (26) was disassembled to replace the flapper or cover O-ring, position the flapper in the valve body and check to ensure free movement.

Install the valve cover O-ring and secure the cover to the body with the previously removed hardware.

Apply a small amount of light grease to the discharge flange gasket to hold it in place and position it against the pump casing flange. Support the discharge check valve assembly using a sling and a suitable lifting device. Using the previously removed hardware, secure the discharge check valve assembly and flange gasket to the pump assembly (1).

### Priming Chamber Assembly and Installation

#### (Figure 6)

Clean and inspect the components of the priming valve (1). Inspect the linkage and ensure the orifice button (not shown) squarely engages the valve seat. Replace the orifice button if required (see **Priming Chamber Removal and Disassembly** for orifice button removal).

If the orifice button was removed, screw the new orifice button into the linkage bar until fully seated. Align the hole in the linkage bar with the holes in the bracket and reinstall the pivot pin. Secure the pivot pin with the previously removed “e-clip”.

Adjust the orifice button seating as necessary by screwing the orifice button into or out of the linkage bar. Proper adjustment is achieved when the orifice button fully seats against the orifice before the linkage bar on the float bottoms against the threads on the orifice button. When adjustment is complete, install and tighten the lock washer and hex nut securing the orifice button.

Install the strainer (6) and priming valve gasket (4).

Lower the float into the priming chamber (5) and secure the priming valve with the previously removed hardware (2 and 3).

#### (Figure 5)

Install the baffle (9) and gasket (8) and use a sling and suitable lifting device to position the priming chamber assembly on the pump casing (1, Figure 3). Secure the priming chamber assembly with the hardware (6 and 7).

Reconnect the air discharge tubing to the priming chamber assembly. Reconnect the suction piping to the suction spool.

## LUBRICATION

### (Figure 3)

#### Seal Assembly

Fill the seal cavity through the hole for the vented plug (6) with SAE No. 30 non-detergent oil to the middle of the sight gauge (8). Check the oil level regularly and refill as required. When lubricating a

dry seal cavity, add approximately 9.4 U.S. quarts (8,9 liters) of oil to the level indicated. Clean and reinstall the vented plug. Maintain the oil level at the middle of the sight gauge.

#### Bearings

### (Figure 4)

The bearing housing was fully lubricated when shipped from the factory. Check the oil level regularly through the sight gauge (8) and maintain it at the midpoint of the gauge. When lubrication is required, remove the air vent (12) and add SAE No. 30 non-detergent oil through the opening. When lubricating a dry (overhauled) intermediate, fill the bearing cavity with approximately 40 ounces (1,2 liter).

Clean and reinstall the air vent. **Do not** over-lubricate. Over-lubrication can cause the bearings to over-heat, resulting in premature bearing failure.

Under normal conditions, drain the bearing housing once each year and refill with clean oil. Change the oil more frequently if the pump is operated continuously or installed in an environment with rapid temperature change.



Monitor the condition of the bearing lubricant regularly for evidence of rust or moisture condensation. This is especially important in areas where variable hot and cold temperatures are common.

For cold weather operation, consult the factory or a lubricant supplier for the recommended grade of oil.

**For Warranty Information, Please Visit  
[www.grpumps.com/warranty](http://www.grpumps.com/warranty)  
or call:  
U.S.: 419-755-1280  
Canada: 519-631-2870  
International: +1-419-755-1352**

**GORMAN-RUPP PUMPS**