May 17, 1999 Rev. B 05-7-2025

Use With: OM-03989 MR-03991



## PUMP MODEL RD3A31-B

MANUAL PART 2 of 3

PARTS
LIST
WITH
PERFORMANCE CURVE

THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

# Register your new Gorman-Rupp pump online at www.grpumps.com

Valid serial number and e-mail address required.

## **RECORD YOUR PUMP MODEL AND SERIAL NUMBER**

Please record your pump model and serial number in the								
spaces	provided	below.	Your	Gorman-Rupp	distributor			
needs th	nis informa	tion whe	n you	require parts of	r service.			
Pump M	1odel:							

Serial Number:

RD SERIES PUMP PL—04016

## PERFORMANCE CURVE - SECTION A

## RECORDING MODEL AND SERIAL NUMBERS

Please record the pump model and serial number in the spaces provided below and in the separate <a href="Installation/Operation Manual">Installation/Operation Manual</a> accompanying your pump. Your Gorman-Rupp distributor needs this information when you require parts or service.

Pump Model:	
Serial Number:	

#### WARRANTY INFORMATION

The pump warranty is provided as part of Gorman-Rupp's support program for customers who operate and maintain their equipment as described in this manual and other accompanying literature. Please note that should the equipment be abused or modified to change its performance beyond the original factory specifications, the warranty will become void and any claim will be denied.

#### PERFORMANCE CURVE

The performance curve on the following page is based on 70° F (21° C) clear water at sea level, corrected to 0.80 specific gravity, with minimum suction lift. Since pump installations are seldom identical, your performance may be different due to such factors as viscosity, specific gravity, elevation, temperature, and impeller trim.


If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify performance or part numbers.



Pump speed and operating condition points must be within the continuous performance range shown on the curve(s).

PAGE A - 1 PART LIST MANUAL

PL-04016 RD SERIES PUMP



### Performance Curve — Model RD3A31—B

PARTS LIST MANUAL PAGE A – 2


RD SERIES PUMP PL-04016

This Page Intentionally Blank

PAGE A – 3 PART LIST MANUAL

В RD3A31-B

S/N 1212293 Up PUMP ISSUE 2



## THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

RD3A31-B

**S/N 1212293 Up PUMP ISSUE 2** 

## PARTS LIST Pump Model RD3A31-B

If your pump serial number is followed by an "N", your pump is **NOT** a standard production model. Contact the Gorman-Rupp Company to verify part numbers.

ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY	ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY
1 2 * 3 * 4 5 6 7 8 9 10 11 12 13 *	SHAFT KEY BRG HOUSING ASSY NAME PLATE DRIVE SCREW LUBE DECAL DISCH TUBE ASSY MALE ELBOW SCREW T-TYPE LOCKWASHER DISCHARGE STICKER	W01173-02 38623-530 N0611 44143-078 2613DZ BM#04-03 38816-081 46335-063 25812-011 21513-314 AL04 6588BJ K79329-23 23962-506	11010 13048 15990  13990 17000  17170  15990	1 1 1 1 1 2 1 1 1 2 2 1 1 1 2 2 1	26 27 28 29 30 31 32 33 34 35 36 37 38	SUCTION STICKER PIPE PLUG PIPE PLUG STRAINER CONNECTOR SUCT TUBE ASSY PIPE PLUG  * PUMP CASING GASKET STUD HEX NUT BEARING HSG SUPPOR HEX HD CAPSCREW LOCKWASHER FLAT WASHER	6588AG P02 P06 26841—094 25812—214 46335—076 P02 R12531 C0807 D08 T R12852—0 B0805 J08 K08	4 6 15079 20000 15991 15991	1 1 1 1 1 1 1 12 12 12 2 2
15 * 16	IMPELLER NUT GUIDE VALVE STEM PIPE PLUG DISCH VALVE SPRING VALVE STEM	K75776 K86489 K86487 P02 K86490 K86488 25152—335 38345—629 D#10S AK#10 P02	15111 15991 15991 15079  17000  13047 15991 15991 15079	1 1 1 1 1 1 1 1 1 1		SHOWN:  * DISCH CHK VALVE GSK  * DISCH FLANGE GASKE' ROTATION DECAL BEARING TAG INSTRUCTION TAG  ONAL: COMPANION FLANGES —COMPANION FLANGES TEEL TUBING KIT	T N14147 2613M 6588ABB 38817—01	OISCHARG	1 1 1 1 1


 $<sup>\</sup>frak*$  INDICATES PARTS RECOMMENDED FOR STOCK


<sup>†</sup> ALL ROTO-PRIME® IMPELLERS ARE TRIMMED.

SEE ACCOMPANYING LITERATURE FOR INDIVIDUAL PARTS, MAINTENANCE AND REPAIR.

B RD3A31-B

### S/N 1212293 Up PUMP ISSUE 2





## THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

RD3A31-B

**S/N 1212293 Up PUMP ISSUE 2** 

PARTS LIST 44143-078 Bearing Housing Assembly


ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY	ITEM PART NAME PART MAT'L NO. NUMBER CODE	QTY
1 *	SEAL ASSEMBLY	25271-921		1	26 PIPE PLUG P06 15079	1
2	SEAL RETAINING RING	24124-243		1	27 * CENTER PLATE GASKET N14145 19210	1
3	BEARING CAP	R12770-02	10010	1	28 HEX HD CAPSCREW B0615 15991	8
4	BEARING LOCK NUT	23962-011		1	29 LOCKWASHER J06 15991	8
5 *	BEARING CAP GASKET	N18938-01	18000	1	30 DOWEL PIN 21133-073	2
6	TAB WASHER	23962-511		1	31 * OIL SEAL 25227-240	1
7 *	OUTBOARD BEARING	23282-011		1	32 PIPE PLUG P02 15079	1
8	AIR VENT	S1703		1	33 * OIL SEAL 25227-240	1
9	BEARING HOUSING	W01172-03	11010	1	34 CONNECTOR 25812-214	1
10 *	IMPELLER SHAFT	T08467-02	15010	1	35 HEX HD CAPSCREW B0605 15991	4
11 *	BALL BEARING	23282-010		1	36 LOCKWASHER J06 15991	4
12	BEARING RET RING	24124-245		1	37 PIPE NIPPLE T0606 15079	1
13	PIPE PLUG	P02	15079	1	38 CHECK VALVE 26641-112	1
14	AIR VENT	S2162		1	39 MALE ELBOW 25812-011	1
15 *	SPACER PLATE GASKET	N14144	18000	1		
16	SPACER PLATE	N14129-02	11010	1	OPTIONAL:	
17	PRESS REG SPRING CAP	K68064	15991	1	SST IMPELLER SHAFT T08467-02 17080	1
18 <del>*</del>	SPRING CAP GASKET	K86067		1	<ul> <li>OIL LUBE BEARING</li> </ul>	
19 *	PRESS REG SPRING	K76301		1	HOUSING ASSEMBLY 44143-097	1
20	BODY COVER	T07826-04	11010	1	-INBOARD BEARING S1088	1
21 *	ROTOR WOODRUFF KEY	K61559	15990	1	-OUTBOARD BEARING \$1077	1
22 *	ROTOR BLADE	K79300-22		6	-OIL CUP 26713-051	1
23	GROUP GRIND	42212-014		1	GROUP GRIND WITH	
24 *	LOCATING PIN	21154-666		1	C.I. ROTOR LK05266	1
25 †	CENTER PLATE GASKET	N14145	18010	2	TEFLON SEAL 25271-761	1

<sup>\*</sup> INDICATES PARTS RECOMMENDED FOR STOCK

<sup>† 2</sup> GASKETS REQUIRED WHEN ROTOR OR SLIDE IS THICKER THAN CENTER PLATE.

<sup>•</sup> ALL OTHER COMPONENTS SAME AS STANDARD BEARING HOUSING ASSEMBLY.

S/N 1212293 Up PUMP ISSUE 2



## PARTS LIST 42212-014 Group Grind

ITEM NO.	PART NAME	PART NUMBER	MAT'L CODE	QTY
1	CENTER PLATE	NOT AVAILABLE		1
2	ROTOR	NOT AVAILABLE		1
3	SLIDE	NOT AVAILABLE		1

**NOTE:** THE GROUP GRIND MUST BE REPLACED AS A COMPLETE UNIT: INDIVIDUAL PIECE PARTS ARE NOT SOLD SEPARATELY.

## THE GORMAN-RUPP COMPANY • MANSFIELD, OHIO

5 of 5

# For U.S. and International Warranty Information, Please Visit www.grpumps.com/warranty or call:

U.S.: 419-755-1280 International: +1-419-755-1352

For Canadian Warranty Information,
Please Visit www.grcanada.com/warranty
or call:
519-631-2870